

ACTIVAL™

Three-Way Ball Valve with Threaded-End Connection

■ General

ACTIVAL Model VY5303A is a three-way ball valve with threaded-end connection (ISO 7-1: 1994). It proportionally controls chilled/hot water for HVAC (heating, ventilation, and air conditioning) applications.

Model VY5303A has bronze valve body, stainless-steel ball and stem, and the components exposed to process fluid are made of other corrosion resistant materials.

Cv value and size variation of Model VY5303A are best suited to HVAC control.

It combines with the actuator Model MY53X0A. Regarding the detailed information on the actuator, refer to Specifications/Instructions of ACTIVAL Model MY53X0A.




■ Features

- Compact and lightweight:
Valve can be installed in a restricted space such as inside of compact AHU (air handling unit).
- Bronze valve body applicable to PN16.
- Easy assembly with Model MY53X0A actuator using no tool, and no adjustment required.
- Linear flow characteristic.

IMPORTANT:
To control ACTIVAL with a third-party controller, please consult with Azbil Corporation's sales personnel.

■ Dimensions



■ Model Numbers

Base model number	Material	—	Size/CV	Description
VY53				Three-way valve with threaded-end connection
	0			Bronze
		3A00		Fixed
			21	DN20 (3/4") / 4 in Cv
			22	DN20 (3/4") / 6.3 in Cv
			23	DN25 (1") / 10 in Cv
			31	DN32 (1 1/4") / 16 in Cv
			41	DN40 (1 1/2") / 25 in Cv

Model number	Dimension					
	DN	Rc*	L (mm)	H (mm)	E (mm)	M (mm)
VY5303A0021	20	Rc 3/4	72	50	33	36
VY5303A0022	20	Rc 3/4	72	50	33	36
VY5303A0023	25	Rc 1	85	54	40	42
VY5303A0031	32	Rc 1 1/4	99	69	49	50
VY5303A0041	40	Rc 1 1/2	109	72	55	52

* Rc: Internal tapered pipe thread complying with ISO 7-1:1994.

Figure 1. Dimensions and maintenance (mm)

Safety Instructions

Please read instructions carefully and use the product as specified in this manual. Be sure to keep this manual near by for ready reference.

Usage Restrictions

This product is targeted for general air conditioning. Do not use this product in a situation where human life may be affected. If this product is used in a clean room or a place where reliability or control accuracy is particularly required, please contact Azbil Corporation's sales representative. Azbil Corporation will not bear any responsibility for the results produced by the operators.

Warnings and Cautions

 WARNING	Alerts users that improper handling may cause death or serious injury.
 CAUTION	Alerts users that improper handling may cause minor injury or material loss.

Signs


	Alerts users to possible hazardous conditions caused by erroneous operation or erroneous use. The symbol inside \triangle indicates the specific type of danger. (For example, the sign on the left warns of the risk of electric shock.)
	Notifies users that specific actions are prohibited to prevent possible danger. The symbol inside \ominus graphically indicates the prohibited action. (For example, the sign on the left means that disassembly is prohibited.)
	Instructs users to carry out a specific obligatory action to prevent possible danger. The symbol inside \bullet graphically indicates the actual action to be carried out. (For example, the sign on the left indicates general instructions.)

 CAUTION	
	Do not freeze this product. Doing so may damage the valve body and cause leakage.
	When piping this product, be sure there is no foreign matter in the pipes. If foreign matter remains in the pipes, the product may break down.
	Install and use this product according to the specifications stated in this manual. Failure to do so may cause device failure.
	Do not screw a pipe excessively far into this product. Doing so may damage the inside of the valve and cause leakage outside of the valve, or may cause malfunction.
	After installation, make sure no fluid leaks from the valve-pipe connections. Improper piping may cause fluid leakage outside of the valve.
	Do not put a load or weight on this product. Doing so may damage the product.
	Do not carelessly touch this product when it is used to control hot water. Doing so may result in burns, because the product reaches a high temperature.

■ Specifications

Item	Specification			
Type	Three-way ball valve with threaded-end connection (internal), proportional control			
Applicable actuator	Model MY53X0A			
Pressure rating	PN16 (Max. working pressure: 1.6 MPa)			
Valve size, Cv, Close-off rating	Model number	Size	Cv	Close-off rating
	VY5303A0021	DN20 (3/4")	4.0	0.5 MPa
	VY5303A0022	DN20 (3/4")	6.3	0.5 MPa
	VY5303A0023	DN25 (1")	10	0.5 MPa
	VY5303A0031	DN32 (1 1/4")	16	0.3 MPa
	VY5303A0041	DN40 (1 1/2")	25	0.3 MPa
Mounting orientation	Horizontal or vertical mounting			
Materials	Body	Cast bronze (equivalent to: - CuAn5An5Pb5-C (DIN EN1982) for global standard - CAC406 (JIS) for Japanese standard)		
	Seat ring	PTFE		
	Ball	Cast stainless steel		
	Stem	Stainless steel		
	O-ring	EPDM		
End connection	Internal threaded-end (equivalent to ISO 7-1: 1994)			
Applicable fluid	Chilled/hot water, brine (ethylene glycol solutions, 50 wt.% max.)			
Allowable fluid temperature	0 °C to 100 °C (non-freezing)			
Flow characteristics	Linear characteristic			
Rangeability	30 : 1			
Seat leakage in fully closed position	0.01 % of rated Cv value (0.0006 Cv or less for Model VY5303A0021)			
Installation locations	Indoor / outdoor Note: Salt air, corrosive gas, flammable gas, and organic solvent must be avoided.			
Mounting position	Refer to ■ "Installation," ● "Mounting position."			
Weight * Actuator to combine is excluded.	Model VY5303A0021	0.7 kg		
	Model VY5303A0022	0.7 kg		
	Model VY5303A0023	0.9 kg		
	Model VY5303A0031	1.4 kg		
	Model VY5303A0041	1.7 kg		

■ Parts Indication and Materials



No.	Part name	Material
1	Body	Cast bronze (equivalent to: - CuAn5An5Pb5-C (DIN EN1982) - CAC406 (JIS))
2	Cap	Cast bronze (equivalent to CuAn5An5Pb5-C (DIN EN1982))
3	Seat ring	PTFE
4	Ball	Cast stainless steel
5	Stem	Stainless steel
6	O-ring	EPDM

Figure 2. Parts identification and materials

■ Flow Characteristic




Figure 3. Flow characteristic diagram

■ Installation

● Precautions for installation

 CAUTION	
	Do not freeze this product. Doing so may damage the valve body and cause leakage.
	When piping this product, be sure there is no foreign matter in the pipes. If foreign matter remains in the pipes, the product may break down.
	Install and use this product according to the specifications stated in this manual. Failure to do so may cause device failure.

- To remove foreign substances inside the pipes, install a strainer on the inflow side of each valve. In case that the strainers cannot be installed on the inflow side of each valve, install it on the pipe diverting sections (sections diverting from main piping system to sub piping system).
- Install the valve so that the flow direction of process fluid agrees with the arrow indicated on the valve body.

● Installation location

- Install the ACTIVAL (valve and the assembled actuator) in a position allowing easy access for maintenance and inspection. Fig. 1 shows the minimum clearance for maintenance and inspection. When installing the ACTIAL in a ceiling space, provide an access hole within the 50 cm radius of the ACTIVAL. And, place a drain pan under the valve.
- Do not install the product nearby a steam coil or a hot-water (in high temperature) coil. High heat radiation may result in an actuator malfunction.
- Do not mount the valve on a pipe where water hammer occurs, or where solid objects including slug may accumulate.

● Mounting position

The valve (assembled with the actuator) can be mounted in any position ranging from upright to sideways (90° tilted). The valve should be installed with its actuator vertically positioned above the valve body. However, the valve must be installed always in upright position outdoors.




Figure 4. Mounting position

● Piping

 CAUTION	
	Do not screw a pipe excessively far into this product. Doing so may damage the inside of the valve and cause leakage outside of the valve, or may cause malfunction.

- Install a bypass pipe and gate valves on the inflow, outflow, and bypass sides. Also, install a strainer (with 40 or more meshes) on the inflow side.
- When installing the valve to pipes, do not allow any object, such as chips, to get inside a pipe or valve. Valve cannot fully closes, or the valve seat may get damaged causing fluid leakage, due to a foreign object jammed inside the valve.
- When piping, do not apply too much sealing material, such as solidifying liquid and tape, to the pipe connection sections so that these materials flow into the valve. Valve cannot fully closes, or the valve seat may get damaged causing fluid leakage, due to the sealing material jammed inside the valve.

- When connecting the valve to pipes, hold the valve body (where a pipe is screwed) with a tool such as a wrench, and screw the pipe into the valve. (See Fig. 5.) Do not apply excessive torque to the pipe. Refer to the table in Fig. 5 for the recommended torque.




Figure 5. Valve connection to a pipe

- Before activating the ACTIVAL (valve with actuator), flush the pipes (with the ACTIVAL installed) at the maximum flow rate to remove all the foreign substances. Fully open (in 100 % position) the ACTIVAL to flush. (Factory preset position: Port A 100 %)

⚠ CAUTION	
❗	After installation, make sure no fluid leaks from the valve-pipe connections. Improper piping may cause fluid leakage outside of the valve.
🚫	Do not put a load or weight on this product. Doing so may damage the product.

● **Flow direction**




Figure 6. Flow direction

Identification of the ports A and B

Valve body without heat insulation material wrapped:

Identify the ports with the letters 'A' and 'B' embossed on the valve body.

Valve body with the insulation material wrapped:

Identify the ports with the tip of the valve joint surface, as shown in Fig. 7.

The port on the side where the tip points is the port B.




Figure 7. Identification of port A / B

● **Heat insulation**

Do not apply heat insulation to the joint surface. Correctly apply heat insulation to the valve as shown in Fig. 8.




Figure 8. Heat insulation

● **Factory preset position**

Port A of the ACTIVAL is set in 100 % (fully open) position for shipment.

■ Assembling the valve Model VY5303A with the actuator Model MY53X0A

IMPORTANT:

- Do not assemble the valve with any other actuator.
- The actuator can be horizontally rotated every 90 degrees to fit into the valve mounting position (4 mounting positions). Make sure the positions of the actuator and the valve as follows, referring to Fig. 8:
 - Actuator: Indicator/manual lever points at 100 (fully open position).
 - Valve: An arrow on the top of the stem points at 100 (fully open position).
 (Align the hole on the side of the stem with the tip at the joint surface as 'a' in Fig. 8 shows.)
- Set the ACTIVAL (actuator and valve) in 100 % position when changing the mounting position. If the valve in 0 % position is assembled with the actuator in 100 % position, the actuator put torque on the closed valve, and the gear of the actuator gets damaged.




Figure 9. Mounting the actuator onto the valve

● Mounting procedure

- 1) Manually turn the indicator/manual lever of the actuator to "100" with the lever release button pressed.




Figure 10. Indicator/manual lever at 100 % (fully open) position

- 2) Move the lock lever to right-end to unlock.




Figure 11. Unlocking the lock lever

- 3) Confirm that the arrow on the top of the valve stem points at "100". A hole on the side of the stem faces the same direction at which the tip of the valve joint surface (with the actuator) points when the valve position is fully open. (See 'a' in Fig. 9.)




Figure 12. Valve stem pointing at 100 % (fully open) position

- 4) Assemble Model MY53X0A actuator with the valve. Engage 4 pins of the actuator with the mating holes on the valve joint surface.

- 5) Move the lock lever to left-end to lock. Locked position is indicated with the groove as shown in Fig. 13.




Figure 13. Locking the lock lever

■ Application Examples

● Diverting application




Figure 14. Application example: Diverting valve

● Mixing application




Figure 15. Application example: Mixing valve

■ Mounting Examples

● Diverting application




Figure 16. Mounting examples: Diverting valve

● Mixing application




Figure 17. Mounting examples: Mixing valve

■ Maintenance

⚠ CAUTION	
⊘	Do not put a load or weight on this product. Doing so may damage the product.
⊘	Do not carelessly touch this product when it is used to control hot water. Doing so may result in burns, because the product reaches a high temperature.

- Inspect the ACTIVAL according to Table 1.
- Manually open/close the ACTIVAL at least once a month if it is left in inactive state for a long period after installation.
- Visually inspect the ACTIVAL (e.g., fluid leakage) every six months. If any of the problems described in Table 2 is found, take corresponding actions shown in the table. If your problem is not solved by the corresponding action, please contact Azbil Corporation near you.

Table 1. Inspection items and details

Inspection item	Inspection interval	Inspection detail
Visual inspection	Semiannual	<ul style="list-style-type: none"> Loosened lock lever of the assembled actuator Valve and actuator damages Fluid leakage from the gland/pipe connecting part
Operating status	Semiannual	<ul style="list-style-type: none"> Unstable open/close operation Abnormal noise and vibration
Routine inspection	Any time	<ul style="list-style-type: none"> Abnormal noise and vibration Unstable open/close operation Valve hunting

Table 2. Troubleshooting

Problem	Part to check	Action
Valve does not operate smoothly / valve stops halfway / valve does not operate at all.	Conditions of the power applied and of the input signal applied to the actuator. Wiring condition/disconnected wires of the actuator. Foreign substance jammed.	Check the power supply and the controller connected to. Check the wiring. Remove foreign substance by manually opening the valve.
Fluid leaks to the outside of the valve when the valve is in fully closed position.	Confirm the mounting procedure referring to the section Assembling the valve Model VY5303A with the actuator Model MY53X0A.	Dismount and remount the actuator according to the correct mounting procedure.
The valve vibrates or produces an abnormal noise.	Primary pressure condition. Differential pressure condition. Control stability.	Reset and adjust the valve inlet/outlet pressure. Modify control parameter/PID setting of the controller.
The auxiliary switch of the actuator does not operate.	Auxiliary switch (cam switch) condition. Wiring condition/disconnected wires of the actuator.	Redo the cam switch setting. Check the wiring.
Connecting part between the valve and actuator vibrates or produces an abnormal noise.	Lock lever condition of the actuator. Yoke damages.	Lock the lock lever. Consult with our sales/service personnel.
Water flowing sound level is too high.	—	Consult with our sales/service personnel.
Actuator in operation produces an abnormal noise.	—	Consult with our sales/service personnel.

■ Disposal

Dispose of this product as industrial waste in accordance with your local regulations.
Do not reuse all or any part of the product.

ACTIVAL is a trademark or registered trademark of Azbil Corporation in Japan or in other countries.



Specifications are subject to change without notice.

Azbil Corporation
Building Systems Company

<https://www.azbil.com/>