

C15M Single Loop Controller User's Manual "Installation"

Thank you for purchasing the C15M.
Before operating this product described in this User's Manual, please take note of the following points regarding safety.
Be sure to keep this manual nearby for handy reference.

Please read the "Terms and Conditions" from the following URL before ordering or use:
<http://www.azbil.com/products/bi/order.html>

NOTICE

Be sure that the user receives this manual before the product is used.

Copying or duplicating this user's manual in part or in whole is forbidden. The information and specifications in this manual are subject to change without notice.

Considerable effort has been made to ensure that this manual is free from inaccuracies and omissions. If you should find an error or omission, please contact Azbil Corporation.

In no event is Azbil Corporation liable to anyone for any indirect, special or consequential damages as a result of using this product.

© 2013 Azbil Corporation All Rights Reserved.

This manual explains handling precautions, mounting, wiring procedures, PV range types, parameter list and main specifications only.

■ Unpacking

Check the following items when removing the C15MT from its package:

Name	Part No.	Q'ty	Remarks
Mounting Bracket	81446403-001	1	
Gasket	81409657-001	1	
User's Manual	CP-UM-5410ET	1	This Manual

SAFETY PRECAUTIONS



WARNING

Warnings are indicated when mishandling this product might result in death or serious injury to the user.



CAUTION

Cautions are indicated when mishandling this product might result in minor injury to the user, or only physical damage to this product.

WARNING

- ❗ Note that incorrect wiring of the C15M can damage the C15M and lead to other hazards. Check that the C15M has been correctly wired before turning the power ON.
- ❗ Before wiring, or removing/mounting the C15M, be sure to turn the power OFF. Failure to do so might cause electric shock.
- 🚫 Do not touch electrically charged parts such as the power terminals. Doing so might cause electric shock.
- 🚫 Do not disassemble the C15M. Doing so might cause electric shock or faulty operation.

CAUTION

- ❗ Use the C15M within the operating ranges recommended in the specifications (temperature, humidity, voltage, vibration, shock, mounting direction, atmosphere, etc.). Failure to do so might cause fire or faulty operation.
- 🚫 Do not block ventilation holes. Doing so might cause fire or faulty operation.
- ❗ Wire the C15M properly according to predetermined standards. Also wire the C15M using specified power leads according to recognized installation methods. Failure to do so might cause electric shock, fire or faulty operation.
- ❗ Do not allow lead clippings, chips or water to enter the controller case. Doing so might cause fire or faulty operation.
- ❗ Firmly tighten the terminal screws at the torque listed in the specifications. Insufficient tightening of terminal screws might cause electric shock or fire.
- 🚫 Do not use unused terminals on the C15M as relay terminals. Doing so might cause electric shock, fire or faulty operation.
- ❗ We recommend attaching the terminal cover (sold separately) after wiring the C15M. Failure to do so might cause electric shock, fire or faulty operation.
- ❗ Use the relays within the recommended service life. Continuous use might cause fire or faulty operation.
- ❗ Use Azbil Corporation's "SURGENON" if there is the risk of power surges caused by lightning. Doing so might cause fire or faulty operation.
- 🚫 Do not operate the keys with a propelling pencil or sharp-tipped object. Doing so might cause faulty operation.

Mounting

■ Location

Install the controller in the following locations:


- Common mode voltages for I/O excluding the power supply and relay contact output: The voltage to ground is 30Vr.m.s max., 42.4V peak max., and 60Vdc max.
- Not high or low temperature / humidity.
- Free from silicone gas and other corrosive gases such as sulfide gas.
- Less dust or soot.
- Appropriately processed locations to prevent direct sunlight, wind or rain.
- Less mechanical vibration and shock.
- Not close to the high voltage line, welding machine or electrical noise generating source.
- The minimum 15 meters away from the high voltage ignition device for a boiler.
- Less effect by the magnetic.
- No flammable liquid or gas.

■ Mounting Procedure

- The mounting must be horizontal within 10 degrees tilted in back side lowering or within 10 degrees tilted in back side rising.
- In the case of panel mount type (C15MT), the mounting panel should be used with a thickness of less than 9 mm of firm board.

■ External Dimensions


● C15MT (Panel Mount Type)



! Handling Precautions

- To fasten this controller onto the panel, tighten a mounting bracket screws, and turn one more half turn when there is no play between the bracket and panel. Excessively tightening the screws may deform the controller case.

● Panel Cutout Dimensions



! Handling Precautions

- When three or more units are gang-mounted horizontally, the maximum allowable ambient temperature is 40°C.
- If dustproof or waterproof protection is required, mount the device using the stand-alone mounting method. If gang-mounted, dustproof and waterproof protection may not be maintained.
- Provide a space of at least 50mm or more above and below the controller.

Wiring

Be sure to provide a switch within operator reach for shutting OFF the main power supply to the controller in the main supply wiring.
Also, in case of AC power supply models, the main supply wiring also requires a time-lagged type (T) fuse (rated current: 0.2A, rated voltage: 250 V). (IEC127)

The following table shows the meaning of the symbols in the terminal wiring label on the controller side:


Symbols	Meaning
~	AC power supply
⚠	Caution, fear of electric shock
⚠	Caution

! Handling Precautions

- Before wiring the C15M, verify the controller's model No. and terminal Nos. written on the label on the side of the body. Inspect all wiring once wiring work for the C15M has been completed.
- Provide a distance of at least 50cm between I/O lead wires or communications lead wires and power lead wires of 100V min. Also, do not pass these lead wires through the same piping or wiring duct.
- Be careful not to allow any crimp terminals lugs to touch adjacent terminals.
- To connect 2 (max.) crimp terminals to the same terminal screw, bend the crimp terminals beforehand.
- Connect wires to terminals 1 - 6 and 13 - 18 from the left (when viewing the terminal block).
- Use crimp terminals compatible with M3 terminal screws, as shown in the diagram.
A: 5.8mm max. B: 5.5 to 7.6mm
- When the power to this controller is turned off, the current input circuit is cut off. If you connect two or more current-input type controllers in series, change the current input to voltage input by connecting a resistor (No. 81401325, sold separately).
- Prepare a heater current conductor to send a heater current through the current transformer.
Do not use a heater current that exceeds the specified permissible current as this may damage the controller.

- The controller requires about 6 seconds to start up once the power is turned ON. The controller can be used once it has started up. However, it is recommended to allow a warm-up time of at least 30 minutes to attain the specified accuracy.
- The current transformer input cannot be used for phase control.
- There is no isolation provided between control output 1 and control output 2. Install an isolator as required.
- Do not connect a terminating resistor to either end of the RS-485 communications line. Doing so may interfere with communication.
- Make sure that devices and equipment connected to this device have reinforced insulation suitable for the maximum operating voltage of this device's power supply and input/output ports.

● Connection of C15MT




● I/O isolation

Items surrounded by solid lines are insulated from other signals.
Availability of input or output is based on a model number.

Power supply	Internal Circuit	Control output 1 Control output 2
PV input Current Transformer input 1 Current Transformer input 2 Loader communication		Event output 1 Event output 2 Event output 3
Digital input 1 Digital input 2 RS-485 Communication		


Part names and functions



- (1) Upper display: Displays PV values (current temperature, etc.) or setup items.
- (2) Lower display: Displays SP values (set temperature, etc.) and other values of setup items.
- (3) Mode indicator rdy: Lights when READY (control stop)
man: Lights when MANUAL (manual mode)
ev1 to ev3: Lights when event relays are ON.
ot1 to ot2: Lights when the control output is ON.
- (4) Mode key: The operation which was set beforehand can be done by pressing the key for 1s or more. Factory setting is RUN / READY selection.
- (5) Para key: Switches the display.
- (6) <, v, ^ keys: Used for incrementing numeric values and performing arithmetic shift operations.
- (7) Loader connector: Connects to a personal computer with the special cable provided in the smart loader package.

Key Operation and Setting

The following shows the flow of the key operation. Various displays and



settings can be called up to the console:

● PV Input range setup

In the setup setting display mode [C01], press the [$\leftarrow$] • [$\vee$] • [$\wedge$] key to set the lower display to select a desired PV range type.
>> When no keys are pressed for 2 sec. or longer, the flashing of the numeric value is stopped to set the currently displayed value.

● SP setup

While the PV/SP is displayed in the operation display mode, press the [$\leftarrow$] • [$\vee$] • [$\wedge$] key to change the SP in the lower display.
>> When no keys are pressed for 2 sec. or longer, the flashing of the numeric value is stopped to set the currently displayed value.
SP can be set in the parameter setting display mode.

PV range table

C01 No.	Sensor type	Range[*C]	Range[*F]	C01 No.	Sensor type	Range[*C]	Range[*F]
1	K	-200 to +1200	-300 to +2200	41	Pt100	-200 to +500	-300 to +900
2	K	0 to 1200	0 to 2200	42	JPt100	-200 to +500	-300 to +900
3	K	0 to 800	0 to 1500	43	Pt100	-200 to +200	-300 to +400
4	K	0 to 600	0 to 1100	44	JPt100	-200 to +200	-300 to +400
5	K	0 to 400	0 to 700	45	Pt100	-100 to +300	-150 to +500
6	K	-200 to +400	-300 to +700	46	JPt100	-100 to +300	-150 to +500
9	J	0 to 800	0 to 1500	51	Pt100	-50.0 to +200.0	-50 to +400
10	J	0 to 600	0 to 1100	52	JPt100	-50.0 to +200.0	-50 to +400
11	J	-200 to +400	-300 to +700	53	Pt100	-50.0 to +100.0	-50 to +200
13	E	0 to 600	0 to 1100	54	JPt100	-50.0 to +100.0	-50 to +200
14	T	-200 to +400	-300 to +700	63	Pt100	0.0 to 200.0	0 to 400
15	R	0 to 1600	0 to 3000	64	JPt100	0.0 to 200.0	0 to 400
16	S	0 to 1600	0 to 3000	67	Pt100	0 to 500	0 to 900
17	B	0 to 1800	0 to 3300	68	JPt100	0 to 500	0 to 900
18	N	0 to 1300	0 to 2300				
19	PLII	0 to 1300	0 to 2300	C01 No.	Input type	Range	
20	WR5-26	0 to 1400	0 to 2400	84	0 to 1V	The scaling and decimal point position can be changed variably in a range of -1999 to +9999	
21	WR5-26	0 to 2300	0 to 4200	86	1 to 5V		
24	DIN U	-200 to +400	-300 to +700	87	0 to 5V		
25	DIN L	-100 to +800	-150 to +1500	88	0 to 10V		
				89	0 to 20mA		
				90	4 to 20mA		

! Handling Precautions

- The accuracy of the B thermocouple is $\pm 5\%$ FS for a range of 260°C or less, and $\pm 1\%$ FS for 260 to 800°C.
- The accuracy of the PLII thermocouple(C01 No.19) in the range of 0 to 32°F does not meet the indication accuracy specified in the Specifications.
- For ranges with a decimal point, tenths are displayed on the line underneath point.
- Make sure to set the correct number in setup display C01, according to the type and range of the sensor used. If the setting is wrong, problems such as large temperature errors in the output may occur.

Alarm code table

Alarm code	Error	Cause	Countermeasure
AL01	PV input error (over range)	Sensor line break, incorrect wiring, incorrect range code setting	Checking wiring or reset range code.
AL02	PV input error (under range)	Sensor line break, incorrect wiring, incorrect range code setting	
AL03	CJ failure	Terminal temperature compensation unit failure (thermocouple)	Checking the allowable ambient temperature.
	PV input error	Sensor line break, incorrect wiring (RTD)	Checking wiring.
AL11	CT input failure (over-range) (CT input 1 or 2, or both)	A current exceeding the upper limit of the display range was measured. The number of CT turns or the number of CT power wire loops is incorrectly set, or wiring is incorrect.	- Use a CT with the correct number of turns for the display range. - Reset the number of CT turns. - Reset the number of CT power wire loops. - Check the wiring.
AL70	A/D conversion error	Defective A/D converter	Replace unit.
AL95	Parameter error	- Power turned OFF during fixing of data - Data corrupted due to noise, etc.	Reset data or replace unit.
AL96	Adjustment data error	- Power turned OFF during fixing of data - Data corrupted due to noise, etc.	
AL97	Parameter error (RAM area)	Data corrupted due to noise, etc.	
AL98	Adjustment data error (RAM area)	Data corrupted due to noise, etc.	
AL99	ROM error	Data corrupted due to noise, etc.	Replace unit.

Maintenance

Cleaning: When wiping out the C15M, use the soft and dried cloth.

Parts replacement: Do not replace the parts.

Fuse replacement: When replacing the fuse for the power supply wires, make sure that the replacement fuse complies with all applicable safety standards.
Standard IEC127, Cutoff Speed Delayed operation type (T),
Rated Voltage 250V, Rated Current 200mA

Model selection table

Basic model No.	Mounting	Control output	PV input	Power supply	Optional functions	Language	Specifications	
C15M								
	T						Panel mount type	
							Control output 1	Control output 2
		R0					Relay output (NO)	None
		V0					Voltage pulse output (for SSR drive)	None
*1		C0					Current output	None
			T				Thermocouple input (K, J, E, T, R, S, B, N, PLII, WR5-26, DINU, DINL)	
							RTD input (Pt100/JPt 100)	
							DC voltage /DC current input (0 to 1Vdc, 1 to 5Vdc, 0 to 5Vdc, 0 to 10Vdc, 0 to 20mA, 4 to 20mA)	
						A	AC Model (100 to 240Vac)	
					01		Event relay output: 3 points	
					02		Event relay output: 3 points Current transformer input: 2 points Digital input: 2 points	
					03		Event relay output: 3 points Current transformer input: 2 points RS-485 communication	
						00	Chinese (Simplified)	
						01	Chinese (Traditional)	

*1. To be determined.

*2. If R is selected for PV input, 01 must be selected as the option. (Option 02 will be available soon.)

Specifications

● PV input

Thermocouple:

K,J,E,T,R,S,B,N (JIS C1602-1995)
PL II (Engelhard Industries Data (ITS90))
WR5-26 (ASTM E988-96(Reapproved 2002))
DIN U,DIN L (DIN 43710-1985)

Resistance temperature detector (RTD):

Pt100 (JIS C1604-1997)
JPt100 (JIS C1604-1989)
0 to 1V, 1 to 5V, 0 to 5V, 0 to 10V
0 to 20mA, 4 to 20mA
500ms
 $\pm 0.5\%$ FS ± 1 digit,
 $\pm 1\%$ FS ± 1 digit for a negative area of the thermocouple (at ambient temperature 23 $\pm 3^{\circ}$ C)
• -0.5 V to +12 V (thermocouple, RTD, DC, voltage)
• 30 mA max or 4 V max (DC current)
More than the allowable input voltage or current may damage this device.

Allowable input:

● Digital input

Input type : Dry contact or open collector
Allowable ON contact resistance : Max.250 Ω
Allowable OFF contact resistance : Min.100k Ω
Allowable ON voltage : Max.1.0V
Approx.7.5mA in case of short circuit
Approx.5.0mA in case of contact resistance 250 Ω
1s or more

Minimum hold time :

● Current transformer input

Number of input points: 2 points
Input object: Current transformer with 100 to 4,000 turns (availability is by 100-turn units)
Optional unit Model No.: QN206A (800 turns, hole diameter: 5.8 mm)
Optional unit Model No.: QN212A (800 turns, hole diameter: 12mm)

Current measurement lower limit:

0.4Aac (800 turns, 1 time)
Formula; Number of turns $\div$ (2000 x number of power wire loops)

Current measurement upper limit:

50.0Aac (800 turns, 1 time)
Formula; Number of turns $\div$ (16 x number of power wire loops)
70.0Aac (800 turns, 1 time)
Formula; Number of turns $\div$ (16 x number of power wire loops) x 1.4

Allowable measured current:

Display range lower limit: 0.0Aac
Display range upper limit: 70.0Aac (800 turns, 1 time)
Formula; Number of turns $\div$ (16 x number of power wire loops) x 1.4
Display accuracy: $\pm 5\%$ FS
Display resolution: 0.1Aac

● Control output

Relay output
Contact rating : NO side 250Vac/30Vdc, 3A (resistive load)
NC side 250Vac/30Vdc, 1A (resistive load)
NO side Min. 50,000 operations
NC side Min. 100,000 operations

Life :

Min. switching specifications : 5V, 100mA
Min. ON time / OFF time : 250ms

• Voltage pulse output (for SSR drive)

Open circuit voltage : 19Vdc $\pm 15\%$
Internal resistance : 82 $\Omega \pm 0.5\%$
Allowable current : Max. 24mAac
Min. OFF time / ON time : 1ms (Time proportional cycle time < 10s)
250ms (Time proportional cycle time ≥ 10 s)

• Current output

Output type : 0 to 20mAac or 4 to 20mAac current output
Allowable load resistance : Max.600 Ω
Output accuracy : $\pm 0.5\%$ FS (at ambient temperature 23 $\pm 3^{\circ}$ C)
 $\pm 1\%$ FS at 0 to 1mA

● Event relay outputs (ev1 to 3)

Contact rating : 250Vac/30Vdc 2A (resistive load)
Life : Min. 100,000 operations
Min. switching specification : 5V, 10mA (Reference value)

● RS-485 communication

Transmission line : 3-wire system
Transmission speed : 4800, 9600, 19200, 38400bps
Communication protocol : CPL and MODBUS conforming
Terminating resistor : Do not connect a terminating resistor.

● Environmental condition

Operating conditions
Ambient temperature : 0 to 50°C (Gang-mounting: 0 to 40°C)
Ambient humidity : 10 to 90%RH (Without condensation)
Power supply voltage : AC Model
85 to 264Vac, 50/60Hz ± 2 Hz
(Rated power voltage 100 to 240Vac 50/60Hz)

• Transport conditions

Ambient temperature : -20 to +70°C
Ambient humidity : 10 to 95%RH (Without condensation)

● Other specifications

Degrees of protection :

Case front side IP66 /NEMA 4 equivalent
(Only for stand-alone mounting on a panel when an attached gasket is used.)

Power consumption :

AC Model
Max. 12VA (100Vac:8VA, 264Vac:12VA)
(6VA for 100Vac and 9VA for 264Vac to our company SDC10 equivalent function)
Max. 20ms (AC model)

Non-detected power failure time :

Altitude : Max. 2000m
Mass : Approx.150g (with mounting bracket) at panel mount type

Terminal screw tightening torque :

0.4 to 0.6N·m

Applicable standards :

EN61010-1, EN61326-1

Over-voltage category :

Category II (IEC60364-4-443, IEC60664-1)

Allowable pollution degree :

Pollution degree 2

Recommended cables:

For thermocouples:
Connect thermocouple wires to the terminals directly. When a thermocouple is connected to terminal block, or wiring distance is long, connect the wire via a shielded compensating lead wire.
For input/output other than thermocouples:
Use a JCS 4364 instrument cable or equivalent. If electromagnetic induction noise is comparatively low, a shielded multiconductor microphone cord (MVVS) may be used.

Accessories and optional parts

Name	Model No.
Mounting bracket (for C15MT)	81446403-001 (Accessory)
Gasket (for C15MT)	81409657-001 (Accessory)
Current transformer	QN206A (5.8mm hole dia.) QN212A (12mm hole dia.)
Hard cover	81446442-001
Soft cover	81446443-001
Terminal cover	81446898-001

■ Event assignment bank

Bank selection: $E\upsilon CF$

Display	Item	Contents	Initial value	User level
$E\text{t}\text{t}$ to $E\text{S}\text{t}$	Operation type of internal event 1 to 5 configuration 1	0: No event 1: PV high limit 2: PV low limit 3: PV high/low limit 4: Deviation high limit 5: Deviation low limit 6: Deviation high/low limit 7: Deviation high limit (Final SP reference) 8: Deviation low limit (Final SP reference) 9: Deviation high/low limit (Final SP reference) 10: SP high limit 11: SP low limit 12: SP high/low limit 13: MV high limit 14: MV low limit 15: MV high/low limit 16: CT1 heater burnout/over-current 17: CT1 heater short-circuit 18: CT2 heater burnout/over-current 19: CT2 heater short-circuit 20: Loop diagnosis 1 21: Loop diagnosis 2 22: Loop diagnosis 3 23: Alarm (status) 24: READY (status) 25: MANUAL (status) 26: Invalid 27: During AT execution (status) 28: During SP ramp (status) 29: Control direct action (status) 30: ST execution (status) 31: Invalid 32: Timer (status)	0	0
$E\text{t}\text{t}$ to $E\text{S}\text{t}$	Internal event 1 to 5 Configuration 2	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.	0000	0
	1st digit: Direct/Reverse	0: Direct 1: Reverse	0	
	2nd digit: Stand-by	0: None 1: Standby 2: Standby + Standby at SP change	0	
	3rd digit: EVENT state at READY	0: Continue 1: Forced OFF	0	
	4th digit: Undefined	0	0	
$E\text{t}\text{t}$ to $E\text{S}\text{t}$	Internal event 1 to 5 Configuration 3	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.	0000	2
	1st digit: Alarm OR	0: No event 1: Alarm direct + OR operation 2: Alarm direct + AND operation 3: Alarm reverse + OR operation 4: Alarm reverse + AND operation	0	
	2nd digit: Special OFF	0: As normal execution 1: Event OFF at the event setting value (main)=0	0	
	3rd digit: Delay time unit	0: 0.1s 1: 1s 2: 1min	0	
	4th digit: Undefined	0	0	

■ DI assignment bank

Bank selection: d

Display	Item	Contents	Initial value	User level
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Operation type	0: No function 1: LSP group selection (0/+1) 2: LSP group selection (0/+2) 3: LSP group selection (0/+4) 4: Invalid 5: Invalid 6: Invalid 7: RUN/READY selection 8: AUTO/MANUAL selection 9: Invalid 10: AT Stop/Start 11: ST Disabled/Enabled 12: Control action direct/reverse selection (As per setting/opposite operation of setting) 13: SP ramp Enabled/Disabled 14: PV hold (No-hold/Hold) 15: PV maximum value hold (No-hold/Hold) 16: PV minimum value hold (No-hold/Hold) 17: Timer Stop/Start 18: Release of all DO latches (Continue/Release) 19: Invalid 20: Invalid	0	0
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Input bit operation	0: Disabled. (Input of default) 1: Function 1 ((A and B) or (C and D)) 2: Function 2 ((A or B) and (C or D)) 3: Function 3 (A or B or C or D) 4: Function 4 (A and B and C and D)	0	2

Display	Item	Contents	Initial value	User level
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Input assignment A	0: Normally open (OFF, 0) 1: Normally close (ON, 1) 2: DI1 3: DI2 4 to 9: Undefined 10: Internal event 1 11: Internal event 2 12: Internal event 3 13: Internal event 4 14: Internal event 5 15 to 17: Undefined 18: Communication DI1 19: Communication DI2 20: Communication DI3 21: Communication DI4 22: MANUAL mode 23: READY mode 24: Undefined 25: During AT execution 26: During SP ramp 27: Undefined	2 to 4	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Input assignment B	12: Internal event 3 13: Internal event 4 14: Internal event 5 15 to 17: Undefined 18: Communication DI1 19: Communication DI2 20: Communication DI3 21: Communication DI4 22: MANUAL mode 23: READY mode 24: Undefined 25: During AT execution 26: During SP ramp 27: Undefined	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Input assignment C	28: Alarm is enabled. 29: PV alarm is enabled. 30: Undefined 31: Mode key function selection status 32: Event output 1 status 33: Control output 1 status	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Input assignment D	28: Alarm is enabled. 29: PV alarm is enabled. 30: Undefined 31: Mode key function selection status 32: Event output 1 status 33: Control output 1 status	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Polarity A to D	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.	0000	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	1st digit: Polarity A (Polarity of input assignment A)	0: Direct 1: Reverse	0	
	2nd digit: Polarity B (Polarity of input assignment B)		0	
	3rd digit: Polarity C (Polarity of input assignment C)		0	
	4th digit: Polarity D (Polarity of input assignment D)		0	
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Polarity	0: Direct 1: Reverse	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$	Internal contact 1 to 3 Internal event No.assignment	0: Every internal event 1 to 5: Internal event numbers	0	2

■ DO assignment bank

Bank selection: d

Display	Item	Contents	Initial value	User level
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 operation type	0: Input of default 1: MV1 (ON/OFF control output, time proportional output, heat-side proportional output of heat/cool control) 2: MV2 (cool-side proportional output of heat/cool control) 3: Function 1 ((A and B) or (C and D)) 4: Function 2 ((A or B) and (C or D)) 5: Function 3 (A or B or C or D) 6: Function 4 (A and B and C and D)	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 output assignment A	0: Normally open (OFF, 0) 1: Normally close (ON, 1) 2: Internal event 1 3: Internal event 2 4: Internal event 3 5: Internal event 4 6: Internal event 5 7 to 13: Undefined 14: MV1 15: MV2 16 to 17: Undefined 18: DI1 19: DI2 20 to 25: Undefined 26: Internal contact 1 27: Internal contact 2 28: Internal contact 3 29 to 33: Undefined	14 to 15 or 2 to 4	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 output assignment B	34: Communication DI1 35: Communication DI2 36: Communication DI3 37: Communication DI4 38: MANUAL mode 39: READY mode 40: Invalid 41: During AT execution 42: During SP ramp 43: Undefined 44: Alarm is enabled. 45: PV alarm is enabled. 46: Undefined 47: mode key function selection status 48: Event output 1 status 49: Control output 1 status	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 output assignment C			
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 output assignment D			

Display	Item	Contents	Initial value	User level
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 2 Polarity A to D	Digits are called as 1st digit, 2nd digit, 3rd digit and 4th digit from the right end digit.	0000	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	1st digit: Polarity A	0: Direct	0	
	2nd digit: Polarity B	1: Reverse	0	
	3rd digit: Polarity C		0	
	4th digit: Polarity D		0	
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 Polarity	0: Direct 1: Reverse	0	2
$d\text{t}\text{t}$ to $d\text{t}\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$ $E\upsilon\text{t}$ to $E\upsilon\text{t}$	Control output 1 to 2, event output 1 to 3 Latch	0: Disabled 1: Enabled (Latch at ON) 2: Enabled (Latch at OFF, except at the time of initialization - after power ON)	0	2

■ User function bank

Bank selection: UF

Display	Item	Contents	Initial value	User level
$UF\text{-}1$	User function definition 1	This is the display in upper display. The setup exception is as follows:	----	1
$UF\text{-}2$	User function definition 2	----- : Yet to be registered.	----	1
$UF\text{-}3$	User function definition 3	$P\text{-}$: Proportional band of the PID group in use $I\text{-}$: Integration time of the PID group in use $d\text{-}$: Derivative time of the PID group in use $r\text{-}E\text{-}$: Manual reset of the PID group in use	----	1
$UF\text{-}4$	User function definition 4	$\phi L\text{-}$: MV low limit of the PID group in use $\phi H\text{-}$: MV high limit of the PID group in use	----	1
$UF\text{-}5$	User function definition 5	$P\text{-}$: Cool-side proportional band of the PID group in use $I\text{-}$: Cool-side integration time of the PID group in use	----	1
$UF\text{-}6$	User function definition 6	$d\text{-}$: Cool-side derivative time of the PID group in use	----	1
$UF\text{-}7$	User function definition 7	$\phi L\text{-}$: Cool-side MV low limit of the PID group in use	----	1
$UF\text{-}8$	User function definition 8	$\phi H\text{-}$: Cool-side of MV high limit of the PID group in use	----	1

■ Lock bank

Bank selection: LoC


Display	Item	Contents	Initial value	User level
LoC	Key lock	0: All settings are enabled. 1: Mode, event, operation display, SP, UF, lock, manual MV, and mode key can be set. 2: Operation display, SP, UF, lock, manual MV, and mode key can be set. 3: UF, lock, manual MV, and mode key can be set.	0	0
C, LoC	Communication lock	0: RS-485 communication read/write is enabled. 1: RS-485 communication read/write is disabled.	0	2
L, LoC	Loader lock	0: Loader communication read/write is enabled. 1: Loader communication read/write is disabled.	0	2
$PRSS$	Password display	0 to 15 5: Password 1A to 2B display	0	0
$PS\text{1}R$	Password 1A	0000 to FFFF (hexadecimal value)	0000	0
$PS\text{2}R$	Password 2A	0000 to FFFF (hexadecimal value)	0000	0
$PS\text{1}b$	Password 1B	0000 to FFFF (hexadecimal value)	0000	0
$PS\text{2}b$	Password 2B	0000 to FFFF (hexadecimal value)	0000	0

■ Instrument information bank

Bank selection: Id

Display	Item	Contents	Initial value	User level
$Id\text{0}1$	ROM ID	0: fixed	-	2
$Id\text{0}2$	ROM version 1	XX.XX (2 digits after decimal point)	-	2
$Id\text{0}3$	ROM version 2	XX.XX (2 digits after decimal point)	-	2
$Id\text{0}4$	SLP support Information		-	2
$Id\text{0}5$	EST support version		-	2
$Id\text{0}6$	Manufacturing date code (year)	Year - 2000 Ex.: "3" means the year 2003.	-	2
$Id\text{0}7$	Manufacturing date code (month, day)	Month + Day ÷ 100 Ex.: "12.01" means the 1st day of December	-	2
$Id\text{0}8$	Serial No.		-	2

CP-UM-5410ET-1



azbil

Specifications are subject to change without notice. (09)

Azbil Corporation
Advanced Automation Company

1-12-2 Kawana, Fujisawa
Kanagawa 251-8522 Japan

URL: <http://www.azbil.com>

1st Edition: Jan. 2013 (F)
2nd Edition: July 2013 (M)

數位顯示調節器 C15M 使用說明書 設定篇

感謝您購買阿自倍爾株式會社產品。為能正確、安全地使用本產品，請務必詳閱本使用說明書，於使用前先行瞭解本書內容。
請將本說明書放置於容易取得之處。

在訂購與使用產品前，請務必閱讀「產品訂購注意事項」。
<http://www.azbil.com/cn/products/order.html>

中文版與英文版的內容若有差異，以英文版為準。

要求

請務必將本使用說明書交付至產品使用者手中。
嚴禁擅自複印和轉載本使用說明書的全部或部分內容。
內容若有變更，恕不另行通知。
本使用說明書內容於發行前已經仔細審查與校對，若有任何錯誤或遺漏之處，請告知本公司。
客戶端用於應用上的任何後果，本公司恕不擔負任何責任，敬請見諒。
© 2013 Azbil Corporation All Rights Reserved.

本書旨在針對使用注意事項以及安裝、配線、PV 量程種類、參數一覽及主要規格等進行說明。

請確認

您購買的 C15MT 含有以下物品。
安裝配件 81446403-001 1 個
密封墊 81409657-001 1 個
使用說明書（本書） CP-UM-5410ET 1 本

安全注意事項

- **警告** 錯誤使用時，可能具有致使使用者嚴重傷害甚或死亡的危險。
- **注意** 錯誤使用時，可能具有致使使用者受傷或物品受損的危險。

警告

- **!** 本機的接線錯誤會造成故障或產生危險災害。供電至本機前，請務必確認接線是否正確。
- **!** 本機於配線或安裝、拆卸時，請務必在切斷電源的情況下進行。否則可能造成電擊、故障等情形。
- **⊘** 請勿觸摸電源端子等導電部分。否則可能造成電擊。
- **⊘** 請勿拆解本機。否則可能造成電擊、故障等情形。

注意

- **!** 請在規範的使用條件（溫度、濕度、電壓、振動、衝擊、安裝方向、環境等）範圍內使用本機。否則可能引起火災、造成故障。
- **⊘** 請勿遮蓋本機的通風口。否則可能會引起火災或造成故障。
- **!** 請依照規定的標準、指定的電源及施工方法進行正確配線。否則可能造成火災、電擊、故障等情形。
- **!** 避免線頭、切削碎屑、水等物品進入本機內部。否則可能造成火災、故障等情形。
- **!** 請依端子螺絲規格中記載的扭矩確實鎖緊螺絲。若未確實鎖緊，則可能造成電擊或引發火災。
- **⊘** 請勿將本機未使用端子作為中繼端子使用。否則可能造成電擊、火災、故障等情形。
- **!** 本機接線後建議蓋上端子蓋。否則可能造成電擊。（本機端子蓋為選購配備）
- **!** 請依規格內所述工作期限使用本機的繼電器。若超限使用則可能造成電擊、故障等情形。
- **!** 若工作環境可能發生雷擊突波情形，請使用本公司生產的突波吸收器。否則可能會引起火災、造成故障。
- **⊘** 請勿使用尖銳的物品（鉛筆尖或針等）操作按鍵。否則會造成故障。


設置

- 安裝場所**
請將本機設置於以下場所。
 - 除供應電源及繼電器接點輸出外，輸入輸出模組的共模電壓：對地電壓為 30Vr.m.s. 以下，峰值 42.4 以下，60VDC 以下。
 - 無高溫、低溫、高濕度、低濕度的場所。
 - 無硫化物等腐蝕性氣體及矽氣體的場所。
 - 低粉塵、低油霧的場所。
 - 無直射陽光及不受天候干擾的場所。
 - 機械振動、衝擊低的場所。
 - 附近無高壓線、焊接機及電氣干擾源的場所。
 - 遠離如鍋爐等具有高壓點火裝置的設備 15m 以上的場所。
 - 受電磁干擾少的場所
 - 無可燃性液體或蒸氣的場所

- 安裝方法**
 - 安裝角度自水平位置起算後仰 10 度以內、前傾 10 度以內。
 - 若為儀表盤安裝型 (C15MT)，請使用厚度 9mm 以下的鋼板。

- 外形尺寸**
 - C15MT（盤面安裝型）


（單位：mm）



- ⚠ 使用注意事項**
鎖緊安裝配件隨附的螺絲，直到安裝配件無法移動後再將螺絲鎖緊 1 圈，確實固定於儀表盤上。
請勿過度鎖緊螺絲，以免機箱變形。

- 盤面開孔圖**
單台安裝 密集安裝

（單位：mm）




- ⚠ 使用注意事項**
 - 3 台以上採用橫向密集安裝時，環境溫度不可超過 40℃。
 - 需要防水、防塵的場合，請採用單台安裝。
 - 已採用密集安裝的場合，無法保證其防水、防塵性能。
 - 上下方向保持 50mm 以上的間隔。

接線

進行儀表電源配線時，請將本產品的主電源切斷開關設置在操作員手能觸及的範圍內。
另外，進行 AC 電源型的儀表電源配線時，請配上延遲型 (T) 額定電流 0.2A、額定電壓 250V 的保險絲。(IEC127)
儀表側面各端子上配置標示的涵義如下表所示。


符 號	內 容
~	交流
	注意，雷擊危險
	注意

- ⚠ 使用注意事項**
 - 請在確認貼在本機側面的儀表型號與端子編號後進行接線。接線完畢後，請務必確認接線無誤。
 - 輸入輸出信號線遠離動力線或電源線50cm以上，而且不能在同一配線管或線槽內。
 - 請注意壓接端子等不能與相鄰的端子接觸。
 - 1個端子螺絲連接多個壓接端子的場合，請事先把壓接端子弯曲處理並連接不超過2個壓接端子。
 - 1~6, 13~18號端子的配線請從端子台側看的左方向進行配線。
 - 端子連接時请使用適合M3螺絲的下述尺寸的端子。



- 儀表電源為OFF時,電流輸入回路被斷開。當計裝設計需數台儀錶的電流輸入串聯時,請配上另售的電阻(81401325),取其電壓作為電壓量程使用。
- 請把流過加熱電流的導線貫通在電流互感器中。同時，請勿在超過規格中規定的容許電流的情況下使用。否則會損壞本機。
- 本機在電源投入後進入穩定狀態前，最長6s內不動作。其後進入運行狀態，但為了保證規定的精度，請預熱30分鐘以上。
- 電流互感器輸入不能用于位相控制。
- 控制輸出1與控制輸出2之間未隔離。請根據需要進行隔離。
- RS-485的通信路的兩端上請勿連接終端電阻。否則不能通訊。
- 與本機連接的機器或裝置，需採取與本機的電源、輸入輸出部的最高使用電壓適合的強化絕緣措施後，才能使用。


- C15MT 的接線**



- 輸入輸出間隔離**
實線用於表示框內信號與其他信號隔離。
有無輸入輸出依型號而定。

電源	內部回路	控制輸出1 控制輸出2
PV輸入		
CT輸入1		
CT輸入2		事件輸出1 事件輸出2 事件輸出3
編程器通訊		
數位輸入1		
數位輸入2		
RS-485通訊		


各部件名稱與功能



- ① 第 1 顯示部：顯示 PV 值（現在溫度等）或設定項目。
- ② 第 2 顯示部：顯示 SP 值（設定溫度值等）或各設定項目的設定值。
- ③ 模式指示燈 rdy：READY 模式（控制停止）時燈亮
man：MANUAL 模式（手動）時燈亮
ev1~ev3：事件繼電器輸出 ON 時燈亮
ot1~ot2：控制輸出為 ON 時燈亮
- ④ [mode] 鍵：按住按鍵 1 秒以上，即可進行預先設定的操作。
出廠時設定為 RUN/READY 切換。
- ⑤ [para] 鍵：顯示切換。
- ⑥ <、V、^ 鍵：數值增減、位數變更時使用。
- ⑦ 編程器插口：使用智慧型程式規劃器套裝軟體隨附的專用纜線連接至電腦。

按鍵操作和設定

下圖為按鍵操作的流程。各項顯示或設定均可自面板上調出。



- PV 輸入量程的設定
設定顯示「C 01」下按 [<]、[V]、[^] 鍵，在第 2 顯示部上設定需要的 PV 量程種類。
不需按鍵，2 秒後將停止閃爍並完成 PV 量程種類的設定。
- SP 的設定
在運作顯示的 PV/SP 顯示中按 [<]、[V]、[^] 鍵，變更第 2 顯示部的 SP。
不需按鍵，2 秒後將停止數值閃爍並確定設定值。
SP 在參數設定顯示下亦可設定。

PV 量程表

C01編號	感測器類型	量程
1	K	-200~+1200℃
2	K	0~1200℃
3	K	0~800℃
4	K	0~600℃
5	K	0~400℃
6	K	-200~+400℃
9	J	0~800℃
10	J	0~600℃
11	J	-200~+400℃
13	E	0~600℃
14	T	-200~+400℃
15	R	0~1600℃
16	S	0~1600℃
17	B	0~1800℃
18	N	0~1300℃
19	PLII	0~1300℃
20	WRe5-26	0~1400℃
21	WRe5-26	0~2300℃
24	DIN U	-200~+400℃
25	DIN L	-100~+800℃

C01編號	感測器類型	量程
41	Pt100	-200~+500℃
42	JPt100	-200~+500℃
43	Pt100	-200~+200℃
44	JPt100	-200~+200℃
45	Pt100	-100~+300℃
46	JPt100	-100~+300℃
51	Pt100	-50.0~+200.0℃
52	JPt100	-50.0~+200.0℃
53	Pt100	-50.0~+100.0℃
54	JPt100	-50.0~+100.0℃
63	Pt100	0.0~200.0℃
64	JPt100	0.0~200.0℃
67	Pt100	0~500℃
68	JPt100	0~500℃

C01編號	輸入類型	量程
84	0~1V	-1999~+9999的 量程範圍，小數點 位置可變
86	1~5V	
87	0~5V	
88	0~10V	
89	0~20mA	
90	4~20mA	

- ❗ 使用注意事項
- B 型熱電偶的精度為 260℃ 以下 $\pm 5\%$ FS、260~800℃ $\pm 1\%$ FS。
 - 在 0~32 ℃ 的量程範圍內，PL II 熱電偶 (C01 No. 19) 的指示精度不能滿足本規格書的規定。
 - 帶小數點顯示的量程，顯示小數點以下一位數。
 - 依據使用感測器的類型與量程，設定資料 C01 的編號。請用設置數據 設定正確的感覺器的類型與量程的編號，否則會引起大的溫度誤差而導致異常輸出。

警報代碼一覽表

警報代碼	異常名稱	原 因	處 理
AL01	PV輸入異常 (超出量程)	感測器斷線、配線錯誤 PV量程種類設定錯誤	確認配線 再次設定PV量程種類
AL02	PV輸入異常 (量程不足)	感測器斷線、配線錯誤 PV量程種類設定錯誤	
AL03	CJ異常	端子溫度補償部故障 (熱電偶)	確認環境溫度
	PV輸入異常	感測器斷線、配線錯誤 (熱敏電阻)	確認配線
AL11	CT輸入異常 (超出量程)	超過顯示範圍上限的電流測量、CT匝數設定錯誤、CT電力線貫通次數的設定錯誤 配線錯誤	使用匝數與顯示範圍符合的CT、重新設定匝數、重新設定 CT 電力線貫通次數、確認配線
AL70	A/D轉換異常	A/D轉換部故障	更換本體
AL95	參數異常	資料確認期間斷電 資料因受干擾而毀損	● 重新供電 ● 重新設定資料 (AL95/97為設定資料，AL96/98為調整資料) ● 更換本體
AL96	調整資料異常	資料確認期間斷電 資料因受干擾而毀損	
AL97	參數異常 (RAM區域)	資料因受干擾而毀損	
AL98	調整資料異常 (RAM區域)	資料因受干擾而毀損	
AL99	ROM異常	ROM (記憶體) 故障	● 重新供電 ● 更換本體

維 護

- 清潔：清除儀表汙物時，請使用柔軟乾布擦拭。
- 零件更換：請勿更換零件。
- 保險絲更換：更換 AC 電源型的電源保險絲時，務必使用指定規格的产品。
規格 IEC127、切斷速度延遲型 (T)、額定電壓 250V、
額定電流 200mA。

型號構成表

基本型號	安 裝	控制輸出	PV輸入	電 源	選 項	言語	規 格	
C15M								
	T						盤面安裝型	
							控制輸出1(ot1)	控制輸出2(ot2)
		R0					繼電器輸出(NO)	繼電器輸出(NC)
		V0					電壓脈衝輸出 (SSR驅動用)	無
※1		C0					電流輸出	無
			T				熱電偶輸入 (K, J, E, T, R, S, B, N, PLII, Wre5-26, DINU, DINL)	
			R			※2	熱敏電阻輸入 (Pt100/JPt100)	
			L			※1	直流電壓 / 電流輸入 (DC0~1Vdc, DC1~5Vdc, DC0~5Vdc, DC0~10Vdc, DC0~20mA, DC4~20mA)	
				A			AC電源 (100~240Vac)	
					01		事件繼電器輸出3點	
					02		事件繼電器輸出3點 變流器輸入2點	
					03		數位輸入2點 事件繼電器輸出3點 變流器輸入2點	
						※1	RS-485通訊	
						00	中文 (簡体字)	
						01	中文 (繁体字)	

- ※1 未定
- ※2 PV 輸入：R 僅可購買選購品 01 (選購品 02 即將販售)

規 格

- PV 輸入
熱電偶：K、J、E、T、R、S、B、N (JIS C 1602-1995)
PL II (Engelhard Industries 資料 (ITS90))
WRe5-26 (ASTM E988-96 (Reapproved 2002))
DIN U、DIN L (DIN 43710-1985)
熱敏電阻：Pt100 (JIS C 1604-1997)
JPt100 (JIS C 1604-1989)
直流電壓：0~1V、1~5V、0~5V、0~10V
直流電流：0~20mA、4~20mA
取樣週期：500ms
顯示精度： $\pm 0.5\%$ FS ± 1 digit
熱電偶的負區域是 $\pm 1\%$ FS ± 1 digit
(環境溫度 23 $\pm 3^\circ\text{C}$)
容許輸入：-0.5V~+12V (熱電偶、熱電阻、直流電壓)
30mA 以下或 4V 以下 (直流電流)
如果輸入容許輸入值以上的電壓或電流，有可能損壞儀表
- 數位輸入
輸入形式：無電壓接點或開路集極
容許 ON 接點電阻：250 Ω 以下
容許 OFF 接點電阻：100k Ω 以上
容許 ON 殘留電壓：1.0V 以下
ON 時端子電流：約 7.5mA (短路時)
約 5.0mA (接點電阻 250 Ω 時)
- 最小保持時間
- 變流器輸入
點數：2 點
輸入對象：變流器卷數 100~4000 匝 (以 100 匝為對應單位)
另售品型號：QN206A (800 匝，孔徑 5.8mm)
另售品型號：QN212A (800 匝，孔徑 12mm)
測量電流下限：0.4Aac (800 匝，在電力線貫通次數為 1 時)
計算式：匝數 $\div$ (2000 $\times$ 電力線貫通次數)
測量電流上限：50.0Aac (800 匝，在電力線貫通次數為 1 時)
計算式：匝數 $\div$ (16 $\times$ 電力線貫通次數)
容許測量電流：70.0Aac 以下 (800 匝、在電力線貫通次數為 1 時)
計算式：匝數 $\div$ (16 $\times$ 電力線貫通次數) $\times 1.4$
顯示範圍下限：0.0Aac
顯示範圍上限：70.0Aac (800 匝，在電力線貫通次數為 1 時)
計算式：匝數 $\div$ (16 $\times$ 電力線貫通次數) $\times 1.4$
顯示精度： $\pm 5\%$ FS
顯示解析度：0.1Aac

- 控制輸出
● 繼電器輸出
接點額定值：控制輸出 NO 側 250Vac/30Vdc、3A (電阻負荷)
控制輸出 NC 側 250Vac/30Vdc、1A (電阻負荷)
壽命：NO 側 5 萬次以上、NC 側 10 萬次以上
最小斷開閉合規格：5V、100mA
最小開時間 / 閉時間：250ms
● 電壓脈衝輸出 (SSR 驅動用)
開路時電壓：19Vdc $\pm 15\%$
內部電阻：82 $\Omega \pm 0.5\%$
容許電流：24mAac 以下
最小 OFF 時間 / ON 時間：時間比例週期小於 10 秒時 1ms
時間比例週期大於 10 秒時 250ms
- 電流輸出
輸出形式：0~20mAac 或 4~20mAac 電流輸出
容許負載電阻：600 Ω 以下
輸出精度： $\pm 0.5\%$ FS (環境溫度 23 $\pm 3^\circ\text{C}$ 時)
但 0~1mA 時為 $\pm 1\%$ FS
- 事件繼電器輸出 (ev1~3)
接點額定值：250Vac/30Vdc 2A (電阻負載)
壽命：10 萬次以上
最小斷開 / 閉合規格：5V、10mA (參考值)
- RS-485 通訊
傳送線路：3 線式
傳送速度：4800、9600、19200、38400bps
通訊協定：採用 CPL、MODBUS 標準
終端電阻：禁止連接
- 環境條件
● 動作條件
環境溫度：0~50℃ (密集安裝時為 0~40℃)
環境濕度：10~90% RH (無凝結水)
電源電壓：AC 電源型 85~264Vac、50/60Hz ± 2 Hz
(額定值：100~240Vac 50/60Hz)
- 運輸條件
環境溫度：-20~+70℃
環境濕度：10~95% RH (無凝結水)
- 其他規格
保護等級：機器面板 IP66/NEMA 4 基準
(使用附屬的墊片時，僅限於盤面單一安裝)
消耗功率：AC 電源型
12VA 以下 (100Vac 時 8VA、264Vac 時 12VA)
(與本公司 SDC10 相當功能的場合，100Vac 時 6VA、264Vac 時 9VA)
斷電停歇時間：AC 電源型 20ms 以下
高 度：2000m 以下
質 量：盤面安裝型 約 150g (含專用安裝件)
端子螺絲鎖緊扭矩：0.4~0.6N $\cdot$ m
適用規格：EN61010-1、EN61326-1
過電壓類別：Category II (IEC60364-4-443、IEC60664-1)
容許污染度：Pollution degree 2
使用電纜：熱電偶輸入
請直接將熱電偶引線連接至端子上。
配線距離長或熱電偶為端子連接時，請於使用補償導線延長後再與端子連接。
其他的輸入輸出
請使用與 JCS-4364 弱電儀表用電纜相同的產品。電磁干擾較小處，可使用含屏蔽線的多芯微音器電纜 (MVVS)。

附屬品、選項零件一覽表

名 稱	型 號
安裝件 (C15MT用)	81446403-001 (附屬品)
密封墊 (C15MT用)	81409657-001 (附屬品)
變流器	QN206A (孔徑 5.8mm)
	QN212A (孔徑 12mm)
硬蓋	81446442-001
軟蓋	81446443-001
端子蓋	81446898-001

■ 事件組態庫

庫選擇： *EvCF*

顯示	項目	內 容	初始值	顯示級別
<i>Et.C1</i> ~ <i>Es.C1</i>	內部事件 1~5 組態 1 動作種類	0：無事件 1：PV 上限 2：PV 下限 3：PV 上下限 4：偏差上限 5：偏差下限 6：偏差上下限 7：偏差上限（最終 SP 基準） 8：偏差下限（最終 SP 基準） 9：偏差上下限（最終 SP 基準） 10：SP 上限 11：SP 下限 12：SP 上下限 13：MV 上限 14：MV 下限 15：MV 上下限 16：CT1 加熱器斷線 / 過電流 17：CT1 加熱器短路 18：CT2 加熱器斷線 / 過電流 19：CT2 加熱器短路 20：回路診斷 1 21：回路診斷 2 22：回路診斷 3 23：警報（狀態） 24：READY（狀態） 25：MANUAL（狀態） 26：無效 27：AT 啟動中（狀態） 28：SP 斜坡中（狀態） 29：控制正動作（狀態） 30：ST 啟動中（狀態） 31：無效 32：計時器（狀態） 33：MFB（馬達回饋）值上下限（本機無效）	0	0
<i>Et.C2</i> ~ <i>Es.C2</i>	內部事件 1~5 組態 2 第 1 位：正逆 第 2 位：待機 第 3 位：READY 時動作 第 4 位：未定義	從右側開始 1、2、3、4 位 0：正 1：逆 0：無 1：待機 2：待機＋ SP 變更時待機 0：繼續 1：強制 OFF 0	0000 0 0 0	0
<i>Et.C3</i> ~ <i>Es.C3</i>	內部事件 1~5 組態 3 第 1 位：警報 OR 第 2 位：特殊 OFF 第 3 位：延時時間單位 第 4 位：未定義	從右側開始 1、2、3、4 位 0：無 1：警報正＋ OR 動作 2：警報正＋ AND 動作 3：警報逆＋ OR 動作 4：警報逆＋ AND 動作 0：一般 1：事件設定值（主）＝ 0 時、事件 OFF 0：0.1s 1：1s 2：1min 0	0000 0 0 0	2

■ DI 分配庫

庫選擇： *di*

顯示	項目	內 容	初始值	顯示級別
<i>di1.1</i> ~ <i>di3.1</i>	內部接點 1~3 動作種類	0：無功能 1：LSP 組選擇 (0/＋1) 2：LSP 組選擇 (0/＋2) 3：LSP 組選擇 (0/＋4) 4：無效 5：無效 6：無效 7：RUN/READY 切換 8：AUTO/MANUAL 切換 9：無效 10：AT 停止 / 啟動 11：ST 禁止 / 啟動 12：控制動作正逆切換 （與設定一致 / 與設定相反） 13：SP 斜坡許可 / 禁止 14：PV 值保持（不保持 / 保持） 15：PV 最大值保持（不保持 / 保持） 16：PV 最小值保持（不保持 / 保持） 17：計時器停止 / 啟動 18：全 DO 鎖定解除（繼續 / 解除） 19：無效 20：無效	0	0
<i>Et.C2</i> ~ <i>Es.C2</i>	內部接點 1~3 輸入位運算	0：不使用（預設輸入） 1：運算 1（A and B）or（C and D） 2：運算 2（A or B）and（C or D） 3：運算 3（A or B or C or D） 4：運算 4（A and B and C and D）	0	2

顯示	項目	內 容	初始值	顯示級別
<i>di1.3</i> ~ <i>di3.3</i>	內部接點 1~3 輸入分配 A	0：常閉 (OFF、0) 1：常閉 (ON、1) 2：DI1 3：DI2 4~9：未定義 10：內部事件 1 11：內部事件 2 12：內部事件 3 13：內部事件 4 14：內部事件 5 15~17：未定義 18：通訊 DI1 19：通訊 DI2 20：通訊 DI3 21：通訊 DI4 22：MANUAL 模式 23：READY 模式 24：未定義 25：AT 啟動中 26：SP 斜坡中 27：未定義 28：有警報 29：有 PV 警報 30：未定義 31：mode 鍵按鍵狀態 32：事件輸出 1 端子狀態 33：控制輸出 1 端子狀態	2~4	2
<i>di1.4</i> ~ <i>di3.4</i>	內部接點 1~3 輸入分配 B	0：不反轉 1：反轉	0	2
<i>di1.5</i> ~ <i>di3.5</i>	內部接點 1~3 輸入分配 C	0：不反轉 1：反轉	0	2
<i>di1.6</i> ~ <i>di3.6</i>	內部接點 1~3 輸入分配 D	0：不反轉 1：反轉	0	2
<i>di1.7</i> ~ <i>di3.7</i>	內部接點 1~3 反轉 A~D 第 1 位：反轉 A （輸入分配 A 反轉） 第 2 位：反轉 B （輸入分配 B 反轉） 第 3 位：反轉 C （輸入分配 C 反轉） 第 4 位：反轉 D （輸入分配 D 反轉）	從右側開始 1、2、3、4 位 0：不反轉 1：反轉	0000 0 0 0	2
<i>di1.8</i> ~ <i>di3.8</i>	內部接點 1~3 反轉	0：不反轉 1：反轉	0	2
<i>di1.9</i> ~ <i>di3.9</i>	內部接點 1~3 內部事件編號指定	0：所有的內部事件 1~5：內部事件編號	0	2

■ DO 分配庫

庫選擇： *do*

顯示	項目	內 容	初始值	顯示級別
<i>do1.1</i> ~ <i>do3.1</i>	控制輸出 1~2、 事件輸出 1~3 動作種類	0：預設輸出 1：MV1 (ON/OFF 控制輸出、時間比例輸出、加熱冷卻控制的加熱側時間比例輸出) 2：MV2 (加熱冷卻控制的冷卻側時間比例輸出) 3：運算 1 ((A and B) or (C and D)) 4：運算 2 ((A or B) and (C or D)) 5：運算 3 (A or B or C or D) 6：運算 4 (A and B and C and D)	0	2
<i>do1.2</i> ~ <i>do2.2</i> ~ <i>do3.2</i>	控制輸出 1~2、 事件輸出 1~3 輸出分配 A	0：常閉 (OFF、0) 1：常閉 (ON、1) 2：內部事件 1 3：內部事件 2 4：內部事件 3 5：內部事件 4 6：內部事件 5 7~13：未定義 14：MV1 15：MV2 16~17：未定義 18：DI1 19：DI2 20~25：未定義 26：內部接點 1 27：內部接點 2 28：內部接點 3	14~15 或者 2~4	2
<i>do1.3</i> ~ <i>do2.3</i> ~ <i>do3.3</i>	控制輸出 1~2、 事件輸出 1~3 輸出分配 B	29~33：未定義 34：通訊 DI1 35：通訊 DI2 36：通訊 DI3 37：通訊 DI4 38：MANUAL 模式 39：READY 模式 40：未定義 41：AT 啟動中 42：SP 斜坡中 43：未定義 44：有警報 45：有 PV 警報 46：未定義 47：Mode 鍵按鍵狀態 48：事件輸出 1 端子狀態 49：控制輸出 1 端子狀態	0	2
<i>do1.5</i> ~ <i>do2.5</i> ~ <i>do3.5</i>	控制輸出 1~2、 事件輸出 1~3 輸出分配 D	0：不反轉 1：反轉	0	2

顯示	項目	內 容	初始值	顯示級別
<i>do1.6</i> ~ <i>do2.6</i> ~ <i>do3.6</i>	控制輸出 1~2、事件 輸出 1~3 反轉 A~D 第 1 位：反轉 A 第 2 位：反轉 B 第 3 位：反轉 C 第 4 位：反轉 D	從右側開始 1、2、3、4 位 0：不反轉 1：反轉	0000 0 0 0	2
<i>do1.7</i> ~ <i>do2.7</i> ~ <i>do3.7</i>	控制輸出 1~2、事件 輸出 1~3 反轉	0：不反轉 1：反轉	0	2
<i>do1.8</i> ~ <i>do2.8</i> ~ <i>do3.8</i>	控制輸出 1~2、事件 輸出 1~3 鎖定	0：無 1：有（ON 時鎖定） 2：有（OFF 時鎖定、電源投入初始化時除外）	0	2

■ 用戶功能庫

庫選擇： *UF*

顯示	項目	內 容	初始值	顯示級別
<i>UF-1</i>	用戶功能定義 1	各設定的第 1 顯示部的顯示，設定例外的內容如下	----	1
<i>UF-2</i>	用戶功能定義 2	----	----	1
<i>UF-3</i>	用戶功能定義 3	----：未登錄		1
<i>UF-4</i>	用戶功能定義 4	<i>P</i> -：使用中 PID 組的比例帶	----	1
<i>UF-5</i>	用戶功能定義 5	<i>I</i> -：使用中 PID 組的積分時間	----	1
<i>UF-6</i>	用戶功能定義 6	<i>d</i> -：使用中 PID 組的微分時間		1
<i>UF-7</i>	用戶功能定義 7	<i>rE</i> -：使用中 PID 組的手動復位	----	1
<i>UF-8</i>	用戶功能定義 8	<i>oL</i> -：使用中 PID 組的操作量下限 <i>oH</i> -：使用中 PID 組的操作量上限 <i>P</i> - <i>L</i> ：使用中 PID 組的冷卻側比例帶 <i>I</i> - <i>L</i> ：使用中 PID 組的冷卻側積分時間 <i>d</i> - <i>L</i> ：使用中 PID 組的冷卻側微分時間 <i>oL</i> - <i>L</i> ：使用中 PID 組的冷卻側操作量下限 <i>oH</i> - <i>L</i> ：使用中 PID 組的冷卻側操作量上限	----	1

■ 鎖定庫


庫選擇： *LoC*

顯示	項目	內 容	初始值	顯示級別
<i>LoC</i>	鍵鎖定	0：所有設定可能性 1：模式、事件、運作顯示、SP、UF、鎖定、手動 MV、mode 鍵的設定可能性 2：運作顯示、SP、UF、鎖定、手動 MV、mode 鍵的設定可能性 3：UF、鎖定、手動 MV、mode 鍵的設定可能性	0	0
<i>LoC</i>	通訊鎖定	0：RS-485 通訊 read/write 可能 1：RS-485 通訊 read/write 不可	0	2
<i>LoC</i>	設定器鎖定	0：設定器通訊 read/write 可能 1：設定器通訊 read/write 不可	0	2
<i>PRSS</i>	密碼顯示	0~15 5：密碼 1A~2B 顯示	0	0
<i>PS1R</i>	密碼 1A	0000~FFFF (16 進位數)	0000	0
<i>PS2R</i>	密碼 2A	0000~FFFF (16 進位數)	0000	0
<i>PS1b</i>	密碼 1B	0000~FFFF (16 進位數)	0000	0
<i>PS2b</i>	密碼 2B	0000~FFFF (16 進位數)	0000	0

■ 儀表資訊庫

庫選擇： *id*

顯示	項目	內 容	初始值	顯示級別
<i>id01</i>	ROM ID	0 固定	-	2
<i>id02</i>	ROM 版本 1	XX. XX (小數點以下 2 位)	-	2
<i>id03</i>	ROM 版本 2	XX. XX (小數點以下 2 位)	-	2
<i>id04</i>	SLP 對應版本		-	2
<i>id05</i>	EST 對應版本		-	2
<i>id06</i>	日期代碼 年	西曆 -2000 例：2003 年為「3」	-	2
<i>id07</i>	日期代碼 月日	月 +(日 ÷ 100) 例：12 月 1 日為「12.01」	-	2
<i>id08</i>	製造編號		-	2



azbil

阿自倍爾株式會社
Advanced Automation Company

台灣阿自倍爾股份有限公司

台北市中山區中山北路二段44號9樓
電話：02-2521-6800
傳真：02-2521-2728

本資料內容若有變更恕不另行通知

版權所有，禁止翻印