

ACTIVAL™

Motorized Two-Way Valve with Flanged-End Connection (JIS 20K / SCPH2)

■ Overview

ACTIVAL Model VY51_EJ is a series of motorized two-way rotary valves, DN15 (1/2") to DN80 (3"), with flanged-end connection. The valve and actuator are integrated in a single unit.

The valve body rating corresponds to JIS 20K.

The actuator has a reversible synchronous motor, which operates at a low voltage of 24 V AC.

There are following four control signals available.

- Nominal 135 Ω feedback potentiometer
Provides proportional control in combination with a DDC controller. (e.g., Inflex GC Model WY5111)
- Nominal resistance 135 Ω input
Provides proportional control in combination with a proportionally controlled electric controller. (e.g., Neostat Model TY900_Z, insertion type Thermostat Model TY9800)
- 4-20 mA DC input
Provides proportional control in combination with a DDC controller. (e.g., Inflex GC Model WY5111, Model R35/R36)
- 2-10 V DC input
Provides proportional control in combination with a DDC controller. (e.g., Inflex AC Model WY5117)



■ Features

- Compact and lightweight
- Valve and actuator integrated in a single unit
- Conforms to IP54 (dust-proof, splash-proof)
Can be installed in AHU.
Note: Waterproof connectors are required to assure IP54.
- A variety of control input signals available
- Durable actuator with low power consumption
- 2-10 V DC output with feedback signal
Only for the 4-20 mA DC input type (Model VY513E)
and the 2-10 V DC input type (Model VY514E) .
- Equal percentage flow characteristic

- Valve is applicable for high differential pressure, large Cv value, high rangeability, and low leakage.

IMPORTANT

- If you want to use this product combined with a third party's controller, please contact Azbil corporation.

Notes:

- AHU: Air Handling Unit
- DDC: Direct Digital Control
- JIS: Japanese Industrial Standards

Safety Precautions

Please read instructions carefully and use the product as specified in this manual. Be sure to keep this manual nearby for quick reference.

Restrictions on Use

This product was developed, designed, and manufactured for general air conditioning use.

Do not use the product in a situation where human life may be at risk or for nuclear applications in radiation controlled areas. If you wish to use the product in a radiation controlled area, please contact Azbil Corporation.

Particularly when the product is used in the following applications where safety is required, implementation of fail-safe design, redundant design, regular maintenance, etc., should be considered in order to use the product safely and reliably.

- Safety devices for protecting the human body
- Start/stop control devices for transportation machines
- Aeronautical/aerospace machines

For system design, application design, instructions for use, or product applications, please contact Azbil Corporation.

Azbil Corporation bears no responsibility for any result, or lack of result, deriving from the customer's use of the product.

Recommended Design Life

It is recommended that this product be used within the recommended design life.

The recommended design life is the period during which you can use the product safely and reliably based on the design specifications.

If the product is used beyond this period, its failure ratio may increase due to time-related deterioration of parts, etc.

The recommended design life during which the product can operate reliably with the lowest failure ratio and least deterioration over time is estimated scientifically based on acceleration tests, endurance tests, etc., taking into consideration the operating environment, conditions, and frequency of use as basic parameters.

The recommended design life of this product is 10 years.

The recommended design life assumes that maintenance, such as replacement of the limited life parts, is carried out properly.

Refer to the section on maintenance in this manual.

Warnings and Cautions



WARNING

Alerts users that improper handling may cause death or serious injury.




CAUTION


Alerts users that improper handling may cause minor injury or material loss.

Signs



Notifies users that specific actions are prohibited to prevent possible danger. The symbol inside  graphically indicates the prohibited action. (For example, the sign on the left means that disassembly is prohibited.)



Instructs users to carry out a specific obligatory action to prevent possible danger. The symbol inside  graphically indicates the actual action to be carried out. (For example, the sign on the left indicates general instructions.)



WARNING



When handling or transporting any heavy product (more than 18 kg), carefully move the product with a handtruck or the like, or with 2 or more people.

Careless lifting or accidental dropping of the product may result in injury or product damage.



CAUTION



Provide a circuit protector (e.g., a fuse or circuit breaker) for the power source. Failure to do so may cause a short circuit leading to fire or device failure.



Do not freeze this product. Doing so may damage the valve body and cause leakage.



When piping this product, be sure there is no foreign matter in the pipes. If foreign matter remains in the pipes, the product may break down.



Install, wire, and use this product under the conditions specified by this manual. Failure to do so may cause fire or device failure.



When installing this product, hold it in the proper position and securely fasten it to the pipes. Excessive tightening or improper installation position may damage the valve.

⚠ CAUTION

❗	After installation, make sure no fluid leaks from the valve-pipe connections. Improper piping may cause fluid leakage outside of the valve.
⊘	Do not put a load or weight on this product. Doing so may damage the product.
❗	Installation and wiring of the actuator must be performed by personnel qualified to do instrumentation and electrical work. Mistakes in installation or wiring may cause fire or electric shock.
❗	Before wiring or maintenance, be sure to turn off the power to this product. Failure to do so may result in electric shock or device failure.
❗	All wiring must comply with applicable codes and ordinances. Otherwise there is a danger of fire.

⚠ CAUTION

❗	Use crimp terminals with insulation for connections to the product terminals. Failure to do so may cause short circuit leading to fire or device failure.
❗	Tighten the terminal screws with the specified torque. Insufficient tightening of the terminal screws may cause fire or overheating.
❗	After wiring or maintenance, be sure to reattach the terminal cover. Failure to do so may result in electric shock.
⚡	Do not carelessly touch this product when it is used to control hot water. Doing so may result in burns, because the product reaches a high temperature.

■ Model Numbers

Model VY51_EJ00__ is the model for the valve and actuator integrated into a single unit.

The model number label is attached on the yoke.

Base model number	Actuator/valve		Actuator		Valve	Description
	Control signal	Rating/material	Type	Fixed	Valve size Cv	
VY51						Motorized two-way rotary valve
	1					Nominal 135 Ω feedback potentiometer (F motor type)
	2					Nominal 135 Ω resistance input (E motor type)
	3					4–20 mA DC with 2–10 V DC feedback signal
	4					2–10 V DC input with 2–10 V DC feedback signal
		E				JIS 20K-SCPH2
			J			IEC IP54 protected and standard torque type actuator with terminal block Applicable valve sizes: DN15 (1/2") to DN80 (3")
				00		Fixed
					11	DN15 (1/2"), Cv: 1.0
					12	DN15 (1/2"), Cv: 2.5
					13	DN15 (1/2"), Cv: 6.0
					21	DN25 (1"), Cv: 10
					22	DN25 (1"), Cv: 16
					41	DN40 (1½"), Cv: 25
					42	DN40 (1½"), Cv: 40
					51	DN50 (2"), Cv: 65
					61	DN65 (2½"), Cv: 95
					81	DN80 (3"), Cv: 125

Note:

- IEC: International Electrotechnical Commission

● Options

Item	Model number		Specification	
Power transformer	AT72-J1		Primary voltage	100 V AC, 200 V AC, or 220 V AC
			Secondary voltage	23 V AC
			Power frequency	50–60 Hz
Waterproof connector*1	83104346-	003	Applicable wire	Dia. 7–9 mm
Auxiliary switch*2	83174063-	101	Number of auxiliary switches	2
			Max. applied voltage, current	30 V DC, 100 mA*3 (Inductive load includes inrush current.)
			Operation range	SWA: variable from 0 % (fully closed) to 100 % (fully open)
				SWB: variable from 0 % (fully closed) to 100 % (fully open)
Auxiliary potentiometer*2	83165275-	001	Number of auxiliary potentiometers	1
			Total resistance	Nominal 1 kΩ
			Operation range	0 % (fully closed) to 100 % (fully open)
			Max. applied voltage	5 V DC Note: It cannot be connected with Model M904E.
Outdoor cover	DY3001A1017		Material	Stainless steel plate t1.0
			Weight	Approx. 550 g

*1 Required to maintain IP54.

*2 Either the auxiliary switch or the auxiliary potentiometer can be added. Cannot coexist.
For details, refer to the user's manual attached to the product.

*3 If the applied current exceeds 100 mA, please contact Azbil Corporation.

■ Specifications

● Valve and actuator

(1 to 2)

Item	Specification		
Operating conditions	Rated operating conditions	Ambient temperature	-20–50 °C
		Environment humidity	5–95 % RH
		Vibration	4.9 m/s ² (10–150 Hz)
	Transportation/storage conditions (in packed state)	Ambient temperature	-20–70 °C
		Ambient humidity	5–95 % RH
		Vibration	19.6 m/s ² (10–150 Hz)
Installation location	Indoor use Note: Salt air, corrosive gas, flammable gas, and organic solvent must be avoided.		
	Outdoor use Note: Salt air, corrosive gas, flammable gas, and organic solvent must be avoided. And, use the outdoor cover (to be ordered separately) etc. to avoid direct sunlight.		
Mounting position	Refer to ■ "Installation," ● "Mounting position."		
Manual operation	Available Refer to ■ "Installation," ● "Manual open/close operation."		
Insulation resistance	Between terminals and case	5 MΩ or more at 500 V DC	

(2 to 2)

Item	Specification		
Withstand voltage	Between terminals and case	500 V AC / 1 min with leak current 5 mA or less	
Weight	Model VY51_EJ00	11	5.2 kg
		12	
		13	
		21	7.4 kg
		22	
		41	10.5 kg
		42	
		51	12 kg
		61	17 kg
		81	22 kg


● Valve

Item	Specification				
Type of valve	Two-way valve, flanged-end connection				
Rated pressure	JIS 20K (max. operating pressure 2.0 MPa)				
Valve size, Cv, Closed-off rating	Model		Valve size	Cv	Closed-off rating
	VY51_EJ00	11	DN15 (1/2")	1.0	1.0 MPa
		12	DN15 (1/2")	2.5	
		13	DN15 (1/2")	6.0	
		21	DN25 (1")	10	
		22	DN25 (1")	16	
		41	DN40 (1½")	25	
		42	DN40 (1½")	40	
		51	DN50 (2")	65	
		61	DN65 (2½")	95	
	81	DN80 (3")	125	0.7 MPa	
End connection	Flanged-end connection (JIS 20K) , raised face flange (RF)				
Applicable fluid	Chilled/hot water, high temperature water, brine (glycol concentration: 50 % or less)				
Temperature of fluid	0–150 °C (without freezing)				
Flow characteristics	Equal percentage characteristic				
Rangeability	100:1				
Leakage from valve seat	0.01 % of the rated Cv (max. 0.0006 of Cv for DN15)				
Major materials	Body		Carbon steel casting (SCPH 2)		
	Plug, stem		Stainless steel		
	Seat ring Gland packing		Heat-resistant PTFE		
	Gasket		Expanded graphite sheet		
Color	Gray (equivalent to M5B 4/1)				
Attaching actuator	Integrated with the valve				
Valve position Indication	Indicated by the groove on the tip of the valve stem.				

● Actuator

Item	Specification	
Power supply	24 V AC \pm 15 %, 50/60 Hz	
Power consumption	Nominal 135 Ω feedback potentiometer	7 VA
	Nominal 135 Ω resistance Input	8 VA
	4–20 mA DC input	
	2–10 V DC input	
Actuator	For valve size DN15 to DN80	Standard torque type
Valve travel time	63 \pm 5 s (50 Hz) , 53 \pm 5 s (60 Hz)	
Control signals	Nominal 135 Ω feedback potentiometer	Feedback potentiometer : total resistance = nominal 135 Ω Max. applied voltage : 5 V DC
	Nominal 135 Ω resistance Input	
	4–20 mA DC input	Input impedance: 100 Ω
	2–10 V DC input	Input impedance: 150 k Ω or more
2–10 V DC feedback signal (for 4–20 mA DC input, 2–10 V DC Input)	Output voltage range	2 V DC (fully closed) to 10 V DC (fully open)
	Maximum load resistance	10 k Ω or more (max. output current: 1 mA)
Valve position indication	Indicator: 0 (fully closed) to 100 (fully open) Can be seen from the forward, backward, or lower position.	
Cable	Screwed on the terminal block (M3.5) , tightening torque 0.8–1.0 N•m Note: Open an appropriate knockout hole (dia. 22) located on both sides of the actuator at the worksite.	
Enclosure protection	IEC IP54 (dust-proof, splash-proof)	
Factory preset position	Fully open	
Major materials	Case	Aluminum diecast
	Top cover, terminal cover	Polycarbonate resin (color: gray (equivalent to DIC-651))
	Yoke	Steel plate
Surface finishing	Case	None
	Yoke	Electro-galvanizing (bright chromate finish)

■ Dimensions



*1 Clearance for maintenance.


*2 For setting the auxiliary switch, make sure to allow a clearance of 300 mm or more.

Figuar 1 Dimensions (mm)

Table 1 Dimension table (mm)

Valve size	L	L1	H	H1	ϕD	ϕC	ϕg	t	ϕh	N
DN15	140	50	213	75	95	70	51	14	15	4
DN25	165	60	228	90	125	90	67	16	19	4
DN40	190	82.5	241	103	140	105	81	18	19	4
DN50	216	115	245	107	155	120	96	18	19	8
DN65	241	120.5	262	124	175	140	116	20	19	8
DN80	283	123	263	125	200	160	132	22	23	8

■ Parts Identifications



Figuar 2 Parts identifications

■ Installation

⚠ WARNING



When handling or transporting any heavy product (more than 18 kg), carefully move the product with a handtruck or the like, or with 2 or more people.

Careless lifting or accidental dropping of the product may result in injury or product damage.

⚠ CAUTION



Do not freeze this product. Doing so may damage the valve body and cause leakage.



When piping this product, be sure there is no foreign matter in the pipes. If foreign matter remains in the pipes, the product may break down.



Install, wire, and use this product under the conditions specified by this manual. Failure to do so may cause fire or device failure.

● Precautions for installation

Observe the following cautions in order to avoid failure of this product.

- Do not strike or jar this product.
- Be sure there is no foreign matter in the pipes. Observe the following instructions to remove foreign matter.
 - Install a strainer on the upstream side of the product.
For chilled/hot water: 40 or more mesh
 - If the strainer cannot be installed just before the inlet of each valve, install it on the pipe diverting sections for each piping group.
- Do not install this product near a steam coil, hot-water coil, etc.
High-temperature radiant heat may cause failure of the actuator.
- Avoid connecting the product to piping where water hammer may occur or slag, etc. easily collects.

In addition, observe the following cautions.

- Install a bypass pipe and gate valves on the inflow, outflow, and bypass sides.
- Install the product so that maintenance and inspection can be done easily.
Refer to ■ "Dimensions."
- When installing the product in the ceiling, provide a trapdoor within 50 cm around the valve. And, place a drain pan under the valve.

● Mounting position

Install the product so that fluid flows in the direction pointed by the arrow on the body. It can be mounted in any position ranging from upright to sideways (90° tilted).

Note: If the product is installed outdoors, place it in upright position.




Figure 3 Correct mounting

Actuator is below the valve.




Figure 4 Incorrect mounting

● Piping

⚠ CAUTION



When installing this product, hold it in the proper position and securely fasten it to the pipes. Excessive tightening or improper installation position may damage the valve.

- (1) Check that the model number of the product is what you ordered. The model number is shown on the label attached on the yoke.
- (2) Install the valve so that fluid flows in the direction pointed by the arrow on the valve body.
Refer to ● "Mounting position."
 - When piping, do not apply too much sealing material, such as solidifying liquid and tape, to the pipe connection sections.
 - Do not allow chippings, sealing material, etc. to get into the pipes.

The foreign matter, such as chippings, seal material for screwing the pipes, may be caught in, resulting damages on the valve seat and the valve may not be fully closed.
- (3) Fully open the valve and flush the pipes at the maximum flow rate. When fluid flows for the first time, it is to clean out the foreign matter and refuse in the pipes.
The valve is set to fully open when it is shipped from the factory.

⚠ CAUTION




After installation, make sure no fluid leaks from the valve-pipe connections. Improper piping may cause fluid leakage outside of the valve.



Do not put a load or weight on this product. Doing so may damage the product.

● Heat insulation

- Apply heat insulation in the area illustrated by  in Fig. 6.
- If the heat insulation material is placed above the yoke, the indicator may be hidden from sight or be deformed by being entangled with the insulation material.




Figure 5 Heat insulation

● Factory preset position

Actuator shaft: fully open

Pointer: completely turned clockwise.




Figure 6 Pointer position for shipment

● Manually opening/closing operation

IMPORTANT

- Before opening or closing the valve manually, turn off the power.
If the valve is manually opened or closed while the power (24 V AC) is applied, the actuator may break down.
- Do not manually open or close the valve beyond the fully open or fully closed scale.

- (1) Turn off the power.
- (2) Hold the joint using a wrench, etc., gently turn the wrench to the desired position, open or close.

Note: If the valve is subject to shock, the actuator may break down.





Figure 7 Manually opening/closing operation

● Changing the actuator mounting position


IMPORTANT

- Do not break combination of the valve, yoke, and actuator.
- When changing the mounting position of the actuator, set the position to 100 % (fully open) for the valve and actuator.
If the valve and actuator are assembled in different valve positions, gears in the actuator will be damaged because the actuator will try to close or open the valve although the valve stops at the fully closed or fully open position.

- (1) Remove the screws connecting the actuator and the yoke.




- (2) Lift the actuator and detach it from the yoke.
- (3) Remove the screws connecting the yoke and the valve.




Note: A special sheet is inserted between the yoke and valve for heat insulation.
When you changed the mounting position, be careful not to lose the sheet.


- (4) Make sure that the groove on the tip of the valve stem is parallel to the pipes (indicating the valve in 100 % position) .



- (5) Align the yoke to the desired orientation.
Orientation of the actuator can be changed by 90° steps from the factory preset position.
(0°/90°/180°/270°)



- (6) Reinsert the sheet removed in step (3) between the yoke and the valve, and then mount the yoke on the valve with the screws.



- (7) Check that the pointer on the actuator indicates the fully open, and that the actuator can be properly seated on the valve stem.
- (8) Mount the actuator on the yoke using the screws removed in step (1) .
- (9) Check that the valve smoothly operates from the fully closed to fully open positions.

■ Wiring

⚠ CAUTION	
❗	Provide a circuit protector (e.g., a fuse or circuit breaker) for the power source. Failure to do so may cause a short circuit leading to fire or device failure.
❗	Install, wire, and use this product under the conditions specified by this manual. Failure to do so may cause fire or device failure.
❗	Installation and wiring of the actuator must be performed by personnel qualified to do instrumentation and electrical work. Mistakes in installation or wiring may cause fire or electric shock.
❗	Before wiring, be sure to turn off the power to this product. Failure to do so may result in electric shock or device failure.
❗	All wiring must comply with applicable codes and ordinances. Otherwise there is a danger of fire.
❗	Use crimp terminals with insulation for connections to the product terminals. Failure to do so may cause short circuit leading to fire or device failure.
❗	Tighten the terminal screws with the specified torque. Insufficient tightening of the terminal screws may cause fire or overheating.

IMPORTANT

- This product is designed for 24 V AC power supply voltage. Do not apply power supply voltage other than 24 V AC.
- For the 2-10 V DC input type and the 4-20 mA input type, check the polarity of the power supply and 2-10 V DC feedback signal, and then correctly wire the product. Incorrect wiring may result in PCB (print circuit board) burnout.

● How to maintain IP54 (dust-proof, splash-proof)

In order to maintain IP54 performance, use a waterproof connector or a water-resistant plica tube when the product is used in high humidity environment or outdoor.

- Be sure to completely close the terminal cover and top cover.
- Apply a waterproofing treatment for the knockout hole.
- For cable connection, use the waterproof connector (to be ordered separately).
- For conduit connection, use the waterproof plica tubes etc.


● Control signals type

The type of control signals is printed on the actuator label and the wiring diagram label as shown below.

F.B. Pot	: Nominal 135 Ω feedback potentiometer (F motor)
135 Ω	: Nominal 135 Ω resistance input (E motor)
4–20 mA	: 4–20 mA DC input
2–10V	: 2–10 V DC Input

● Wiring procedure



- (1) Select a knockout hole according to the wire outlet direction, and open a knockout hole.
Two knockout holes are provided on the bilateral sides of the actuator. The knockout holes can be easily opened by lightly knocking the hole using a screwdriver.



IMPORTANT

- Do not leave pieces of metal (generated by making the knockout hole) inside the actuator.

- (2) Unscrew the 3 setscrews (M4 x 10) on the terminal cover to remove the cover.




- (3) Correctly connect the wires to the terminals with the M3.5 screw terminal screws.

Do not apply 24 V AC to terminals 4 to 7.

Note: Correctly connect the wires referring to Fig. 8 to Fig. 12, "Terminals Connection", Fig. 13 to Fig. 26, "Wiring Examples" and "Advanced Wiring Examples."


- (4) Mount the terminal cover and attach it with the setscrews.



■ Terminals Connection

● Nominal 135 Ω feedback potentiometer


(Model VY511EJ)




Note: The controller that reads the voltage between terminals 4 and 6 as a feedback signal is recommended.

Figuar 8

Recommended controller circuit




Note: If a third-party's controller is used combining with the product, the controller in above is to be used.

-  : Recommended controller circuit
 E : Voltage supplied by the controller
 V : Votage between 4 and 6.

Figuar 9

● Nominal 135 Ω resistance input


(Model VY512EJ)



Figuar 10

● 4–20 mA DC input

(Model VY513EJ)




Note: The terminal 2 (power), terminal 5 (4–20 mA DC input), and terminal 7 (2–10 V DC feedback signal) are internally connected.

Figuar 11

● 2–10 V DC input

(Model VY514EJ)




Note: The terminal 2 (power), terminal 5 (2–10 V DC input), and terminal 7 (2–10 V DC feedback signal) are internally connected.

Figuar 12

■ Wiring Examples

● Nominal 135 Ω feedback potentiometer


(Model VY511E)



Figuar 13 Connection to Inflex GC

● Nominal 135 Ω resistance Input


(Model VY512E)



Figuar 14 Connection to Neostat

● 4–20 mA DC input

(Model VY513E)




*1 The terminal 2 (power), terminal 5 (4–20 mA DC input), and terminal 7 (2–10 V DC feedback signal) are internally connected.

*2 Input impedance of 4–20 mA DC input of the actuator is 100 Ω .
4–20 mA DC input is not isolated. Install the power transformer separately.

Figuar 15 Connection to R-series

● 2–10 V DC input

(Model VY514E)



* Terminals 2, 5, and 7 are internally connected.

Note: Do not implement a daisy chain wiring passing through the actuator's power terminals.


Figuar 16 Connection to Inflex AC

■ Advanced Wiring Examples

● Nominal 135 Ω resistance Input

(Model VY512E)

Minimum opening setting




In addition to the proportional controller, by adding the setting device of 135 Ω output, the minimum opening of the actuator can be set within the range of 0 to 50 % (approximately) .

- * Connect between (R) and (B) with a jumper.

Note: In an abnormal condition (such as disconnection in the actuator, an abnormal input signal, failure of the feedback potentiometer due to its product service life), the minimum opening position cannot be maintained. Avoid instrumentation that may cause secondary damage in case of abnormality.

Figuar 17

Summer-winter changeover




- *1 Directly wire between ④ and ④.

- *2 The current among W, B, and R is 5 mA or more.
A relay equivalent to Model HH54P of Fuji Electric Co.
can be used

Figuar 19

Using relay, interlock



Figuar 18

● 4–20 mA DC input

(Model VY513E)

Precautions


- Power transformer is shared If a power transformer is shared by two products, connect the terminal ① of each actuator to the transformer with the same polarity. Connect the terminal ② in the same way. If the terminals are connected with different polarities, the product may break down (see Fig. 21).

- Control signals are shared for 4–20 mA DC input The 4–20 mA DC input signals of this product are not isolated from the power.

And, the input impedance of 4–20 mA DC signals is 100 Ω . The relations among the input impedance of the product, the output load resistance of the controller, and the output load resistance and input impedance of an isolator (if necessary) must meet the following formula. Applicable load resistance > Total of input impedance

If two products are operated by one controller, configure the system referring to Fig. 22 for two individual transformers, Fig. 20 for a shared transformer. To share a power transformer, install an isolator to the 4–20 mA DC input terminals of the second product. Otherwise, the product will malfunction.

Input signals and power are shared




*1 Provide an isolator for the controller that is not internally isolated.

*2 Terminals 2, 5, and 7 are internally connected.

*3 Refer to notes under "Power transformer is shared."

Figuar 20

Power is shared




*1 Provide an isolator for the controller that is not internally isolated.

*2 Terminals 2, 5, and 7 are internally connected.

Figuar 21

Input signals are shared



*1 Provide an isolator for the controller not internally isolated.

*2 Terminals 2, 5, and 7 are internally connected.

*3 Provide an isolator if no isolator is provided to the 4–20 mA DC input of the first actuator AND the applicable load resistance of controller is less than 200 Ω .

Figuar 22


● 2–10 V DC input

(Model VY514E)

Precautions

- If a power transformer is shared by two products terminal 1 of each actuator to the transformer with the same polarity. Connect the terminal 2 in the same way.
- If the terminals are connected with different polarities, the product may break down (see Fig. 24).


Input signals and power are shared



- *1 Provide an isolator for the controller that is not internally isolated.
- *2 Terminals 2, 5, and 7 are internally connected.
- *3 Refer to notes under "Power transformer is shared."

Figuar 23


Power is shared



- *1 Provide an isolator for the controller that is not internally isolated.
- *2 Terminals 2, 5, and 7 are internally connected.
- *3 Refer to notes under "Power transformer is shared."

Figuar 24

Input signals are shared




- *1 Provide an isolator for the controller not internally isolated.
- *2 Terminals 2, 5, and 7 are internally connected.

Figuar 25

● For connecting multiple products

Nominal 135 Ω feedback potentiometer (Model VY511E)

Or, for connecting the nominal 135 Ω resistance input (Model VY512E) and the “nominal 135 Ω resistance input.”



*1 If two auxiliary potentiometers (option) are connected to ACTIVAL, externally connect the $240 \pm 5\%$ Ω resistor, which is included in the auxiliary potentiometer kit, between W and B.

*2 Generally use an isolated transformer such as Model AT72-JI for a valve, and do not share the transformer with other devices such as sensor, transmitter.

Figure 26

■ Maintenance

⚠ CAUTION	
⊘	Do not put a load or weight on this product. Doing so may damage the product.
!	Before doing maintenance, be sure to turn off the power to this product. Failure to do so may result in electric shock or device failure.
!	After maintenance, be sure to reattach the terminal cover. Failure to do so may result in electric shock.
⊘	Do not carelessly touch this product when it is used to control hot water. Doing so may result in burns, because the product reaches a high temperature.

- After piping the product, if it is not operated for a long period, execute valve open and close operations once a month or so.
- Execute maintenance according to table 2.
- Once every six months or so, visually check that there is no leakage of fluid to the outside of the valve and the actuator operates smoothly.

if a trouble occurs as described in Table 3, take appropriate measures according to the symptom. Although the measures are taken, if the trouble cannot be recovered, please contact Azbil Corporation.

Table 2 Inspection items and inspection method

Item	Inspection cycle	Inspection method
Visual check	6 months	<ul style="list-style-type: none"> • There is no leakage from the gland and flange. • Loose bolts. • There is no damage on the valve and actuator.
Operation status	6 months	<ul style="list-style-type: none"> • The valve is smoothly opened or closed. • Check that no abnormal sound or vibration is observed.
Daily inspection	Any time	<ul style="list-style-type: none"> • Check that there is no leakage of fluid to the outside of the valve. • Check that no abnormal sound or vibration is observed. • The valve is smoothly opened or closed. • Check that there is no hunting observed with the valve.

Table 3 Troubleshooting

Abnormal phenomenon	Where to inspect	Measure
Leakage from the flange	Loose flange bolts Gasket on the flange. Misaligned pipes	Retighten the flange bolts. Replace the gasket. Do piping again.
Leakage from the gland	-----	Contact Azbil Corporation
Leakage from the top lid joint.	Loose bolts	Retighten the bolts.
The valve is not smoothly opened or closed. The valve stops halfway. The valve does not move.	Check that the power line and the input signal are correctly fed. Loose terminals Check that wires are firmly connected, no disconnected wire.	Check the power supply voltage and the controller. Retighten the terminals. Check the wirings.
Leakage is observed when the valve is fully closed.	Pointer position when the valve is fully closed	Fully close the valve.
Abnormal sound or vibration is observed.	Check that level of pressure at the primary is adequate. Check the level of differential pressure.	Adjust the mounting conditions.
The auxiliary switch does not work.	Check the conditions of the auxiliary switch cam. Loose terminals Check that wires are firmly connected, no disconnected wire.	Do settings again. Retighten the terminals. Check the wirings.
The auxiliary potentiometer does not work.	Resistance value Loose terminals Check that wires are firmly connected, no disconnected wire.	Check the resistance. (1 kΩ) Retighten the terminals. Check the wirings.
Valve hunting	Level of pressure and differential pressure at the secondary Stability of control	Adjust the mounting conditions. Adjust the settings of control parameter such as PI.
Mismatch between the input signal and the feedback signal in the voltage/current input specifications	-----	If the input specification is voltage or current, the valve moves from 0 % to 100 % corresponding to the input signal from 10 % to 90 % in order to fully close the valve. Therefore, the input signal and the feedback signal do not match, but it is not abnormal.

■ Disposal

Dispose of this product as industrial waste in accordance with your local regulations.

Do not reuse all or any part of the product.



This product complies with the following harmonised standards of the Electromagnetic Compatibility Directive (EMCD) .

EMCD: EN 61000-6-2

EN 55011 Class A, Group 1

- * ACTIVAL is a trademark of Azbil Corporation.
- * Inflex is a trademark of Azbil Corporation.

Azbil Corporation
Building Systems Company

1-12-2 Kawana, Fujisawa, Kanagawa
251-8522 JAPAN

<https://www.azbil.com/>

azbil