

Device Management System InnovativeField Organizer

R60

What is InnovativeField Organizer?

InnovativeField Organizer is a device management system for smart field devices that support HART® Communication Protocol.

Features

- Contributes to fast commissioning using improved methods of adjusting, checking, and testing field devices and control valves before startup/restart of plant.
- Once plant operation has started, InnovativeField Organizer monitors the status of field devices 24 hours a day, 365 days a year to detect any changes in the device at the earliest stage possible.
- With HART communication, the real-time status of operating devices can be monitored with data updated at intervals of about 1 second.*
- * When InnovativeField Organizer is used with Azbil Corporation's HART communication interface
- During plant operation, online control valves are continuously diagnosed, and indexes for condition-based maintenance (CBM) of valves can be quantified.
- Plug&Play facilitates operations such as device registration and setup, and system reconfiguration if new devices are added.
- InnovativeField Organizer can be introduced without affecting DCS software simply.
- The status of devices is displayed in conformity with alarm standard 107 of the European user association NAMUR (hereinafter NAMUR NE107) and with Fieldbus Foundation FF912.

Advantages

- Supports quick and accurate plant startup by providing strong support for device connection checks, configuration/calibration, inspections, and loop checks before the plant starts.
- Once the plant has started operation, the operation status of field devices is monitored 24 hours a day, 365 days a year. By detecting field device abnormalities at an early stage, InnovativeField Organizer brings the opportunities to prevent unscheduled plant shutdown.
- InnovativeField Organizer assists plant managers to make the transition from time-based maintenance to condition-based maintenance, allowing them to create appropriate maintenance plans based on the actual degree of deterioration of control valves as indicated by CV diagnostic data.

Function Overview

Display of Device Status

The operation status of field devices is displayed in a tree format that corresponds to the management hierarchy or system configuration of the plant equipment. This format provides operators and maintenance staff with a device management screen that can be viewed easily, offering excellent convenience and device visibility.








Figure 1. Device Management Screen

InnovativeField Organizer indicates device status in the device tree with symbols that comply with NE 107: 2006 issued by NAMUR, a European automation user organization. When an alert status is detected for a device, an alert symbol is displayed in the tree, and details are displayed with a timestamp and saved as alert history information. By double-clicking an on-going alert, further details about the alert can be checked.

Table 1. Symbols compliant with NAMUR NE107

Symbol	Description
	Maintenance Required
	Out of Specification
	Check Function
	Failure




Figure 2. Detailed Alert Data dialog box

Major Alert

If a major alert*1 that is urgent and requires the operator’s attention is detected for a field device, it is possible to have the system issue an alert sound, turn on the LAN rotary beacon light,*2 or send a notification to the DCS.*3 *4 Notification that a major alert has been issued is sent to the DCS. The details of the alert will be displayed in the pop-up Major Alert window of InnovativeField Organizer.

- *1: The user can specify which types of alerts are considered to be major alerts.
- *2: The LAN rotary beacon light is sold separately.
- *3: To use this function, an OPC server that can write data to the DCS is required.
- *4: Do not use the DCS to change the value written to it in the major alert notification.




Figure 3. Major Alert

Device Memo

A memo can be created for individual field devices and can be opened from the device tree for easy reference. The user can use device memos for purposes such as recording the installation date, adjustment history, or abnormal conditions, in order to manage devices.

Adjustment and Setting

Field devices made by manufacturers other than Azbil Corporation can be adjusted and set using the device type manager (DTM) or Device Description (DD/EDD) provided by the field device manufacturer.




Figure 4. DTM for Azbil Corporation’s AVP302

Real-time Trends

Multiple variables retained by HART devices (HART variables*) can be easily monitored on the Trend tab.

* The variables (8 max.) that can be obtained by HART command 3 or 9

“Real-time Trend” is a function for displaying selected HART variables in a continuously updated trend graph. No special settings are required, and the variables can be displayed simply by selecting the device. Several graphs can be displayed simultaneously for a device, and the graphs can be used for many purposes, such as monitoring the actual valve travel or the device temperature, or monitoring and diagnosing impulse pipe clogging.

Tag Commissioning

InnovativeField Organizer user can be easily and quickly checked whether exact field devices are connected or not. Then the report can be created.

Support for Loop Checks

In preparation for trial operation and startup, InnovativeField Organizer helps the user to quickly implement a variety of processes, from loop checking to adjusting individual devices and creating reports. Analog inputs (AI) and analog outputs (AO) of up to 50 devices can be checked simultaneously with automatic evaluation of the results, improving work efficiency significantly. The following support functions are available.

■ **Device connection status**

The user can check quickly whether HART devices are connected to the loops defined in the design and whether they are operating. This function is useful for checking the connection status of devices that were removed for maintenance.

■ **Commissioning**

For connected HART devices, basic parameters such as tag, vendor, and range can be quickly checked. This function ensures that users will not forget to reset a temporarily changed range.

■ **AI Check / AO Check**

With the analog input (AI) check, the usual troublesome onsite 3- or 5-point check using a communicator or signal generator can be automated. In addition, the results are evaluated and recorded automatically in cooperation with the DCS.

With the analog output (AO) check*, in cooperation with the DCS, output commands can be sent automatically, and the results are automatically evaluated, eliminating the need for a visual onsite check of control valve's travel. The AI or AO of up to 50 devices can be checked simultaneously, reducing work time significantly. This function is available for field devices that support HART command 40.

* Automatic checking of the AO using the DCS is available for Advanced-PS, Harmonas-DEO, and Yokogawa Electric CENTUM. To execute this function, an OPC server that can change the values output from the DCS is required. If DCS outputs are changed manually from a DCS operator station, AO checks can be executed with a system other than Advanced-PS, Harmonas-DEO, and CENTUM. If PLUG-IN Valstaff is not installed, AO checks can be executed only if [Flow type] (I/O characteristics) is set to "Linear" for the positioner.

Progress

The progress of the loop check (device connection status, commissioning, AI/AO check) can be checked for each device.

Device Tag	Unit	Set	Dev	Unit	PV	Set	Dev	Unit	PV	Set	Dev	Unit	PV	Result	Date and Time
GT700001	U1	4	4.000	3.988	-0.010	12	12.000	11.999	49.990	20	20.000	19.998	99.990	OK	01/19/2018 14:34:32
GT700002	U1	4	4.000	3.988	-0.010	12	12.000	11.999	49.990	20	20.000	19.998	99.990	OK	01/19/2018 14:34:34
GT700003	U1	4	4.000	3.988	-0.010	12	12.000	11.999	49.990	20	20.000	19.998	99.990	OK	01/19/2018 14:34:34
GT700004	U1	4	4.000	4.000	0.000	12	12.000	11.999	49.990	20	20.000	19.987	99.980	OK	01/19/2018 14:34:32
GT700005	U1	4	4.000	4.002	0.000	12	12.000	12.002	50.010	20	20.000	20.003	100.020	OK	01/19/2018 14:34:35
GT700006	U1	4	4.000	4.000	0.000	12	12.000	12.002	50.000	20	20.000	20.000	100.000	OK	01/19/2018 14:34:32
GT700007	U1	4	4.000	4.000	0.000	12	12.000	11.999	49.990	20	20.000	19.995	99.970	OK	01/19/2018 14:34:35
GT700008	U1	4	4.000	3.988	-0.010	12	12.000	12.000	49.990	20	20.000	20.000	100.000	OK	01/19/2018 14:34:35
GT700009	U1	4	4.000	4.000	0.000	12	12.000	12.000	50.000	20	20.000	20.000	99.990	OK	01/19/2018 14:34:37
GT700010	U1	4	4.000	3.988	-0.010	12	12.000	11.999	49.990	20	20.000	19.987	99.980	OK	01/19/2018 14:34:37
GT700011	U1	4	4.000	4.002	0.010	12	12.000	12.002	50.010	20	20.000	20.003	100.010	OK	01/19/2018 14:34:39

Figure 5. AI Check screen (while multiple devices are being checked)

Support for Interlock Test and Sequence Tests

InnovativeField Organizer provides a batch handling tool for outputting simulated signals. When an InnovativeField Organizer user executes the DCS Interlock Test or Sequence Test, this tool can be used to instruct simulated signal output to many field devices in one operation. With conventional methods, many people would be required in order to input simulated signals to multiple field devices. This function is available for HART devices that support HART command 40.

Automated report generation of device parameters

Usually, after completing adjustment of field devices and before starting operation at a plant, workers must collect parameter data from all the field devices and record this master data in a register. Until now workers have had to go around to each individual device, but using InnovativeField Organizer enables them to record the parameters of multiple devices in one batch, and it automatically creates data reports. The parameters defined by the data report output function of DTM or DD provided by device vendors are output.

HART Variables Historian (optional)

Regardless of the device type, variables retained by HART devices (HART variables*) can be stored as continuous history data for the long term and can be displayed in trend graphs. On the graphs, operations such as checking the correlation with other devices and searching for data by a timestamp or tag are possible. In addition, history data can be utilized in Microsoft Excel.

* Variables (8 max.) that can be obtained by HART command 3 or 9.




Figure 6. HART Variables Historian Screen (optional)

HART Variable Bridge (optional)

Using this software, the DCS, the plant information management system (PIMS), and other host computers can use up to eight HART variables that InnovativeField Organizer collects in real time from field devices using HART command 3 or 9.

The HART Variable Bridge provides an OPC server function that enables a host computer to access up to eight HART variables of a field device collected by InnovativeField Organizer. The host computer can read the HART variables using OPC DA or OPC UA.

In addition, when a DOPC IV controller is used in the Harmonas-DEO or Advanced-PS DCS system, by connecting InnovativeField Organizer to the DCS control network, the collected HART variables can be transferred to DOPC IV variables which can be used by the DCS as data in operations. Also, if Harmonas-DEO R510 or later and DOPC IV R5.0 or later are used, valve travel data retained by a HART-compatible Smart Valve Positioner model AVP300 or AVP700 can be displayed on the faceplate of a regulatory control point or an analog output (AO) point. Note that if HART communication is interrupted due to an InnovativeField Organizer restart or electromagnetic noise, updates of DOPC IV's HART data and OPC communication with the host computer will stop.




Figure 7. PID faceplate displaying control output and valve travel

Diagnostics Application

In addition to the internal self-diagnostics executed by field devices, sophisticated device-specific diagnostic mechanisms and management functions specially made for the devices, which cannot be realized by a DTM only, are provided as optional plugin applications for InnovativeField Organizer.

■ PLUG-IN Valstaff (Control Valve Diagnostic Maintenance Support Package)

PLUG-IN Valstaff makes the major valve management functions of Valstaff, Azbil Corporation's control valve maintenance support system, available on InnovativeField Organizer. In combination with Azbil's AVP Smart Valve Positioner, PLUG-IN Valstaff provides online CV diagnostics, positioner auto-setup, automated step response test, and valve signature test.

* See SS2-PVS600-0001 for details on PLUG-IN Valstaff.

System Configuration

For Advanced-PS (TDCS3000)

Digital field devices and InnovativeField Organizer can be connected using HART communication.

If process controller I/O modules are the base unit type, HART-compliant I/O modules (BU100H series) can be mounted on them.

BU100H modules are mounted in communication slots that connect to digital field devices (HART). The modules and InnovativeField Organizer are connected using a device communication network (Ethernet).

With the OPC communication function of the HART Variable Bridge, the HART variables that InnovativeField Organizer collects in real time from field devices using HART command 3 or 9 can be sent to an OPC client system such as the PIMS (host computer).

If a DOPV IV controller is used in Advanced-PS (Rel.43X/53X), by connecting InnovativeField Organizer to an UCN-EX network, the collected HART variables can be transferred to DOPV IV variables which can be used by Advanced-PS as data in operations.

Notes

- Basically, one InnovativeField Organizer can be connected to one UCN or UCN-EX network.
- If one InnovativeField Organizer is connected to multiple UCN or UCN-EX networks, make sure to set different node numbers for the controllers when configuring the system.
- To use InnovativeField Organizer connected to the LCN control network so that the collected HART variables can be used as Advanced-PS data, InnovativeField Organizer must be installed on a standard workstation sold by Azbil.




Figure 8. Configuration for Advanced-PS/TDCS3000

For Harmonas-DEO

Digital field devices can be connected to InnovativeField Organizer using HART communication.

For HART communication, HART-compliant I/O modules (BU100H series) can be mounted on the base unit I/O modules connected to the process controllers. BU100H modules are mounted in communication slots that connect to digital (HART) field devices. The modules and InnovativeField Organizer are connected using a device communication network (Ethernet).

With the OPC communication function of the HART Variable Bridge, the HART variables that InnovativeField Organizer collects in real time from field devices using HART command 3 or 9 can be sent to an OPC client system such as the PIMS (host computer).

If a DOPC IV controller is used, by connecting InnovativeField Organizer to the DEO control network, the collected HART variables can be transferred to DOPC IV variables and used by Harmonas-DEO as data in DCS operation. Furthermore, if Harmonas-DEO R510 or later and DOPC IV R5.0 or later are used, valve travel data retained by a HART-compatible Smart Valve Positioner model AVP300 or AVP700 can be displayed on the faceplate of a regulatory control point or an analog output (AO) point.

Notes

- One Harmonas-DEO system can include only one InnovativeField Organizer.
- To use InnovativeField Organizer connected to the DEO control network so that the collected HART variables can be used as Harmonas-DEO data, InnovativeField Organizer must be installed on a standard workstation sold by Azbil.




Figure 9. Configuration for Harmonas-DEO

System configuration which is independent from DCS

1. HNU (HART Network Unit)

By using a HART Network Unit (HNU), HART-compliant digital field devices can be connected to InnovativeField Organizer regardless of the type of the DCS.

The AI/AO terminals or relay terminals of the DCS are connected to the HNU with analog wiring, and an Ethernet device communication network is used to link the HNU to InnovativeField Organizer.

With the OPC communication function of the HART Variable Bridge, the HART variables that InnovativeField Organizer collects in real time from field devices using HART command 3 or 9 can be sent to an OPC client system such as the PIMS (host computer).




Figure 10. System configuration which is independent from DCS

For examples of connection between an HNU and DCS I/O devices from various vendors, please contact us.

2. HART modem

Commercially available HART modems can be used as the communication interface between InnovativeField Organizer and HART devices.

Connect the HART modem to the COM port of InnovativeField Organizer, and the HART modem banana plugs to the DCS's analog input and output lines. By connecting multiple HART modems to InnovativeField Organizer, up to 4 HART devices can be connected.

This portable device diagnostic tool can be used to check device operation before InnovativeField Organizer is installed.

Notes

- A HART modem connection cannot coexist with an Ethernet connection to a BU100H HART I/O module or HART Network Unit (HNU) in the same InnovativeField Organizer system.
- To connect a HART communicator if a HART modem connection is established, disable HART communication (periodic data collection) using InnovativeField Organizer before connecting the HART communicator.
- If multiple HART modems are connected to InnovativeField Organizer, the same number of interfaces (USB) as the number of connected modems is needed.




Figure 11. System configuration via a HART modem

Note: For a HART modem connection, a commercially available HART modem is needed. The computer must have an interface (USB port) for a HART modem connection. Azbil Corporation has verified compatibility with the HART modems listed below. For connection to modems other than the following, contact the azbil Group.

- For positioner models AVP302/202/102 that do not have a HART certification label on the main unit, please use the Bell202 modem provided by M-System Co.
- Please note that not all computer platforms and field devices are guaranteed to be compatible with the tested modems.
- VIATOR USB HART Interface made by Pepperl+Fuchs. (Note that an RS232-USB converter cannot be used.)
- Bell202 modem (model: COP-HU) by M-System Co.
- USB HART Modem, Isolated (model: HM-USB-ISO) by ProComSol, Ltd.

System Specifications

Table 2. Application specifications

Maximum number of supported devices	3000 devices/system
-------------------------------------	---------------------

Throughput performance of HART Variable Bridge

Function of HART Variable Bridge	Throughput performance
Transfer HART variables to DOPC IV	500 variables/second
OPC Server to upper layer computer	2000 variables/second

Transfer speed of HART variables to DOPC IV of HART Variable Bridge

Type of HART device	HART variable	Transfer period
AVP300 series	Travel	1 s ^{*1}
	Input, EPM (Drive Signal)	5 s
AVP700 series	Position (valve travel following flow type conversion)	1 s ^{*1}
	Input, Drive Signal, Po1 (1st output air pressure), Po2 (2nd output air pressure), Ps (supply air pressure), Pn (nozzle back pressure)	5 s
Other HART devices	All variables	10 s

*1. The valve opening indicator on the faceplate on DOSS (DCS Operator Station) updates every second.
Note that it takes a few seconds to be reflected to the valve opening indicator after changing OP value.

Configurable read period of HART Variable Bridge by OPC Client

Type of HART device	HART variable	Fastest period
AVP300 series	Travel, Input, EPM (Drive Signal)	3 s
	Temperature, Stick Slip Alarm Counts, Stick Slip X, Stick Slip Y	60 s
AVP700 series	Position (valve travel following flow type conversion), Input, Drive Signal, Po1 (1st output air pressure), Po2 (2nd output air pressure), Ps (supply air pressure), Pn (nozzle back pressure)	3 s
	Temperature	60 s
Other HART devices	All variables	5 s

* Please use cash read to reduce OPC Server load of HART Variable Bridge.

Table 3. Computer platform operating environment (if InnovativeField Organizer is not connected to the DEO control network)

Operating system ^{*1}	Windows 10 Pro 64 bit Windows 11 Pro 64 bit
CPU (recommended specs)	Intel Xeon processor E3-1230 v5 (3.40 GHz / 8 MB 4-core) or higher
Memory	8GB or more (4GB in case of use with HART modem connection only)
Free space of C drive	At least 20 GB
USB	1 port or more (for HART modem connection)
Size of HDD/SSD	1 TB or more (at least 500GB) (250GB in case of use with HART modem connection only)
External media	DVD-RAM drive
Network	Wired or wireless LAN One or more physical network adapters ^{*2}
Display resolution	1024 × 768 (XGA) min. 1920 × 1200 (WUXGA) is recommended for display of online diagnostic window sets.

*1 Operation with these operating systems is guaranteed as of August 2023. Since the operating systems are continually updated, future operation cannot be guaranteed.

*2 Wired LAN is required. If the computer is connected to a HART modem, wireless LAN can be used.

Note: Any anti-virus software can not be installed.

Note: To use the report function, Microsoft Excel (not included) is necessary.

If you purchase an Office 2019 PC, please select Office for business, not for personal use.

Please purchase one of the following programs.

Operating system	Required product
Windows 10 Pro 64 bit Windows 11 Pro 64 bit	Microsoft Excel 2019 32 bit / 64 bit, Microsoft Excel 2021(LTSC) 32 bit / 64 bit

Note: Do not install any software other than software specified by Azbil Corporation that is required for running InnovativeField Organizer.

Note: There are rules for the settings of the user account on the PC on which InnovativeField Organizer is installed. Please contact us for details.

Note: There are rules for the IP addresses used by the devices that make up the system. The system will not operate in an environment where these IP addresses cannot be used. Please contact us for details.

Note: When installing or upgrading InnovativeField Organizer, do not connect a writable removable drive (external HDD/SSD, etc.). There is no problem with connecting a DVD drive.

Specifications

Table 4. Standard workstation specifications

Note: If InnovativeField Organizer is connected to the DEO control network, and if HART Variable Bridge is used to utilize the collected HART variables in Harmonas-DEO, a workstation of the model shown below is required.

Item	Specifications		Remarks
	HD-4PB3-1HESSAE		
OS	Windows 10 IoT Enterprise 2021 LTSC		*1
CPU	Intel® Core™ i5-12500 Processor (3.9 GHz, 6 cores, 18 MB)		
Memory	16 GB DDR5 SDRAM (4400 MHz, ECC, unbuffered, 16 GB × 1)		Standard config.
Sound function	Standard equipment		Standard config.
Internal storage	HDD	500 GB (SW RAID1 mirroring)*2	Standard config.
	SD card reader-writer	HP SD media card reader	Standard config.
Interface	LAN port	4 ports	Standard config.
	USB port	Front: USB Type-C Speed and Charge × 1 (5 V, 3 A)	Standard config.
		Rear: USB Type-A × 4	
	Display	DisplayPort × 2	Standard config.
Serial port	RS232C port × 1 (rear)	Standard config.	
Operation device	Keyboard	USB slim standard keyboard (English version 104 keyboard)	Standard config.
	Mouse	Optical USB mouse	Standard config.
Power	Voltage	100-240 V AC ±10 %	
	Frequency	50-60 Hz	
	Instant power outage	10 ms	
	Power consumption	Max.: 450 W, normal: 90 VA or less	
Dimensions (W × D × H)	384 × 308 × 100 mm		For horizontal installation
Footstand dimensions (W × D × H)	150 × 200 × 28 mm		For vertical installation
Mass	Approx. 6 kg		
Recommended replacement cycle (main unit)	5 years		
Recommended replacement cycle (parts, accessories)	HDD	3 years	
	Keyboard	3 years	
	Mouse	3 years	

*1. When the product is shipped, the C drive is formatted to have a maximum capacity of about 446 GB.

*2. The OS is an embedded licensed version. Therefore, it can be used only with an Azbil system like Harmonas-DEO.

License System

InnovativeField Organizer

Table 5. InnovativeField Organizer base license

	Model number	Description
License for number of device connection	AZ-2AMS6XE00	InnovativeField Organizer R6x base license 16TAG entry edition
	AZ-2AMS6XE01	InnovativeField Organizer R6x base license 100TAG
	AZ-2AMS6XE03	InnovativeField Organizer R6x base license 300TAG
	AZ-2AMS6XE05	InnovativeField Organizer R6x base license 500TAG
	AZ-2AMS6XE10	InnovativeField Organizer R6x base license 1000TAG
	AZ-2AMS6XE20	InnovativeField Organizer R6x base license 2000TAG
	AZ-2AMS6XE30	InnovativeField Organizer R6x base license 3000TAG
	AZ-2AMS6XEMS	InnovativeField Organizer R6x Modem license set

Table 6. InnovativeField Organizer AVP limited license for PLUG-IN

	Model number	Description
License for number of AVP connection	AZ-2AMS6XEV1	InnovativeField Organizer R6x license AVP only 16TAG entry edition
	AZ-2AMS6XEV2	InnovativeField Organizer R6x license AVP only 25TAG
	AZ-2AMS6XEV3	InnovativeField Organizer R6x license AVP only 50TAG
	AZ-2AMS6XEV4	InnovativeField Organizer R6x license AVP only 100TAG
	AZ-2AMS6XEV5	InnovativeField Organizer R6x license AVP only 200TAG
	AZ-2AMS6XEV6	InnovativeField Organizer R6x license AVP only 300TAG
	AZ-2AMS6XEV7	InnovativeField Organizer R6x license AVP only 500TAG
	AZ-2AMS6XEV8	InnovativeField Organizer R6x license AVP only 750TAG
	AZ-2AMS6XEV9	InnovativeField Organizer R6x license AVP only 1000TAG

Table 7. InnovativeField Organizer DCS connection license

	Model number	Description
License for DCS connection	AZ-2AMS6XE-A	InnovativeField Organizer R6x DCS connect license for APS/TDCS
	AZ-2AMS6XE-C	InnovativeField Organizer R6x DCS connect license for DEO R410 or later
	AZ-2AMS6XE-Y	InnovativeField Organizer R6x DCS connect license for Other DCS

Table 8. InnovativeField Organizer TAG extension license

After InnovativeField Organizer is installed, this license is used to increase the number of connected devices.

	Model number	Description
License for number of device extension	AZ-2AMS6XEP1	InnovativeField Organizer R6x TAG extension license 16to100
	AZ-2AMS6XEP2	InnovativeField Organizer R6x TAG extension license 100to300
	AZ-2AMS6XEP3	InnovativeField Organizer R6x TAG extension license 300to500
	AZ-2AMS6XEP4	InnovativeField Organizer R6x TAG extension license 500to1000
	AZ-2AMS6XEP5	InnovativeField Organizer R6x TAG extension license 1000to2000
	AZ-2AMS6XEP6	InnovativeField Organizer R6x TAG extension license 2000to3000

Table 9. InnovativeField Organizer AVP limited extension license

After InnovativeField Organizer is installed, this license is used to increase the number of connected AVPs.

	Model number	Description
License for number of AVP extension	AZ-2AMS6XEW1	InnovativeField Organizer R6x for AVP limited TAG extension license 16to25
	AZ-2AMS6XEW2	InnovativeField Organizer R6x for AVP limited TAG extension license 25to50
	AZ-2AMS6XEW3	InnovativeField Organizer R6x for AVP limited TAG extension license 50to100
	AZ-2AMS6XEW4	InnovativeField Organizer R6x for AVP limited TAG extension license 100to200
	AZ-2AMS6XEW5	InnovativeField Organizer R6x for AVP limited TAG extension license 200to300
	AZ-2AMS6XEW6	InnovativeField Organizer R6x for AVP limited TAG extension license 300to500
	AZ-2AMS6XEW7	InnovativeField Organizer R6x for AVP limited TAG extension license 500to750
	AZ-2AMS6XEW8	InnovativeField Organizer R6x for AVP limited TAG extension license 750to1000

Table 10. InnovativeField Organizer optional license

Model number	Description
AZ-2AMS6XEO1	InnovativeField Organizer R6x Optional license for HART Variables Historian
AZ-2AMS6XEO2	InnovativeField Organizer R6x Optional license for HART Variables Bridge

* If both the HART Variables Bridge and HART Variables Historian are used in a system, set the HART Variables Historian to collect all variables on a 60-second or longer cycle.

PLUG-IN Valstaff

Table 11. PLUG-IN Valstaff base license

	Model number	Description
License for number of device connection	AZ-2AMV6XE01	PLUG-IN Valstaff R6x license 16TAG entry edition
	AZ-2AMV6XE02	PLUG-IN Valstaff R6x license 25TAG
	AZ-2AMV6XE05	PLUG-IN Valstaff R6x license 50TAG
	AZ-2AMV6XE10	PLUG-IN Valstaff R6x license 100TAG
	AZ-2AMV6XE20	PLUG-IN Valstaff R6x license 200TAG
	AZ-2AMV6XE30	PLUG-IN Valstaff R6x license 300TAG
	AZ-2AMV6XE50	PLUG-IN Valstaff R6x license 500TAG
	AZ-2AMV6XE75	PLUG-IN Valstaff R6x license 750TAG
	AZ-2AMV6XEA0	PLUG-IN Valstaff R6x license 1000TAG

Table 12. PLUG-IN Valstaff DMS connection license

	Model number	Description
License for DMS connection	AZ-2AMV6XE-A	PLUG-IN Valstaff R6x DMS connect License for InnovativeField Organizer
	AZ-2AMV6XE-B	PLUG-IN Valstaff R6x DMS connect License for PRM

Table 13. PLUG-IN Valstaff TAG extension license

After PLUG-IN Valstaff is installed, this license is used to increase the number of connected devices.

	Model number	Description
License for number of device extension	AZ-2AMV6XEP1	PLUG-IN Valstaff R6x TAG extension license 16to25
	AZ-2AMV6XEP2	PLUG-IN Valstaff R6x TAG extension license 25to50
	AZ-2AMV6XEP3	PLUG-IN Valstaff R6x TAG extension license 50to100
	AZ-2AMV6XEP4	PLUG-IN Valstaff R6x TAG extension license 100to200
	AZ-2AMV6XEP5	PLUG-IN Valstaff R6x TAG extension license 200to300
	AZ-2AMV6XEP6	PLUG-IN Valstaff R6x TAG extension license 300to500
	AZ-2AMV6XEP7	PLUG-IN Valstaff R6x TAG extension license 500to750
	AZ-2AMV6XEP8	PLUG-IN Valstaff R6x TAG extension license 750to1000

External Storage

Automatic backup and external storage is available for control valve diagnostic data collected by PLUG-IN Valstaff operating in InnovativeField Organizer.

If PLUG-IN Valstaff is used, be sure to install an external storage device when introducing the system.

If diagnostic data is backed up to the external storage, the data can be accessed from other PCs simply by connecting the external storage, which is convenient for analysis.

For automatic back-up, the user can use the following operability-confirmed external storage media.

- Tandberg Data Inc.
RDX QuikStor External USB Docking Station
Model: 8782
- Tandberg Data Inc.
RDX QuikStor Cartridge (Memory: 1 TB)
Model: 8586

Tandberg Data Inc. web site:

<http://www.tandbergdata.com/us/>

Notes



When automatic backup to an external storage device is used, it is necessary to keep the PC safe. However, do not install anti-virus software on the PC used for InnovativeField Organizer. (The installation of anti-virus software specified by Azbil on standard PCs sold by Azbil is excluded.) Check for viruses remotely from another PC.

Also, if an external storage device whose operation we have not checked is used, Azbil Corporation cannot guarantee its operation or the integrity of the data. If the lack of a guarantee is acceptable and an external storage device which we have not checked is used, please use a device that meets the following conditions at a minimum.



- No special software is required to operate the device (do not install any software other than what is specified by Azbil Corporation on the PC used for InnovativeFieldOrganizer).
- This device does not incorporate a security function.

About icons for safety precautions










The safety precautions described in this document are indicated by the following icons.

	WARNING	Warnings are indicated when mishandling this product might result in death or serious injury.
	CAUTION	Cautions are indicated when mishandling this product might result in minor injury to the user, or only physical damage to the product.

■ Example

	The indicated action is prohibited.
	Be sure to follow the indicated instructions.

■ Safety precautions

 CAUTION	
	Do not touch electrically charged parts such as the power supply terminals. Doing so may result in an electric shock.
	Back up data and check for viruses regularly. Failure to do so may result in corrupted data or program malfunction.
	Do not install any anti-virus software into this PC. Check for viruses remotely from another PC.
	When using the loop check tool, exit these other tools first. <ul style="list-style-type: none"> • Vendor DTM • Device Description • PLUG-IN Valstaff • Device Watcher The loop check tool may operate in unexpected ways.
	Before executing an AI check, stop programs such as control programs and interlock programs. Failure to do so may change the input value for the DCS, resulting in an unexpected operation.
	Before executing an AO check, stop programs such as control programs and interlock programs. Also stop programs in the case of a DCS that is not made by Azbil Corporation. Otherwise, since an input value is written to the DCS, an unexpected operation may occur.
	Before connecting the HART modem, inform operators in the control room that devices will be operate. Unexpected device behavior can injure workers.
	Before using PLUG-IN Valstaff online while devices are operating, please make sure that HART communication will not affect the host control system.

- InnovativeField Organizer and Valstaff are trademarks of Azbil Corporation.
- FOUNDATION™ is a trademark of FieldComm Group.
- HART® is a registered trademark of FieldComm Group.
- Windows 10 Pro and Excel are registered trademark or trademark of Microsoft Corporation in the United States and other countries.
- Other product names, model nos., and company names may be trademarks of the respective company.

Please read "Terms and Conditions" from the following URL before ordering and use.

<https://www.azbil.com/products/factory/order.html>

Specifications are subject to change without notice.

The logo for Azbil Corporation, featuring the word "azbil" in a bold, lowercase, sans-serif font.

Azbil Corporation

Advanced Automation Company

1-12-2 Kawana, Fujisawa
Kanagawa 251-8522 Japan
URL: <https://www.azbil.com/>

1st edition: October 2023
2nd edition: March 2024

No part of this publication may be reproduced or duplicated without the prior written permission of Azbil Corporation.