


**MagneW FLEX+/PLUS+
Electromagnetic Flowmeter
Converter**

Model MGG10C/MGG14C

User's Manual



Copyright, Notices and Trademarks

© 2007-2023 Azbil Corporation. All Rights Reserved.

While the information in this manual is presented in good faith and believed to be accurate, Azbil Corporation disclaims any implied warranty of merchantability or fitness for a particular purpose and makes no express warranty except as may be stated in its written agreement with and for its customer.

In no event shall Azbil Corporation be liable to anyone for any indirect, special or consequential damages. This information and specifications in this document are subject to change without notice.

MagneW is a trademark of Azbil Corporation in Japan and/or other countries.

HART® is a registered trademark of FieldComm Group.

Safety

About this manual

This manual contains information and warnings that must be observed to keep the model MGG10C/MGG14C MagneW FLEX+/PLUS+ Flowmeter operating safely. Correct installation, correct operation and regular maintenance are essential to ensure safety while using this device.

For the correct and safe use of this flowmeter, it is essential that both operating and service personnel follow generally accepted safety procedures in addition to the safety precautions specified in this manual.

Conventions Used in This Manual

- The safety precautions explained below aim to prevent injury to you and others, and to prevent property damage.



WARNING

Warnings are indicated when mishandling this product may result in death or serious injury.



CAUTION

Cautions are indicated when mishandling this product may result in minor injury or property damage only.

- In describing the product, this manual uses the icons and conventions listed below.



Indicates that caution is required in handling.



The indicated action is prohibited.



Be sure to follow the indicated instructions.

Safety messages

Carefully read this section before installing or operating this device.

WARNING



ELECTRIC SHOCK HAZARD! Turn the power supply OFF before opening the converter cover.

CAUTION



Switch the control equipment to manual control before terminating flowmeter operation and shutting off the output to the control equipment. This action prevents the power shut-off from directly affecting the control equipment.



Install the flowmeter in a location with an ambient temperature of -25 °C to 60 °C (-13 °F to 140 °F) and an ambient humidity of 5 to 100% RH to prevent equipment malfunction or output errors.



Do not install the flowmeter near high-current power lines, motors or transformers to prevent damage from electromagnetic induction, which can cause equipment malfunction or output errors.



Do not install the flowmeter in a location subject to direct sunlight, wind, rain, severe vibration, or in a highly corrosive atmosphere. The converter and detector can be damaged.



Be sure to ground the welding power transformer when welding near the flowmeter to avoid output errors.



DO NOT use the flowmeter to ground a welder. It can damage the flowmeter.

Cautions to Disposal of Electrical and Electronic Equipment

Disposal of Electrical and Electronic Equipment (for Environmental Protection)

This is an industrial product subject to the WEEE Directive.

Do not dispose of electrical and electronic equipment in the same way as household waste.

Old products contain valuable raw materials and must be returned to an authorized collection point for correct disposal or recycling.



MagneW FLEX+/PLUS+ Electromagnetic Flowmeter CE Conformity Supplement

CE CONFORMITY: This product is in conformity with the protection requirements of the following European Council Directive: **2014/30/EU**, the EMC Directive and **2014/35/EU**, Low Voltage Directive. Conformity of this product with any other “CE Mark” Directive(s) shall not be assumed.

EMC Directive/Standard	PC	Conformity	Notes
ELECTROMAGNETIC COMPATIBILITY: 2014/30/EU , EMC Directive			
EMISSIONS: EN61326-1:2013, Gr.1 Class A , Electrical equipment for measurement, control and laboratory use			
EN 55011:2009/A1: 2010, Gr.1, Class A , Industrial Control Equipment, Radiated electromagnetic disturbances 30MHz - 1000MHz,		30MHz-230MHz quasi-peak limit 40dB(uV/m) at 10m 230MHz-1000MHz quasi-peak limit 47dB(uV/m) at 10m	1
IMMUNITY: EN61326-1:2013 , Electrical equipment for measurement, control and laboratory use, EN 61326-2-3:2013 , Particular requirements		PERFORMANCE: Unless otherwise noted, the performance of this product, at the specified levels of electromagnetic interference, is within the specifications for for “Performance Under Rated Conditions.”	
EN 61000-4-2: 2009 , ESD, Electrostatic Discharge	B B	4 kV Contact 8kV Air	
EN 61000-4-3:2006 + A2:2010 , Radio-frequency electromagnetic field, amplitude modulated 80 -2700 MHz	A	1kHz, AM80% 10 V/m (80 -1000 MHz) 3V/m (1.0 -2.0 GHz) 1V/m (2.0 -2.7 GHz)	1
EN 61000-4-4:2012 , Electrical Fast Transients/Burst	B	1kV	1
EN 61000-4-5: 2006 , Surge	B	1kV	1
EN 61000-4-6:2009 , Conducted Radio-frequency, 150 KHz - 80 MHz	A	3V	1
EN 61000-4-8: 2010 , Power frequency magnetic field	A	30A/m 50Hz	1
EN 61000-4-11:2004 , Voltage Dip/short interruptions	B C C C	0.5, 1cycle 0% (100%) 10/12 cycle 40% (60%) 25/30 cycle 70% (30%) 250/300 cycle 0% (100%)	

NOTES:

PC = Performance Criteria

1. Twist pair cables required for all I/O interface circuits.

In case of remote model,two core double shield cable in metal conduit pipe is required for the input line in connection with detector.

Performance Criteria: Immunity includes the tests and severity levels specified in EN 61326-1-2013 and EN 61326-2-3-2013.

LV Directive	Conformity
LOW VOLTAGE DIRECTIVE: 2014/35/EU	EN 61010-1: 2010+A1: 2019 , Safety requirements for electrical equipment for measurement, control and laboratory use Part 1: General requirements

MagneW FLEX+/PLUS+ Electromagnetic Flowmeter Documentation Supplement

1. Mains supply

The symbol for a.c. or d.c. on the name plate is as follows:

 for a.c. power supply

 for d.c. power supply

2. Fuse marking



The fuse cannot be replaced by the operator.

Fuse rating and electric characteristics are as follows:

Fuse rating: Voltage 250V


Current 3A

Manufacturer type: 239003 (LITTEL FUSE)


3. Grounding (Earthing)

Protective grounding (earthing) should be connected as shown in Operator's Manual.

The MagneW FLEX+/PLUS+ has protective grounding (earthing) terminals in the terminal box and on the external surface of its casing (see figure).



Remote models



Integral models

An external switch or circuit-breaker must be installed near the MagneW FLEX+/PLUS+ on the power line.

4. Equipment operation



Power line is connected to commercial power. The terminal cover must not be opened when power is on.

Table of Contents

Chapter 1: Introduction

MagneW FLEX+/PLUS+ Flowmeter	1-1
Main components.....	1-1
Analog output and digital output.....	1-3
System configuration for analog output (4 to 20 mA DC output)	1-4
System configuration WITHOUT the communication function.....	1-5
System configuration WITH the HART communication function with the internal power supply.....	1-6
System configuration WITH the SFC or HART communication function with the external power supply.....	1-7
System Configuration for Digital Output (DE Output).....	1-8
System configuration.....	1-8
Approval of this Device.....	1-10

Chapter 2: Installation

Site selection.....	2-1
Unpacking and storage	2-3
Installation options.....	2-4
Changing the orientation of the converter.....	2-5
Wiring	2-6
Integral wiring - 1 (1-contact input and 1- contact output).....	2-8
Integral wiring - 2 (2-contact input).....	2-9
Integral wiring - 3 (2-contact output).....	2-10
Remote wiring - 1 (1-contact input and 1- contact output)	2-11
Remote wiring - 2 (2-contact input)	2-12
Remote wiring - 3 (2-contact output).....	2-13
Grounding	2-14
Signal and excitation cable specifications.....	2-14
Signal and excitation cable wiring	2-16
Wiring cable.....	2-17
Wiring	2-18
Setting write protection.....	2-21
Setting the communication via the HART.....	2-23
Setting the empty detection function	2-24
Setting the communication via the SFC	2-25
Connecting power	2-26

Chapter 3: Operation

Start-up.....	3-1
Shut down	3-1
Using the display panel	3-2
Using the infrared touch sensor keys.....	3-3

Chapter 4: Using the display panel

About modes	4-1
MEASURING MODE.....	4-4
LCD display flow.....	4-5
Entering BASIC SETUP MODE	4-11

Table of Contents

Setting the TAG NO.	4-12
Default setting	4-12
Setting range	4-12
Damping time constant	4-13
Default setting	4-13
Setting range	4-13
Auto zero	4-14
Flow counter - Reset value	4-16
Flow counter - Resetting	4-17
Detector data.....	4-18
Default setting	4-18
Setting the Number of Dummy Detectors	4-20
Default setting	4-20
Setting range	4-20
Flow rate range	4-21
Setting range	4-21
Flow rate indication	4-22
Default setting	4-22
Setting range	4-22
Entering ENGINEERING / ADVANCED / MAINTENANCE MODE.....	4-23
Entering ENGINEERING MODE.....	4-23
Entering ADVANCED MODE.....	4-23
Entering MAINTENANCE MODE.....	4-24
Selecting functions	4-25
Relations for setting function FXXXX	4-27
Range functions	4-30
Single range.....	4-30
Normal direction automatic dual range	4-31
Normal direction, external switching dual range	4-32
Normal/reverse automatic switching range.....	4-33
[Built-in counter function]	4-35
[Contact input function]	4-36
[Contact output function].....	4-37
Flow rate range	4-40
Setting range	4-40
Setting hysteresis	4-42
Selecting the current output method for dual range.....	4-43
Setting / Changing the preset value of the built-in flow counter	4-44
Specific gravity.....	4-45
Pulse weight	4-46
Setting the pulse width.....	4-47
Setting high and low limit alarms	4-49
Setting a 2-stage flow rate alarm	4-50
Selecting fail-safe mode for the analog output.....	4-52
Default setting	4-52
Setting range	4-52
Selecting fail-safe mode for the pulse output.....	4-53
Default setting	4-53
Setting range	4-53
Setting the contact output status	4-54
Damping time constant	4-56
Default setting	4-56
Setting range	4-56

Table of Contents

Manual zeroing.....	4-57
Important.....	4-57
How to set.....	4-57
Setting moving average	4-58
Default setting	4-58
Setting range	4-58
Auto spike cut function.....	4-60
Default setting	4-60
Manual spike cut function	4-61
Default setting	4-61
Setting range	4-61
Coefficient of compensation.....	4-62
Setting the drop-out	4-63
Setting the low flow cut	4-64
Setting decimal place.....	4-65
Change the excitation frequency	4-66
Setting the analog output limit	4-67
Change the flow direction	4-68
Error history check/clear	4-69

Chapter 5: Maintenance and Troubleshooting

Function check	5-2
Input and output signal loop check	5-2
Analog output check.....	5-3
Default setting	5-3
Setting range	5-3
Pulse output check.....	5-4
Default setting	5-4
Setting range	5-4
Contact input/output loop check.....	5-5
Default setting	5-5
Setting range	5-5
Excitation current check.....	5-8
Simulated signal by the calibrator	5-9
Preparation	5-9
Troubleshooting.....	5-10
Errors at startup.....	5-11
Operation errors	5-12
Error messages	5-13
Error codes for critical problems	5-13
Error codes for non-critical problems	5-14
Safety precautions.....	5-15
Operating precautions.....	5-15
Examples of symbol.....	5-15
Structure and functions of SFC.....	5-16

List of Figures

Figure 1-1	Integral System.....	1-1
Figure 1-2	Remote System.....	1-2
Figure 1-3	System configuration of analog output WITHOUT communication function.....	1-5
Figure 1-4	System configuration of with the HART communication with internal power supply.....	1-6
Figure 1-5	System configuration for analog output WITH the communication function (example setup).....	1-7
Figure 1-6	System configuration for digital output.....	1-8
Figure 1-7	Parts of the converter	1-9
Figure 1-8	System configuration	1-11
Figure 2-1	Integral installation.....	2-4
Figure 2-2	Wall mounted remote installation	2-4
Figure 2-3	Pipe mounted remote installation.....	2-5
Figure 2-4	Integral converter terminal block	2-8
Figure 2-5	Integral converter terminal block	2-9
Figure 2-6	Integral converter terminal block	2-10
Figure 2-7	Remote converter terminal block	2-11
Figure 2-8	Remote converter terminal block	2-12
Figure 2-9	Remote converter terminal block	2-13
Figure 2-10	Cable usage ranges.....	2-14
Figure 2-11	Signal Cable Dimensions	2-15
Figure 2-12	Excitation Cable Dimensions.....	2-15
Figure 2-13	Signal and excitation cable construction.....	2-15
Figure 2-14	Detector to converter wiring diagram	2-16
Figure 2-15	Wiring diagram for current output	2-18
Figure 2-16	Wiring diagram for pulse output	2-19
Figure 2-17	Switch locations on main card	2-19
Figure 2-18	Wiring diagram for contact input.....	2-20
Figure 2-19	Wiring diagram for contact output.....	2-20
Figure 2-20	Switch locations on main card	2-22
Figure 2-21	Write protection switch positions.....	2-22
Figure 2-22	Switch locations on main card	2-23
Figure 2-23	HART communication switch positions	2-23
Figure 2-24	Switch locations on main card	2-24
Figure 2-25	Empty detection function switch positions	2-24
Figure 2-26	Switch locations on main card	2-25
Figure 2-27	SFC communication switch positions.....	2-25
Figure 2-28	Name plate	2-26
Figure 3-1	Start-up display	3-1
Figure 3-2	Display panel.....	3-2
Figure 3-3	Touch sensor keys.....	3-3
Figure 3-4	Using the touch sensor keys.....	3-3
Figure 4-1	Single range.....	4-30
Figure 4-2	Normal direction automatic dual range.....	4-31
Figure 4-3	Normal/reverse automatic switching range.....	4-33
Figure 4-4	2-stage flow rate alarm output.....	4-39
Figure 4-5	Selecting the current output method for dual range.....	4-43

List of Tables

Table 2-1 Remote converter terminal descriptions (1-contact input & 1-contact output)	2-8
Table 2-2 Remote converter terminal descriptions (2-contact input)	2-9
Table 2-3 Remote converter terminal descriptions (2-contact output)	2-10
Table 2-4 Remote converter terminal descriptions (1-contact input & 1-contact output)	2-11
Table 2-5 Remote converter terminal descriptions (2-contact input)	2-12
Table 2-6 Remote converter terminal descriptions (2-contact output)	2-13
Table 2-7 Write Protection Levels	2-21
Table 3-1 Touch Sensor key Functions	3-4
Table 3-2 Default settings	3-5
Table 4-1 Mode functions	4-2
Table 4-2 Output selection	4-37
Table 5-1 Startup Errors	5-11
Table 5-2 Operation Errors	5-12
Table 5-3 Critical Errors	5-13
Table 5-4 Non-critical	5-14

List of Tables

Chapter 1: Introduction

This chapter contains an overview of the model MGG10C/MGG14C MagneW FLEX+/PLUS+ Flowmeter. It provides definitions for all the major parts of the converter.

MagneW FLEX+/PLUS+ Flowmeter

Thank you for purchasing the Azbil Corporation model MGG10C/MGG14C Flowmeter. This system features:


- Digital panel display
- Intuitive, versatile operator interface with large characters and backlit liquid crystal display (LCD)
- I/O Capacity

Main components

The model MGG10C/MGG14C MagneW FLEX+/PLUS+ Flowmeter consists of a detector and a converter which operate on the principles of Faraday's law.

Integral - The converter is mounted directly on the detector and they are installed as an integrated unit on the fluid pipe.

Remote - The converter and detector are installed separately and connected together via cables






Figure 1-2 Remote System

Analog output and digital output

Introduction

The choice of either an analog output or digital output system configuration depends on whether or not you want to use the digitally enhanced (DE) communication mode.

Analog output (4 to 20 mA DC output)

In analog mode, the flowmeter sends the instantaneous flow rate as a proportional 4 to 20 mA output signal to a controller or a recorder in the control system.

Digital output (DE output)

A flowmeter in the DE mode can communicate in a direct digital fashion with Azbil Corporation or Honeywell DCS system. The digital signal can include flow rate, flowmeter database, and self-diagnostics.

Switching output mode

The analog/digital output mode is selectable.

System configuration for analog output (4 to 20 mA DC output)

Introduction

In the analog mode, the flowmeter can be configured with or without SFC communications.

WITHOUT the communication function

The DC power supply that transmits the analog output, when the flowmeter is used without SFC communications, is built into the product.

The analog output signal is transmitted directly to the host control system.

- Analog output range: 0.8 to 22.4 mA (-20 to +115%)
- Resistive load: 0 to 600 Ω

WITH HART communication function

The DC power supply that transmits the analog output and HART communication, when the flowmeter is used with the HART communications, is built into the product.

- Analog output range: 3.2 to 22.4 mA (-5 to +115%)
- Resistive load: 0 to 600 Ω

WITH the communication function (SFC or HART)

When the flowmeter is used in the analog mode with SFC communications, an external power supply (DC power) and external resistive load (minimum 250 Ω) is required. HART communication is also available with the external power supply and resistive load.

- Analog output range: 3.2 to 22.4 mA (-5 to +115%)
- DC power: 16 to 45V DC
- Maximum value of external resistive load is calculated:

$$\text{Maximum resistive load } (\Omega) = \frac{\text{External power supply for communication} - 8.5V}{0.025}$$


CAUTION



For systems WITH the SFC communication function, failure to install the external power supply and the external resistive load, will prevent the analog output from being accepted on the receiving instrument side. Be sure to install the external power supply and the external resistive load as specified.

System configuration WITHOUT the communication function

Figure 1-3 shows a sample system configuration without the communication. In this system, the device measures the flow rate and outputs analog 4 to 20 mA DC signal to the Host Control System.




Smart Electromagnetic Flowmeter (device)

- Measures flow rate and outputs an analog signal.

System configuration WITH the HART communication function with the internal power supply

Figure 1-4 shows a sample system configuration in with the HART communication.



Smart Electromagnetic Flowmeter (device)

- Measures flow rate and outputs an analog signal.


HART Communicator:

- Communicate with the MagneW FLEX+/PLUS+ and configure the data of the MagneW FLEX+/PLUS+. For the HART communication by the HART 375 communicator, the necessary DD file needs to be downloaded.

System configuration WITH the SFC or HART communication function with the external power supply

Figure 1-5 shows a sample system configuration in which the instantaneous flow rate measured by the unit is output with a 4 to 20 mA DC analog signal.

In order to enable communications, a DC power supply and a resistance of 250Ω or more must be installed on the receiving side.



Smart Electromagnetic Flowmeter (device)

- Measures flow rate and outputs an analog signal instantaneous flow rate.

Smart Communicator (SFC):

- Communicates with the device to read data and change the device settings.
- The SFC version must be V7.0 or later.

HART Communicator:


- For the HART communications by the HART 375 communicator, the necessary DD file needs to be downloaded.

System Configuration for Digital Output (DE Output)

System configuration

Figure 1-5 shows a system configuration in which the flow rate measured by the unit, the database in the unit, and self-diagnostics are output using the DE (Digital Enhancement) protocol (rules for digital signal communication).

In this system, the DE protocol-based digital signal transmitted from the unit is output to the control system after conversion to an analog signal at the smart protocol converter (SPC). Or, the digital signal is directly transmitted to the control system, if it is capable of receiving the DE protocol-based signal directly.



Smart Electromagnetic Flowmeter (device)

Measures flow rate and outputs the instantaneous flow rate and unit self-diagnostics using a digital signal.

Smart protocol converter (SPC)

Converts the DE protocol-based digital signal into a 4 to 20 mA or 1 to 5 V DC analog signal for output.

Smart handy loader (SHL)

Used to change the SPC settings.

Smart communicator (SFC)

- Used to communicate with the device to read data and change the device settings.

PM100

- Simultaneously executes such functions as process control on the UCN, regulatory control, sequencing, calculation, and process input/output.

The converter consists of the components shown in the figure below.




Figure 1-7 Parts of the converter

Converter

- Converts electromotive force by the detector to the flow rate signal.
- Transmits the analog output or the digital output as the flow rate signal.

Data setting device (A)

- Displays the flow rate and the totalized value.
- The Data can be configured through the four infrared sensor keys.

Terminal box (B)

- Encloses the inputs/outputs terminals.
- Equipped with lightning arrestor.

Name plate (C)

- Indicates model numbers, product numbers and the detector factor (EX).

Tag number plate (D)

- Indicates the tag number as specified in the product order.

CAUTION



Do not apply over-voltage that exceed following lightning arrestor specification. The converter may be damaged.

- Power supply terminal: series mode 1kV, common mode 2kV
- Input/Output terminal: series mode 1kV, common mode 1kV

Approval of this Device

Overview

If the basic model number is MGG14C and 1/2 NPT wiring connection is selected and style code is selected as “N”, this device functions as an FM, non-incentive-approved model. In this case, the installation standards described in this section must be followed.

Installation of this device

FM Nonincendive model

THIS EQUIPMENT IS SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS(A, B, C, D), CLASS II/III, DIVISION 2, GROUPS (F, G), OR NON-HAZARDOUS LOCATIONS ONLY.



CAUTION



- Power supply and internal voltage of ordinary equipment to the earth shall not exceed AC250V 50/60HZ, DC250V in case of normal /formal conditions.
- Ambient temperature is from - 25 to 60C
- Process temperature is from -40 to 160C (Remote model).
- Process temperature is from -40 to 120C (Integral model)




Figure 1-8 System configuration

If an MGG18/19 detector is used with an MGG14C converter as an FM-approved nonincendive product, both the detector and the converter should be FM-approved nonincendive products.

If they are not, the MGG18/19 detector cannot be used as an FM-approved nonincendive product.

MEMO

Chapter 2: Installation

This chapter describes the installation and wiring procedures for the flowmeter.

 WARNING	
	ELECTRIC SHOCK HAZARD! DO NOT perform wiring work while the power is ON!

Site selection

When selecting an installation site for the flowmeter, observe the following safety measures:

 CAUTION	
	Install the flowmeter in a location with an ambient temperature of -25 °C to 60 °C (-13 °F to 140 °F) and an ambient humidity of 5 to 100% RH to prevent equipment malfunction or output errors.
	Do not install the flowmeter near high-current power lines, motors or transformers to prevent damage from electromagnetic induction, which can cause equipment malfunction or output errors.
	Be sure to ground the welding power transformer when welding near the flowmeter to avoid output errors.
	DO NOT use the flowmeter to ground a welder. It can damage the flowmeter.
	Do not install the flowmeter on the bridge or deck of the ship.
	When installing the flowmeter, follow the instructions before and install it appropriately. Otherwise, the flow meter may be damaged.
	When installing a flowmeter for trial operation or inspection work, install it appropriately as described above. Otherwise, the flow meter may be damaged.
	Check the polarity of each wire before starting trial operation or inspection. Read the Note in the wiring section carefully before you start working. If the polarity of wiring is incorrect, it may damage the equipment.



CAUTION



Be sure to return the flowmeter to an appropriate installation condition after installation of the flowmeter in trial operation or inspection work. Otherwise, the flow meter may be damaged.



Both integral and separate detectors become heavier as the aperture increases. Please be careful when carrying or lifting. Otherwise, there is a risk of injury or damage to the flow meter.

Unpacking and storage

The model MGG10C/MGG14C MagneW FLEX+/PLUS+ Flowmeter is a precision instrument and should be handled with care to prevent damage or breakage.

After unpacking the flowmeter, verify that the following items are included:

- Model MGG10C/MGG14C converter
- Standard accessories
- MagneW setting data sheet
- Test report

If you have questions regarding the technical specifications of the flowmeter, contact your nearest Azbil Corporation office or Azbil Corporation representative. When making an inquiry, make sure to provide the model number and product number of your flowmeter.

Storage

When storing the flowmeter before use:



- Store indoors at room temperature (77 °F or 25 °C) within a humidity level of approximately 65%.
- Store away from vibration or shock.
- Store the converter and detector in the original packaging.


In addition, when storing the converter after use:

- Attach the display cover, Terminal box cover and Waterproof gland(s) to prevent moisture ingress into the device.

Installation options

There are three ways to install the flowmeter. Integral systems are pre-assembled with the converter attached to the detector; remote systems allow you to install the converter in a remote location - wall mounted or mounted directly to a two inch (50.8 mm) pipe. The following illustrations provide dimensions for the three different installation options.





Changing the orientation of the converter

The model selected when the flowmeter is purchased determines the orientation of the display. It is possible, however, to change the horizontal or vertical orientation of the converter.

To change the orientation of the converter:

1. Remove the four screws holding the display cover to the main body and remove the cover.
2. Remove the four screws holding the display panel to the main body.
3. Remove and rotate the display panel to the required orientation.
4. Replace the four screws and tighten.
5. Rotate the display cover so that the openings for the LEDs are correctly aligned with the Display Panel.
6. Replace the four screws and tighten.

Wiring

 CAUTION	
	Use electrical tube and duct to prevent water entry and protect the cable from external damage.
	Be sure to use a waterproof gland at the conduit connection to prevent water entry inside of the terminal box and prevent output errors.
	Turn off the power supply before connecting the cables to the converter. The converter can be damaged. This type of damage is not covered by Azbil Corporation's warranty.
	Be sure to plug all unused conduit connections with a water tight plug.
	In case that a remote model is installed in a ship, the cables between the converter and detector must be covered with a flexible metal conduit.

 **WARNING****ELECTRIC SHOCK HAZARD!**

The AC POWER and XY terminals of the converter terminal block are high-voltage terminals.

Turn off the power supply, before connecting the cables to these terminals.

When connecting the cables to these terminals, lift the protective cover which indicates “WARNING” sign.

After connecting the cables to these terminals, return the protective cover to its original position.

Be sure to do the above.

 **CAUTION**

When connecting wires, check the polarity of each wire.

Read the Notes in this wiring section carefully before you start working.

If the polarity of wiring is incorrect, it may damage the equipment.



Check the polarity of each wire, before starting trial operation or inspection.

Read the Notes in this wiring section carefully before you start working.

If the polarity of wiring is incorrect, it may damage the equipment.



Be sure to return to the correct wiring for the normal use after the trial operation or inspection.

Read the Notes in this wiring section carefully before you start working.

If the wiring is incorrect, it may damage the equipment.

Integral wiring - 1 (1-contact input and 1- contact output)

To wire a remote system, the following cables are required:

- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Table 2-1 Remote converter terminal descriptions (1-contact input & 1-contact output)

Symbol		Description
I. OUT	+	Analog output
	-	
P. OUT	+	Pulse output
	-	
STATUS IN	+	Contact input
	-	
STATUS OUT	+	Contact output
	-	
E		Not used
⏏		Grounding (grounding resistance must be <100Ω)

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Integral wiring - 2 (2-contact input)

To wire a remote system, the following cables are required:

- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Table 2-2 Remote converter terminal descriptions (2-contact input)

Symbol		Description
I. OUT	+	Analog output
	-	
P. OUT	+	Pulse output
	-	
STATUS IN 1	+	Contact input 1
	-	
STATUS IN 2	+	Contact input 2
	-	
E		Not used
⏚		Grounding (grounding resistance must be <100 Ω)

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Integral wiring - 3 (2-contact output)

To wire a remote system, the following cables are required:

- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Table 2-3 Remote converter terminal descriptions (2-contact output)

Symbol		Description
I. OUT	+	Analog output
	-	
P. OUT	+	Pulse output
	-	
STATUS OUT 1	+	Contact output 1
	-	
STATUS OUT 2	+	Contact output 2
	-	
E		Not used
⏏		Grounding (grounding resistance must be <100 Ω)

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Remote wiring - 1 (1-contact input and 1- contact output)

To wire a remote system, the following cables are required:

- Signal cable - see page 2-14
- Excitation cable - see page 2-14
- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Figure 2-7 Remote converter terminal block

Table 2-4 Remote converter terminal descriptions (1-contact input & 1-contact output)

Symbol	Description	
A	Flow rate signal input	
B		
C		
SA		
SB		
I. OUT	+	Analog output
	-	
P. OUT	+	Pulse output
	-	
STATUS IN	+	Contact input
	-	
STATUS OUT	+	Contact output
	-	
X	Excitation	
Y		
E	Not used	
⊥	Grounding (grounding resistance must be <100Ω)	

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Remote wiring - 2 (2-contact input)

To wire a remote system, the following cables are required:

- Signal cable - see page 2-14
- Excitation cable - see page 2-14
- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Figure 2-8 Remote converter terminal block

Table 2-5 Remote converter terminal descriptions (2-contact input)

Symbol	Description	
A	Flow rate signal input	
B		
C		
SA		
SB		
I. OUT	+ -	Analog output
P. OUT	+ -	Pulse output
STATUS IN 1	+ -	Contact input 1
STATUS IN 2	+ -	Contact input 2
X		Excitation
Y		
E		Not used
⏏		Grounding (grounding resistance must be <100 Ω)

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Remote wiring - 3 (2-contact output)

To wire a remote system, the following cables are required:

- Signal cable - see page 2-14
- Excitation cable - see page 2-14
- Analog output cable - see page 2-18
- Pulse output cable - see page 2-19
- Contact input/output cable - see page 2-19

The following pages provide information on selecting the correct cables and wiring the system. A diagram of the terminal block for a remote system is shown below.




Figure 2-9 Remote converter terminal block

Table 2-6 Remote converter terminal descriptions (2-contact output)

Symbol	Description
A	Flow rate signal input
B	
C	
SA	
SB	
I. OUT	Analog output
+	
P. OUT	Pulse output
STATUS OUT 1	Contact output 1
STATUS OUT 2	Contact output 2
X	Excitation
Y	
E	Not used
⊥	Grounding (grounding resistance must be <100 Ω)

~ Note In case of DC24V and DC110V power supply, the symbol of the “L” and “N” of the power supply become “+” and “-”.

Grounding



CAUTION



ELECTRIC SHOCK HAZARD! Grounding is essential for accurate measurement. The grounding resistance must be less than 100 Ω.

Signal and excitation cable specifications

For remote installations, the converter and detector are connected using a set of dedicated cables (Model MGA12W). The signal cable connects the output signal of the detector to the converter and the excitation cable feeds the excitation current to the detector. You can obtain these cables from Azbil Corporation or purchase commercially available cables. Integral flowmeters already contain the converter to detector connections.

The cables between the detector and converter should be no longer than 300 m (984 ft.), but the actual length depends on conductivity of the fluid being measured.


The following cable diameters apply:

Signal cable - 11.4 mm (0.45 in.), 0.75 mm² (.0011625 sq. in.) or equivalent commercially available cable (CVVS or CEEV, for example)

Excitation cable - 10.5 mm (0.41 in.), 2 mm² (.0031 sq. in.) or equivalent commercially available cable (CVV, for example)

Cable dimensions and construction are shown on the following pages.

The following graphs show the ratio of fluid conductivity to cable length and show cable usage ranges for different diameter cables. The acceptable usage range for Azbil Corporation’s cable Model MGA12W cables encompass both areas A and B in the graphs below while commercially available cables are limited to area A only.






Figure 2-11 Signal Cable Dimensions




Figure 2-12 Excitation Cable Dimensions




Figure 2-13 Signal and excitation cable construction

~ **Note** Strip the conductive tubing (black) down to the ends of the inner shields on the conductive wires for terminals A and B of the signal cable.

Signal and excitation cable wiring

The following figure shows the proper terminal connections for the signal and excitation cables for both model MGA12W cables and commercial cable.




Figure 2-14 Detector to converter wiring diagram

Wiring cable

Selecting the cable

The recommended wiring cable is a 600V vinyl sheath electrical wire CVV (JIS C 3401) with a conductor section of 2 mm²(0.0031 inch²), or a twisted cable with an equivalent or higher capacity.

Shielded wire is recommended for wiring at locations subject to electromagnetic noise interference.

Select a sheath material suitable for the cable installation environment (consider ambient temperature, corrosive gas, corrosive fluid, etc.)

Run the cable into the terminal block through the conduit connection (G1/2 internal thread, CM20 external thread, Pg13.5 or 1/2NPT internal thread).

An outer diameter of $\phi 11$ (0.433 inch) is optimum. (The applicable range of cable outer diameters is $\phi 10$ (0.394 inch) - $\phi 12$ (0.4724 inch).)

A crimp terminal (M4 screw) with an insulation sleeve is recommended for the terminal connections.

The maximum length of the wiring cable is 1500 m(4921 ft). However, the maximum length between converter and detector is 300 m(984 ft).

Wiring the cable

When wiring the cable between this product and the control equipment, the following precautions must be observed.

- ~ **Note** • *Run the wiring away from equipment that may generate noise, such as high-capacity transformers, motors, or power supplies. DO NOT install the cable in the same tray or duct as other power cables. Output errors may result.*
- *For water proofing and damage prevention of the wire, we recommend cabling work using conduits and ducts. Use a water proof cable gland.*


Wiring

Analog output wiring

The current output wiring method depends on HART or SFC communication.

An external power supply is required to communicate with the SFC.

(Change dip switch settings only after turning power supply OFF.)



- ~ Note**
- Check and confirm that the polarity of the wiring is correct. Incorrect polarity may cause damage to the equipment.
 - In case of not using communication function, the position of dip switch pins should be set as the HART communication. HART Communication works with the wiring for the SFC communication.
 - The communication type (HART or SFC) must be specified when ordering. In case of communication change, the following two configurations are necessary.
 - 1) According to the communication type, switch position should be changed. (Refer to the Figure 2-15).
 - 2) Change communication type in the “COM SELECT” screen in the “Shipping Info” screen.

Pulse output wiring

The pulse output is an open collector output.

Pay close attention to voltage and polarity when wiring.




Figure 2-16 Wiring diagram for pulse output

~ Note Check and confirm that the polarity of the wiring is correct. Incorrect polarity may cause damage to the equipment. Use an external power supply that meets the voltage and capacity specifications. Pulse may be output when the power is turned ON or OFF. Pulse output protection circuit causes voltage drop. Some counters may not pick up the pulses due to this voltage drop. In such case, turn On S6 switch. Refer to the Figure 2-17.




Figure 2-17 Switch locations on main card

Contact input wiring

Either a semi conductive contact or a no-voltage contact can be used as the contact input.

The contact input terminals are not available when a 2-contact output model has been selected.




Figure 2-18 Wiring diagram for contact input

Contact output wiring

Pay close attention to voltage and polarity when wiring for an open collector output.




Figure 2-19 Wiring diagram for contact output

~ Note Check and confirm that the polarity of the wiring is correct. Incorrect polarity may cause damage to the equipment.
Use an external power supply that meets the voltage and capacity specifications.

Setting write protection

Write protection settings allow you to control the level at which data confirmation and manipulation are possible. The system has four modes:

Basic setup mode - used to run the flowmeter on a day-to-day basis.

Engineering mode - used by those who are responsible for flowmeter configuration.

Maintenance mode - used when system maintenance is required.

Advanced mode - used to apply some specific noise immunity functions, and other advanced functions.

Write protection settings are changed by setting the switch positions of the write protection switch on the main card in the converter. When the flowmeter is shipped, settings can be made in any mode (Level 0). The following table shows the write protect levels available by resetting the switch:

Table 2-7 Write Protection Levels

Level	Basic setup/ Engineering mode	Advanced mode	Maintenance mode	Remarks
0	✓	✓	✓	Default setting
1	✓	✓	✗	
2	✓	–	✗	
3	–	–	✗	

✓ - Both data confirmation and manipulation are possible.

– - Only data confirmation is possible.

✗ - Neither data confirmation nor manipulation are possible.

To set the write protection level:

1. Remove the four screws holding the display cover to the main body of the converter and remove the cover.
2. Locate the write protection switch.




Figure 2-20 Switch locations on main card

3. Set the write protection switch positions to the required level of protection.





Figure 2-21 Write protection switch positions


Setting the communication via the HART

To check the communication switch position on the main card:

1. Remove the four screws holding the display cover to the main body of the converter and remove the cover.
2. Locate the communication switch



3. Make sure that position of the I switch (1-4) are ON and positions of the SFC switch (5-8) are OFF.




~ **Note** Refer to the Figure 2-15 Wiring diagram for current output for the wiring

Setting the empty detection function


This function fixes the analog output and latches the display to zero when the detector is empty.

To set the empty detection function:

1. Remove the four screws holding the display cover to the main body of the converter and remove the cover.
2. Locate the empty detection function switch.




3. Set the empty detection function switch positions to the required setting.




Setting the communication via the SFC

To check the communication switch position on the main card:

1. Remove the four screws holding the display cover to the main body of the converter and remove the cover.
2. Locate the communication switch



3. Make sure that position of the I switch (1-4) are OFF and positions of the SFC switch (5-8) are ON.



Connecting power

 WARNING	
	ELECTRIC SHOCK HAZARD! DO NOT perform wiring work while the power is ON!

Commercial power (AC100~120, 200~240V, 50-60Hz) or a 24 VDC \pm 10% power supply is required for this system. The power supply specification is shown on the name plate of your converter.




Figure 2-28 Name plate

The 24 VDC converter has a terminal marked “POWER DC24V” instead of “POWER,” as on the remote converter.

Chapter 3: Operation

This chapter describes the procedure for starting and shutting down the flowmeter and using the display panel and the infrared touch sensor keys.

Start-up

To start operation of the flowmeter:

1. Confirm that the detector is correctly installed on the pipe.
2. Confirm that the wiring between the converter and the detector has been properly completed according to the installation instructions specified in this manual. In case of using a HART/SFC communication function, verify an appropriate wiring according to the wiring in this users manual.
3. Begin and then stop fluid flow through the detector so that fluid is present in the detector in a static condition.
4. Confirm that there is no leakage at the flanges of the detector.
5. Apply power to the converter.
6. The following display appears seven seconds after the power is ON.:




Figure 3-1 Start-up display

7. Zero the flowmeter using the procedure on page 4-14.

The flowmeter is now on and operational.

Shut down


 CAUTION	
	Switch the control equipment to manual control before terminating flowmeter operation and shutting off the output to the control equipment. This action prevents the power shut-off from directly affecting the control equipment and causing the valve positioner to malfunction.

To stop operation of the flowmeter:

1. Switch the control equipment connected to the flowmeter to manual control.
2. Turn off power to the converter.

Using the display panel

The display panel is shown below, followed by a description of each feature. The infrared touch sensor keys are described in the next section.



Main display

- Indicates the flow rate selected in basic setup mode.

Auxiliary display

- Several values are displayed in this area:

- During measurement mode, indicates a flow rate to supplement the flow rate selected in the basic setup mode.
- Indicates the totalized value
- When not in measurement mode, indicates the procedures for parameter setting, adjustment, etc.

Percent flow display

- When lit, indicates that the percent flow rate is currently being displayed on Main display.

Actual flow rate display


- When lit, indicates that the actual flow rate is currently being displayed on Main display.

Totalized value display

- When lit, indicates that the totalized value is currently being displayed on Main display.

Using the infrared touch sensor keys

The infrared touch sensor keys allow you to make selections by simply touching the display panel.



For best results, approach the key from below and completely cover the circle. Then move your finger straight down to its original position. These motions ensure correct operation. Moving sideways across the keys can accidentally activate the wrong control.




Table 3-1 Touch Sensor key Functions

key	Function
UP key 	<p>When the cursor is on the Mode Indicator as shown below, touching the UP key displays the next screen.</p> <div style="text-align: center;">  </div>
	<p>When the cursor is located at a number, touching the UP key increments the number.</p> <div style="text-align: center;">  </div>
	<p>When the cursor is located at the decimal point, touching the UP key moves the decimal point to the left.</p> <div style="text-align: center;">  </div>
	<p>When the cursor is located at READY, touching the UP key starts operation.</p> <div style="text-align: center;">  </div>

Table 3-2 Default settings

Parameter	Default	Parameter	Default
TAG	XXXXXXXX	HI-ALM	+115%
DAMPING	3.0s	LO-ALM	-115%
SPAN	as specified	FALL SAFE MODE	LOW
DISPLAY SELECT	as specified	ST. OUT MODE	CLOSE
HYSTERESIS	0	AVERAGING	OFF
GRAVITY	1.0000	COEFFICIENT	1.0000
PLS SCL (PULSE SCALE)	as specified or 1.0000 l/p	DROP OUT	2%
PLS WID (PULSE WIDTH)	DUTY 50	LOW FLOW CUT	OFF

MEMO

Chapter 4: Using the display panel

This chapter describes the four modes of operation and how to use each one. A flow chart of the functions for each mode is also included.

About modes

The MagneW FLEX+/PLUS+ Flowmeter has five modes of operation:

- MEASURING MODE
- BASIC SETUP MODE
- ENGINEERING MODE
- MAINTENANCE MODE
- ADVANCED MODE

The following table describes the functions available in each mode.

Table 4-1 Mode functions

Mode	Description
MEASURING MODE	<p>This is the normal operational mode and indicates the measuring status.</p> <p>Each time the MEASURING MODE is selected, data is written into memory. Settings entered in other modes are held in temporary memory for two minutes, but will return to the previously saved value unless the MEASURING MODE is selected to save the data. The only exception is the counter, which is always saved into memory immediately.</p>
BASIC SETUP MODE Mode indicator: 	<p>This mode is used to change data settings that must be recorded or changed frequently. These settings include:</p> <ul style="list-style-type: none"> TAG NO. Damping time constant Display select Auto zero Flow rate range Detector data Built -in counter reset/preset
ENGINEERING MODE Mode indicator: 	<p>This mode is used to change data settings that are used less frequently. These settings include:</p> <ul style="list-style-type: none"> Function setting Flow rate range Pulse data Fail safe mode setting
MAINTENANCE MODE Mode indicator: 	<p>This mode is used when adjustment or verification is required for regular maintenance of the system or when troubleshooting the system. This mode includes:</p> <ul style="list-style-type: none"> Shipping information Output adjustment Gain adjustment <p>This mode is further divided into the following two modes:</p> <ul style="list-style-type: none"> OUTPUT CHECK MODE CALIBRATION MODE

Table 4-1 Mode functions

Mode	Description
ADVANCED MODE Mode indicator: &	This mode is used to apply some specific noise immunity functions. This mode includes: Damping Manual zero Averaging Auto spike Cut Coefficient Drop out Low-flow cut off Flow direction change

**CAUTION**

The CALIBRATION MODE and ADVANCED MODE contain adjustments and operations that are very important for proper flow rate measurement. Improper settings in these modes will prevent measurement.

MEASURING MODE

This is the normal operational mode. In this mode, the screen indicates the measuring status. What is displayed on screen depends upon the setting selections made in the other modes.

This mode performs one other important function. Entering this mode causes the system to save settings entered in other modes. Each time the MEASURING MODE is selected, data is written into memory. Settings entered in other modes are held in temporary memory for two minutes, but will return to the previously saved value unless the MEASURING MODE is selected. The only exception is the counter, which is always saved into memory immediately.




CAUTION




After entering settings in other modes, ALWAYS immediately select the MEASURING MODE to save settings.


LCD display flow


The following screens appear in this order.







- (*2): Indicated when single range is selected.
- (*3): Indicated when normal direction automatic dual range or normal direction external switching range is selected.
- (*4): Indicated when normal/reverse automatic range or normal/reverse external switching range is selected.
- (*5): Indicated when automatic range is selected in (*3) and (*4).
- (*6): Indicated when normal direction dual range is selected.
- (*7): Indicated when a mass unit is selected.











Entering BASIC SETUP MODE

The following screens appear in this order in BASIC SETUP MODE.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Left display is an example of MEASURING MODE. Touch MODE key and hold for three seconds. The BASIC SETUP MODE ENTER screen appears.
2	 ↓ 	 ↓ 	<p>Make sure to operate the following within 8 seconds. If no operation is done in 8 seconds, the screen automatically returns to the MEASURING MODE.</p> <p>1) In case of entering BASIC SETUP MODE Touch the  key twice to move the cursor to YES. Touch the  key once.</p> <p>2) In case of back to MEASURING MODE Touch the  key three times to move the cursor to NO. Touch the  key once.</p>
3			With the operation of 1), the BASIC SETUP MODE screen appears for two seconds.
4			TAG setting screen appears two seconds after.

Setting the TAG NO.



This function sets the TAG NO. of the flowmeter.

Default setting

XXXXXXXX

Setting range

8 characters max. Alphanumeric characters, -, @, and space can be set.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter the BASIC SETUP MODE. (See page 4-11)
2			In the BASIC SETUP MODE, the TAG NO. screen is the first screen that appears.
3			Touch the  key until the cursor is at the character to be changed.
4			Touch  or  key to change the character.
5			Touch the  key until the cursor is back at the mode indicator.

Damping time constant



The damping time constant removes minute fluctuations when transmitting the measured flow rate to the control equipment. Check the amplitude of fluctuation in flow output and set the damping time constant to an appropriate value. The new value becomes effective as soon as it is entered

Default setting

3.0 second.

Setting range



0.1 to 199.9 seconds. (0.0 to 199.9 seconds for “Fast Response Option for Short Run Batch Process”.)

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter the BASIC SETUP MODE. (See page 4-11)
2			Use the Touch  or  key to cycle through the screens until the damping screen appears.
3			Touch the  key until the cursor is at the value to be changed. (in the example, the key is touched three times.)
4			Use  or  key to change the numeric value. Touch and holding either key quickly increments or decrements the values.
5			Touch the  key until the cursor is back at the mode indicator. Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the Damping Time Value.

Auto zero

This function adjusts the flowmeter so that the measured flow rate is zero when the fluid is in static condition inside the detector.


 CAUTION	
	Before operating the flowmeter for the first time, be sure to carry out auto zero. Zero adjustment is very important for accurate flow measurement.
	Before performing auto zero calibration of the flowmeter, make sure the detector is properly grounded (grounding resistance must be less than 100 Ω), that the detector is filled with the fluid to be measured and that the fluid is in static condition. Zero adjustment is possible with a flow speed of 0.2 m/s (0.656 ft./s) or less, but the flow speed should be 0.0 m/s (0.0 ft./s) for accurate adjustment. Output errors can result from improper zeroing. If the conditions above can not be guaranteed the auto zero function should be ignored.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter the BASIC SETUP MODE. (See page 4-11)
2			Use the  or  key to cycle through the screens until the AUTO ZERO screen appears.
3			Touch the  key once to move the cursor to READY to indicate that the system is ready for zeroing.
4			Touch the  key once to select READY and start the auto zero adjustment. The large numerical display flashes and READY changes to ON during adjustment. When the zero adjustment is complete, the flashing stops and ON changes back to READY. Zero adjustment takes approximately 60 to 100 seconds.

Step	Screen		Procedure
	(English)	(Japanese)	
5	 <p>0.0 % * AUTO ZERO READY</p>	 <p>0.0 % * ゼロセッテイ READY</p>	<p>Touch the  key until the cursor is back at the mode indicator.</p> <p>Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the zero setting.</p>

Flow counter - Reset value

This function sets the totalization starting value of the built-in flow counter

Step	Screen		Procedure
	(English)	(Japanese)	
1	 <p>123456^{TOTAL} * CNT-RESET VALUE 0000010000</p>	 <p>123456^{TOTAL} * カウントリセットチ 0000010000</p>	To change this function, the DISPLAY SELECT must be set to TOTAL (see page 4-22). Enter BASIC SETUP MODE (see page 4-11). Use the \downarrow or \uparrow key to cycle through the screens until the CNT-RESET VALUE screen appears.
2	 <p>123456^{TOTAL} * CNT-RESET VALUE 00000<u>1</u>0000</p>	 <p>123456^{TOTAL} * カウントリセットチ 00000<u>1</u>0000</p>	Touch the \rightarrow key as many times as is necessary to move the cursor to the value to be changed. (In the example, the key is touched six times.)
3	 <p>123456^{TOTAL} * CNT-RESET VALUE 00000<u>5</u>0000</p>	 <p>123456^{TOTAL} * カウントリセットチ 00000<u>5</u>0000</p>	Touch the \downarrow or \uparrow key to change the numerical value. Touching and holding either key quickly increments or decrements the values.
4	 <p>123456^{TOTAL} * CNT-RESET VALUE 0000050000</p>	 <p>123456^{TOTAL} * カウントリセットチ 0000050000</p>	Touch the \rightarrow key until the cursor is back at the mode indicator. Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the new value.

Flow counter - Resetting

This function resets the current totalized value and saves it to memory. (The default value for the counter is 000000000 at power-up.)

Step	Screen		Procedure
	(English)	(Japanese)	
1			<p>Enter BASIC SETUP MODE (see page 4-11). (The first screen in this mode is always the TAG screen.)</p> <p>Use the  or  key to cycle through the screens until the CNT-RESET screen appears.</p>
2			<p>Touch the  key once to move the cursor to READY.</p>
3			<p>Touch the  key to select READY and reset the counter. READY changes to ON as the counter resets and then changes back to READY when it's done.</p>
4			<p>Touch the  key until the cursor is back at the mode indicator. Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the new value.</p>



Detector data


This function is used to select the constant, model and diameter of the detector being used with this converter. In this screen, three values can be changed: the detector constant (EX), detector type (MGG, KID, NNK, NNM) and the detector diameter (DIA)

Default setting

If only converter is purchased, the default values are EX 300.0, MGG, DIA050.0.

 CAUTION
 <p>If the converter and detector are purchased together, the converter contains the detector data that was set during actual flow calibration. DO NOT change this data or the flowmeter output will be incorrect.</p>

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the  or  key to cycle through the screens until the detector DATA (EX/DIA) screen appears.
2			Touch the  key until the cursor is at the detector Constant (EX) to be changed. Touch the  or  key to change the value.
3			Touch the  key until the cursor is at the detector type. Use the  or  key to change the value.
4			Use the  key to move the cursor to the detector Diameter value. The converter works with the following detector Diameters (in millimeters): <ul style="list-style-type: none"> ◆ 2.5 ◆ 5 ◆ 10 ◆ 15 ◆ 25 ◆ 40 ◆ 50 ◆ 65 ◆ 80 ◆ 100 ◆ 125 ◆ 150 ◆ 200 ◆ 250 ◆ 300 ◆ 350 ◆ 400 ◆ 450 ◆ 500 ◆ 600 ◆ 700 ◆ 800 ◆ 900 ◆ 1000 ◆ 1100

Step	Screen		Procedure
	(English)	(Japanese)	
5			Touch the  key until the cursor is back at the mode indicator

✓ : Can be used

Size/Detector Model No.	MGG	KID	NNM	NNK
2.5	✓	✓		
5.0	✓	✓		
10.0	✓	✓		
15.0	✓	✓		
25.0	✓	✓	✓	
40.0	✓	✓	✓	
50.0	✓	✓	✓	✓
65.0	✓			
80.0	✓	✓	✓	
100.0	✓	✓	✓	✓
125.0	✓			
150.0	✓	✓	✓	
200.0	✓	✓	✓	✓
250.0	✓	✓	✓	
300.0	✓	✓	✓	
350.0	✓	✓	✓	
400.0	✓	✓	✓	✓
450.0	✓		✓	
500.0	✓	✓		
600.0	✓	✓	✓	✓
700.0	✓		✓	
800.0	✓		✓	
900.0	✓			
1000.0	✓			
1100.0	✓			

~ **Note** For MGG and KID type detectors, set the detector factor (EX) as the value stamped on the name plate. For NNM and NNK if you need to replace a converter with a new one, contact an Azbil Corp. representative.

Setting the Number of Dummy Detectors

Specify the number of dummy detectors (model NNK951) that are installed along with the NNK detector (model NNK150).

This screen appears only for open channel type electromagnetic flowmeter NNK.

For example, if there is one detector and one dummy detector, set “1” for [DUMMY].

Also, when specifying the flow rate range, add the flow rate of the dummy detector(s).

For example, if the fluid flows to a detector at 100 m³/h and to a dummy detector at 100 m³/h (200 m³/h in total), set the flow rate range of the converter to 200 m³/h.

Default setting

0

Setting range

0 to 9

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the \uparrow or \downarrow key to cycle through the screens until the detector DATA screen appears. Touch the \rightarrow key move the cursor to the detector type. Change the detector type as NNK using the \uparrow key.
2			Touch the \rightarrow key once.
3			Use the \uparrow or \downarrow key to input the number of dummy detectors. In this example, the number of the dummy detectors has been changed from 0 to 3.
4			Touch the \rightarrow key once to move the cursor to the mode indicator.





Flow rate range

This function is used to set the flow rate range (the value when the analog output reaches 100%). In this screen, three values can be changed: flow rate value, flow rate unit, and time unit.

Setting range

Flow rate: 0.00001 to 99999

Unit: m³/d, m³/h, m³/m, m³/s, l/d, l/h, l/m, l/s, cm³/d, cm³/h, cm³/m, cm³/s, t/d, t/h, t/m, t/s, kg/d, kg/h, kg/m, kg/s, g/d, g/h, g/m, g/s, BPD, BPH, BPM, BPS, kGPD, kGPH, kGPM, kGPS, IGPD, IGPH, IGPM, IGPS, KIGPD, KIGPH, KIGPM, KIGPS, mIGPD, mIGPH, mIGPM, mIGPS, GPD, GPH, GPM, GPS, mGPD, mGPH, mGPM, mGPS, lb/d, lb/h, lb/m, lb/s

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the \downarrow or \uparrow key to cycle through the screens until the SPAN screen appears.
2			Touch the \rightarrow key until the cursor is at the flow rate value to be changed.
3			Touch the \downarrow or \uparrow key to change the value.
4			Use the \rightarrow key to move the cursor to the flow rate unit. Touch the \downarrow or \uparrow key to change the unit. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;"> CAUTION</p> <p> If a weight unit is set, the Specific Gravity must also be set to avoid output errors.</p> </div>
5			Use the \rightarrow key to move the cursor to the time unit. Touch the \downarrow or \uparrow key to change the unit. Available units: h, min., s, d
6			Touch the \rightarrow key until the cursor is back at the mode indicator.

Flow rate indication



This function selects the flow rate indication displayed on screen. The data can be displayed as a percent (%), the actual flow rate (RATE) or the totalized value (TOTAL)

Default setting

As specified when ordered.

Setting range

%(flow rate in percent), RATE (actual flow rate), TOTAL (totalized value)




Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the \downarrow or \uparrow key to cycle through the screens until the DISPLAY SELECT screen appears.
2			Touch the \rightarrow key once to move the cursor to the flow rate indication value.
3			Touch the \downarrow or \uparrow key to scroll through the selections (% , RATE or TOTAL). Note that the Main Display changes as the different display selections appear. The current flow rate indication value appears at the upper right in the Main Display.
4			Touch the \rightarrow key until the cursor is back at the mode indicator.

Entering ENGINEERING / ADVANCED / MAINTENANCE MODE


This is to describe how to enter ENGINEERING, ADVANCED and MAINTENANCE MODE.

~ **CAUTION** Check the write protection level to enter each mode (See page 2-21).

Entering ENGINEERING MODE


Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the ∇ or \blacktriangle key to cycle through the screens until the MODE ENTER ENGINEERING screen appears.
2			Touch the \blacktriangleright key once to move the cursor to ENGINEERING.
3			Touch the \blacktriangle key to select. The ENGINEERING MODE screen appears.
4			Two seconds later, Function set screen appears.

Entering ADVANCED MODE

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the ∇ or \blacktriangle key to cycle through the screens until the MODE ENTER ADVANCED screen appears.
2			Touch the \blacktriangleright key once to move the cursor to ADVANCED.

Step	Screen		Procedure
	(English)	(Japanese)	
3			Touch the  key to select. The ADVANCED MODE screen appears.
4			Two seconds later, DAMPING screen appears.

Entering MAINTENANCE MODE

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter BASIC SETUP MODE (see page 4-11). Use the  or  key to cycle through the screens until the MODE ENTER MAINTENANCE screen appears.
2			Touch the  key once to move the cursor to MAINTENANCE.
3			Touch the  key to select. The MAINTENANCE MODE screen appears.
4			Two seconds later, OUTPUT CHECK MODE screen appears.


Selecting functions

Introduction

Sets the electromagnetic flowmeter functions: range, counter, contact input, and contact output.

There will be restrictions on the functions that can be set depending on your model's specifications. Note that the setting range will be limited depending on the selection of contact input/output.

The possible combinations are shown on the following pages.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ENGINEERING MODE (see page 4-23).
2			Touch the ⇨ key to select the kind of function settings. 1 st character is for range setting, 2 nd is for built-in counter setting, 3 rd is for contact input function setting and 4th is for contact output function setting.
3			Touch the ⇩ or ⇧ key to select the desired function.
4			Two touches of the ⇨ key in step 1 enables the selection of the built-in counter function. Touch the ⇩ or ⇧ key to select the desired function.
5			Three touches of the ⇨ key in step 1 enables the selection of the contact input function. Touch the ⇩ or ⇧ key to select the desired function.
6			Four touches of the ⇨ key in step 1 enables the selection of the contact output function. Touch the ⇩ or ⇧ key to select the desired function.

Step	Screen		Procedure
	(English)	(Japanese)	
7			When completing the setting of the respective functions, touch the  key to move the cursor to the “#”.

Relations for setting function FXXXX

Introduction

The range, built-in counter, contact input, and contact output functions can be set using the combinations shown in the table below. For example, when “Single range” and “Addition with preset” are selected, there are three contact input choices (X, 1, and 2) and three contact output choices.

1-contact input and 1-contact output (DI/DO)

Range function	Built-in counter function	Contact input function	Contact output function
0: Single range	A: Addition	X: Not activated	X: Not activated
			1: Alarm output
			4: Self-check result output
			5: Empty detection function
		1: External 0% lock	X: Not activated
			1: Alarm output
			4: Self-check result output
			5: Empty detection function
		2: External auto zeroing	X: Not activated
			1: Alarm output
			4: Self-check result output
			5: Empty detection function
4: Counter reset	X: Not activated		
	1: Alarm output		
	4: Self-check result output		
	5: Empty detection function		
B: Addition with preset	X: Not activated		
	1: External 0% lock		
	2: External auto zeroing		
1: Automatic switching dual range function	A: Addition	X: Not activated	2: Range switching output
		1: External 0% lock	2: Range switching output
		2: External auto zeroing	2: Range switching output
		4: Counter reset	2: Range switching output
			2: Range switching output
2: External switching dual range	A: Addition	3: External range switching	X: Not activated
			1: Alarm output
			2: Range switching output
			4: Self-check result output
			5: Empty detection function
	6: High/low limit alarm		
B: Addition with preset	3: External range switching	3: Preset output	
3: Normal/reverse automatic switching range	A: Addition	X: Not activated	2: Range switching output
		1: External 0% lock	2: Range switching output
		2: External auto zeroing	2: Range switching output
		4: Counter reset	2: Range switching output
	C: Normal/reverse totalization	X: Not activated	2: Range switching output
		1: External 0% lock	2: Range switching output
		2: External auto zeroing	2: Range switching output
		4: Counter reset	2: Range switching output

Range function	Built-in counter function	Contact input function	Contact output function
4: Normal/reverse external switching range	A: Addition	3: External range switching	X: Not activated
			1: Alarm output
			2: Range switching output
	B: Addition with preset	3: External range switching	4: Self-check result output
			5: Empty detection function
			6: High/low limit alarm
C: Normal/reverse totalization	3: External range switching	3: Preset output	
		X: Not activated	
		1: Alarm output	
	3: External range switching	2: Range switching output	
		4: Self-check result output	
		5: Empty detection function	
			6: High/low limit alarm

2- contact inputs

Range function	Built-in counter function	Contact input function	Contact output function	
0: Single range	A: Addition	X: Not activated	X: Not activated	
		1: External 0% lock	X: Not activated	
		2: External auto zeroing	X: Not activated	
		4: Counter reset	X: Not activated	
		5: External 0% lock + Auto zeroing	X: Not activated	
		7: External 0% lock + Counter reset	X: Not activated	
		9: External auto zeroing + Counter reset	X: Not activated	
2: External switching dual range	A: Addition	3 External range switching	X: Not activated	
		6: External 0% lock + Range switching	X: Not activated	
		8: External auto zeroing + Range switching	X: Not activated	
		A: External range switching + Counter reset	X: Not activated	
4: Normal/reverse external switching range	A: Addition	3 External range switching	X: Not activated	
		6: External 0% lock + Range switching	X: Not activated	
		8: External auto zeroing + Range switching	X: Not activated	
		A: External range switching + Counter reset	X: Not activated	
	C: Normal/reverse totalization	3 External range switching	6: External 0% lock + Range switching	X: Not activated
			8: External auto zeroing + Range switching	X: Not activated
			A: External range switching + Counter reset	X: Not activated

2- contact outputs

Range function	Built-in counter function	Contact input function	Contact output function
0: Single range	A: Addition	X: Not activated	X: Not activated
			E: High 1 and High 2 alarm or Low 1 and Low 2 alarm
			1: Alarm output
			4: Self-check result output
			5: Empty detection function
			6: High/low limit alarm
	B: Addition with preset	X: Not activated	3: Preset output
			D: Alarm + Preset output
			F: Preset + Self-check
			G: Preset + Empty detection
H: Preset + High/low limit alarm	I: Self-check result + Empty detection	J: Self-check result + High/low limit alarm	K: Empty detection + High/low limit alarm
1: Automatic switching dual range	A: Addition	X: Not activated	2: Range switching output
			7: Alarm + Range switching output
			8: Self-check result + Range switching output
			9: Empty detection + Range switching output
			A: High/low limit alarm + Range switching output
	C: Range switching output + Self-check, Empty detection		
B: Addition with preset	X: Not activated	B: Range switching output + Preset output	
3: Normal/reverse automatic switching range	A: Addition	X: Not activated	2: Range switching output
			7: Alarm + Range switching output
			8: Self-check result + Range switching output
			9: Empty detection + Range switching output
			A: High/low limit alarm + Range switching output
			C: Range switching output + Self-check, Empty detection
	B: Addition with preset	X: Not activated	B: Range switching output + Preset output
	C: Normal/reverse totalization	X: Not activated	2: Range switching output
			7: Alarm + Range switching output
			8: Self-check result + Range switching output
9: Empty detection + Range switching output			
A: High/low limit alarm + Range switching output	C: Range switching output + Self-check, Empty detection		

Range functions

Single range


Measures a single range in the normal direction.

The output for a reverse flow will be as follows

Analog output: Possible to approx. -20% (0.8 mA). With communication, to approx. -5% (3.2 mA).

Pulse output: No output

Display: A minus (-) symbol appears.



Normal direction automatic dual range

This function has two ranges: wide and narrow. When the narrow range measurement exceeds 100%, the unit automatically changes to the wide range.

This function should be used in combination with the wide/narrow range distinction output contact. Hysteresis setting is available when dual range is selected.

- ① When AUTO is selected for an analog output
Range No.1 4 to 20 mA DC
Range No.2 4 to 20 mA DC
- ② When WIDE is selected for an analog output
4 to 20 mA DC is output according to either range No.1 or range No.2, whichever has the wider range.

When there is a pulse output

The pulse weight is the same for both ranges No.1 and No.2.


Contact output

At shipment, the contact output status of the distinction status signal for ranges No.1 and No.2 is as follows.

Range No.1: Closed

Range No.2: Open

Reverse setting is also possible.



(Example)

- ① AUTO range
Range No.1 (narrow range): Outputs 4 to 20 mA for 0 to 10 m³/h (a-b).
Range No.2 (wide range): Outputs 4 to 20 mA for 0 to 40 m³/h (a-d)
- ② WIDE range
Range No.1 (narrow range): Outputs 4 to 8 mA for 0 to 10 m³/h (a-c).
Range No.2 (wide range): Outputs 8 to 20 mA for 10 to 40 m³/h (c-d).

Normal direction, external switching dual range

The range is switched via an external switching command to the contact input.

Also, the wide/narrow range distinction contact output (status signal) can be sent out using the same timing.

Analog output

- ① When AUTO is selected for an analog output
Range No.1 4 to 20 mA DC
Range No.2 4 to 20 mA DC
- ② When WIDE is selected for an analog output
4 to 20 mA DC is output according to either range No.1 or range No.2 whichever has the wider range.

When there is a pulse output

The pulse weight is the same for both ranges No.1 and No.2.

Contact input

Range switching command contact input

Range No.1: Close

Range No.2: Open

Contact output (select functions as required.)

Range switching distinction status signal

The contact output status at shipment is as follows.

Range No.1: Closed

Range No.2: Open

Reverse setting is also possible.

Normal/reverse automatic switching range

Automatically switches the range when the fluid flow direction reverses.
Hysteresis setting is available when normal/reverse switching is selected.

Analog output

Normal direction: 4 to 20 mA DC

Reverse direction: 4 to 20 mA DC

When there is a pulse output

There is no distinction in output between the normal and reverse directions. The pulse weight is also the same.

The built-in counter simply integrates the flow rate without distinguishing normal and reverse directions. However, when normal/reverse differential flow integration is selected, integration of the “-” direction (subtraction) is available.

Example: In the normal direction

$-100 \rightarrow -99 \rightarrow -98 \rightarrow \dots 0 \rightarrow 1, 2, 3$

In the reverse direction

$100 \rightarrow 99 \rightarrow 98 \dots 0 \rightarrow -1, -2, -3$

With indication

With a reverse flow rate, the “-” symbol will appear on the flow rate display.

With built-in counter, it is possible to select the normal/reverse differential flow integration function.

Contact output


Normal/reverse distinction status signal

The contact output status at shipment is as follows.

Range No.1: Closed

Range No.2: Open

Reverse setting is also possible



(Example of setting)

① AUTO range

- Range No.1 (normal range): Outputs 4 to 20 mA for 0 to 30 m³/h (a-b).
- Range No.2 (reverse range): Outputs 4 to 20 mA for 0 to -10 m³/h (a-d).

② WIDE range

- Outputs 4 to 8 mA for -10 to 0 m³/h (c-e), 8 to 20 mA for 0 to 30 m³/h (e-b).

When WIDE is selected, Low-flow-cut is not performed.

Normal / Reverse external switching range

Switches between the normal and reverse ranges by inputting a switching command contact from the host system or controller.

It is also possible to output the normal/reverse range distinctive contact output (status signal) using the same timing.

Analog output

- ① When AUTO is selected for an analog output
Normal direction: 4 to 20 mA DC
Reverse direction: 4 to 20 mA DC
- ② When WIDE is selected for an analog output
4 to 20 mA DC is output according to either range No.1 or range No.2, whichever has the wider range.

With pulse output

There is no distinction in output between the normal and reverse directions. The pulse weight is also the same.

The built-in counter simply integrates the flow rate without distinguishing between the normal and reverse directions. However, when normal/reverse differential flow integration is selected, the integration of the “-” direction (subtraction) is available.

Example: In the normal direction

-100 → -99 → -98... 0 → 1, 2, 3

In the reverse direction

100 → 99 → 98... 0 → -1, -2, -3

With indication

With a reverse flow rate, the “-” symbol will appear on the flow rate display.

For the built-in counter, it is possible to select the normal/reverse differential flow integration function.

Contact input

Range switching command contact input

Normal direction: when opened

Reverse direction: when closed

Contact output (select the function required.)

Normal/reverse distinction status signal

The contact output status at shipment is as follows.

Range No.1: Closed

Range No.2: Open

Reverse setting is also possible.

[Built-in counter function]

A: Addition counter

In the normal/reverse range, addition is performed in the normal and reverse directions, respectively.

B: Addition counter with preset

The preset value ranges from 0000000000 - 9999999999.

In the normal/reverse range, addition is made in the normal and reverse directions, respectively.

C: Normal/reverse differential flow rate integration display

Displays the difference in integration between the normal and reverse directions.

It is necessary to determine the direction: normal or reverse.

[Contact input function]

This function can be set when either 1- or 2-contact input has been selected in the additional specifications.

X: Not activated

1: External 0% lock input

Use to completely halt the flow rate signal (display, analog output, or pulse output) at 0%.

2: External auto zero adjustment input

Enables zero adjustment from a remote location.

Zero adjustment is possible when the contact is ON for 0.2 seconds or more.

Be sure to stop the fluid.

3: External range switching input

Range No.1 or normal direction: when opened

Range No.2 or reverse direction: when closed

4: Built-in counter reset input

Reset will take effect when the contact is ON for 0.2 seconds or more, and counting will start from the counter reset value at the moment when the contact turns OFF.

5: External 0% lock input and external auto zero adjustment input

Terminal ST IN1 can be set to external 0% lock input and terminal ST IN2 to external auto zero adjustment input.

6: External 0% lock input and external range switching input

Terminal ST IN1 can be set to external 0% lock input and terminal ST IN2 to external range switching input.

7: External 0% lock input and built-in counter reset input

Terminal ST IN1 can be set to external 0% lock input and terminal ST IN2 to the built-in counter reset input.

8: External auto zero adjustment input and external range switching input

Terminal ST IN1 can be set to external auto zero adjustment input and the terminal ST IN2 to external switching input.

9: External auto zero adjustment input and built-in counter reset input

Terminal ST IN1 can be set to auto zero adjustment input and terminal ST IN2 to built-in counter reset input.

A: External range switching input and built-in counter reset input

Terminal ST IN1 can be set to external range switching input and terminal ST IN2 to built-in counter reset input.

[Contact output function]

This function can be set when 1- or 2-contact output has been selected in the additional specifications.

X: Not activated

1: Alarm contact output

An alarm is output when any of the following items becomes abnormal.

The abnormal item can be checked on the display of the instrument.

Also, external confirmation is available using the SFC.

④ Self-diagnostic

- Coil disconnection
- ROM error
- RAM error
- NVM error
- ADC error

Table 4-2 Output selection

Mode selection	Fail-safe direction high (HIGH)	Hold (HOLD)	Fail-safe direction low (LOW)
Analog output 4 to 20 mA	Fail-safe high (HIGH) without SFC communication: 24 mA DC with SFC communication: 23.8 mA DC	Hold (HOLD)	Fail-safe direction low (LOW) Without SFC communication: 0.8 mA DC With SFC communication: 2.96 mA DC
Pulse output	—	Hold (HOLD)	Fail-safe direction low (LOW) No output
Contact output	Abnormal status (Open/closed can be freely selected.)		

CAUTION



If the power supply is turned OFF with the “Fail-safe direction high” setting, the 4-20 mA output will emit a Fail-safe direction high output once. Pay close attention when turning the power supply OFF.

② Empty detection function

When the detector becomes empty, the respective output signals will be as follows.

Output signal	Status	When the detector is empty
Analog output 4-20 mA DC		4 mA DC
Pulse output		0%
Contact output		Abnormal status (Open/closed can be freely selected.)

~ Note *This function can be used when the conductivity is 30 $\mu\text{S}/\text{cm}$ or greater. The empty detection function selector switch determines whether this function is activated or not. (The empty detection function is set to “NOT activated” as default setting.)*

~ Note *Using the empty detection function with a conductivity of 30 $\mu\text{S}/\text{cm}$ or less will cause a measurement error.*

③ High/low limit alarm function

According to preset High/low limit value, alarm signal is output through ST.OUT terminal.

2: Range switching output

The contact output status at shipment is as follows.

Range No.1 or normal direction: Closed

Range No.2 or reverse direction: Open

Reverse setting is also possible.

3: Counter preset status output

Activated when the counter reaches the preset value.

4: Self-check result output

Activated only when a self-diagnostic abnormality occurs in the alarm contact output of code 1.

5: Empty detection function

Activated only when an empty status is detected in the alarm contact output of code 1.

6: High/low limit alarm

Activated only when a high/low limit alarm occurs in the alarm contact output of code 1.

7: Alarm contact output and range switching output (2-contact output)

The alarm contact output can be set to ST.OUT1 and the range switching output to ST.OUT2.

8: Self-check result output and range switching output (2-contact output)

The self-diagnostic result output can be set to ST.OUT1 and the range switching output to ST.OUT2.

9: Empty detection function and range switching output (2-contact output)

The empty status detection output can be set to ST.OUT1 and the range switching output to ST.OUT2.

A: High/low limit alarm and range switching output (2-contact output)

The high/low limit alarm can be set to ST.OUT1 and the range switching output to ST.OUT2.

B: Range switching output and counter preset status output (2-contact output)

The range switching output can be set to ST.OUT1 and the preset status output to ST.OUT2.

C: Range switching output and (self-check result output or empty detection) (2-contact output)

The range switching output can be set to ST.OUT1 and the output when either a self-check result or empty detection abnormality occurs to ST.OUT2.

D: Alarm contact output and counter preset status output (2-contact output)

The alarm contact output can be set to ST.OUT1 and the counter preset status output to ST.OUT2.

E: 2-stage flow rate alarm output

The high/low limit alarm can be set to ST.OUT1 and the 2-stage high limit alarm or 2-stage low limit alarm to ST.OUT2.




Figure 4-4 2-stage flow rate alarm output

F: Counter preset status output and self-check result output (2-contact output)

The counter preset status output can be set to ST.OUT1 and the self-check result output can be set to ST.OUT2.

G: Counter preset status output and empty detection function

The counter preset status output can be set to ST.OUT1 and empty detection function can be set to ST.OUT2.

H: Range switching output and High/low limit alarm output

The range switching output can be set to ST.OUT1 and High/low limit alarm can be set to ST.OUT2.

I: Self-check result output and empty detection function

The self-check result can be set to ST.OUT1 and empty detection function can be set to ST.OUT2.

J: Self-check result output and High/low limit alarm

The self-check result can be set to ST.OUT1 and the high/low alarm can be set to ST.OUT2.

K: Empty detection function and High/low limit alarm

The empty detection function can be set to ST.OUT1 and the high/low limit alarm can be set to ST.OUT2.



Flow rate range


This function is used to set the flow rate range (the value when the analog output reaches 100%). In this screen, three values can be changed: flow rate value, flow rate unit, and time unit.

Setting range

Flow rate: 0.00001 to 99999

Unit: m³/d, m³/h, m³/m, m³/s, l/d, l/h, l/m, l/s, cm³/d, cm³/h, cm³/m, cm³/s, t/d, t/h, t/m, t/s, kg/d, kg/h, kg/m, kg/s, g/d, g/h, g/m, g/s
BPD, BPH, BPM, BPS, kGPD, kGPH, kGPM, kGPS, IGPD, IGPH, IGPM, IGPS, KIGPD, KIGPH, KIGPM, KIGPS, mIGPD, mIGPH, mIGPM, mIGPS, GPD, GPH, GPM, GPS, mGPD, mGPH, mGPM, mGPS, lb/d, lb/h, lb/m, lb/s

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ENGINEERING MODE (see page 4-11). Use the  or  key to cycle through the screens until the SPAN (range) screen appears.
2			Touch the  key until the cursor is at the flow rate value to be changed.
3			Touch the  or  key to change the value.
4			Use the  key to move the cursor to the flow rate unit. Touch the  or  key to change the unit. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;"> CAUTION</p> <p> If a weight unit is set, the Specific Gravity must also be set to avoid output errors.</p> </div>
5			Use the  key to move the cursor to the time unit. Touch the  or  key to change the unit. Available units: h, min., s, d

Step	Screen		Procedure
	(English)	(Japanese)	
6			Touch the  key until the cursor is back at the mode indicator.

Setting hysteresis





This is used to set the hysteresis as a range function to be used at range switching. Use for normal direction automatic dual range or the normal/reverse direction automatic range.

Default setting

0%


Setting range

0-20%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the hysteresis setup screen by following the steps to enter the engineering mode. (See page 4-11)
2			Touch the  key once.
3			Use the  and  keys to input the desired hysteresis value. In this example, here the hysteresis is changed from 5% to 10%.
4			Touch the  key to move the cursor to the “#”.

Selecting the current output method for dual range

This is used as a range function with the normal direction dual range or normal/reverse direction dual range, to select how to output the 4-20 mA analog output: with either the range switching method or the wider range method.



Default setting

AUTO

Setting the range

Either AUTO or WIDE

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the current output method selection screen by following the steps to enter the engineering mode.
2			Touch the key once.
3			Use the and keys to select the AUTO or WIDE.
4			Touch the key to move the cursor to the “#”.

Setting / Changing the preset value of the built-in flow counter

This changes the contact output status from H to L or from L to H when the flow counter reaches a preset value.

This function is used when contact output has been selected.

Also, be sure to select the preset counter for the contact output in function setting. (See page 4-25)

Default setting

The preset value is set to “0000000000” at shipment.

Setting range

0000000000 - 9999999999

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the built-in flow counter preset value setup screen by following the steps to enter the Engineering mode.
2			Touch the  key to move the cursor to the desired digits. In this example, the cursor is moved to the “2” position by touching the RIGHT SHIFT key five times.
3			Touch the  or  key to set the desired numbers. In this case, the numeral “2” is changed to “5” by three touches of the increment key.
4			When the counter reset value has been changed, touch the  key to return the cursor to the “#”.

Specific gravity

This function is used to set the specific gravity when selecting a weight unit (t, kg, g, lb) in the flow rate measurement range setting.









Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ENGINEERING MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until the GRAVITY screen appears.
2			Touch the \Rightarrow key until the cursor is at the value to be changed. Default setting: 1.0000 Setting range: 0.1000 to 9.9999
3			Touch the \downarrow or \uparrow key to change the value.
4			Touch the \Rightarrow key until the cursor is back at the mode indicator.

Pulse weight

This function is used to set the pulse weight value and pulse weight unit.

Pulse weight should be set so that pulse frequency indicated on the display is between 0.00006 and 3000Hz.

When changing the pulse weight with the dual range, use the wider range.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ENGINEERING MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until the PLS (pulse weight) screen appears.
2			Touch the \rightarrow key until the cursor is at the pulse weight value to be changed. Default setting: 100.00 cm ³ /P.
3			Touch the \downarrow or \uparrow key to change the value.
4			Use the \rightarrow key to move the cursor to the pulse weight unit.
5			Touch the \downarrow or \uparrow key to change the pulse weight unit. <div style="border: 1px solid black; padding: 5px;"> <div style="text-align: center;"> CAUTION</div> <div style="text-align: center;"> Pulse weight units must match span units.</div> </div>
6			Touch the \rightarrow key until the cursor is back at the mode indicator.

Setting the pulse width

This is used to set the pulse width so that the duty ratio at the upper right of the 16-digit display will not exceed 70%.

When changing the pulse width with a dual range, use the wider range.

Default setting

DUTY 50%

Setting range









Pulse width: “NUM”, “DUTY 50%”


Pulse width: 000.10 to 999.99 ms

When “NUM” is selected, the pulse width can be set freely.

When “DUTY” is selected, “DUTY” is fixed at 50%.

When using “DUTY” and the pulse frequency is 0.5Hz or less, the pulse ON duration is fixed at one second.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the pulse width setup screen by following the steps to enter the engineering mode.
2			Use the \Rightarrow key to move the cursor to “NUM”.
3			By touching the \uparrow key, the screen used to enter a numerical value pulse width will change to the screen used to fix the duty ratio at 50%.
4			To enter the pulse width using a numerical value, return to the numerical value entry screen by using the \uparrow key, and move the cursor to the desired digits using the \Rightarrow key.
5			Use the \downarrow and \uparrow keys to change the numbers.

Step	Screen		Procedure
	(English)	(Japanese)	
6	 <p>#PLS 13.889 % WID NUM 005.00ms</p>	 <p>#パルス 13.889 % ハバ NUM 005.00ms</p>	Touch the  key to move the cursor to the “#”.

Setting high and low limit alarms

An alarm is output when the instantaneous percent flow rate exceeds the preset high and low limits.

Important






This function can be used when the high/low limit alarm is selected in the contact output function.

Default setting

HI-ALM +115%, LO-ALM -115%

Setting range

HI-ALM -115 to +115%, LO-ALM -115 to +115%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the high and low limit alarm setup screen by following the steps to enter the engineering mode.
2			Use the \Rightarrow key to move the cursor to desired digit.
3			Use the \downarrow and \uparrow keys to change the numbers.
4			Touch the \Rightarrow key to move the cursor to the “#”.

Make sure to set so that HI-ALM>LO-ALM.

Setting a 2-stage flow rate alarm

The first alarm will be output when the instantaneous percent flow rate exceeds the preset first high or low limit. The second alarm will be output when the flow rate exceeds the second high or low limits.

Important

This function can be used when the 2-stage high/low limit alarm is selected in the contact output function.

Default setting















HI-ALM1, HI-ALM2 +115%

LO-ALM1, LO-ALM2 -115%

Setting range

HI-ALM1, HI-ALM2 -115 to +115%

LO-ALM1, LO-ALM2 -115 to +115%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the 2-stage high/low limit alarm setup screen by following the steps to enter the engineering mode.
2			Use the  key to move the cursor to the desired digits.
3			Use the  and  keys to change the numbers.
4			Touch the  key to move the cursor to the “#”.
5			Touch the  key to set the 2-stage high limit alarm in the same way.
6			Use the  key to move the cursor to the desired digits.
7			Use the  and  keys to change the numbers.

Step	Screen		Procedure
	(English)	(Japanese)	
8			Touch the key to move the cursor to the “#”.

Selecting fail-safe mode for the analog output

This function is used to determine the analog output direction when the electromagnetic flowmeter detects a critical status condition.

	CAUTION
	The fail-safe mode is very important for overall safety of the control process. Choose the fail-safe direction carefully, as equipment damage can result from a wrong choice.

Default setting

“LOW”

Setting range

“LOW” Minimize the output

“HIGH” Maximize the output

“HOLD” Holds the analog output to the value obtained just before the critical status condition occurred.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the fail-safe mode for the analog output screen by following the steps to enter the engineering mode.
2			Touch the ⇨ key.
3			Use the ⬆ or ⬇ key to determine the fail-safe direction.
4			Touch the ⇨ key to move the cursor to the “#”.

Selecting fail-safe mode for the pulse output

This function is used to determine the pulse output direction when the electromagnetic flowmeter detects a critical status condition.

	CAUTION
	The fail-safe mode is very important for overall safety of the control process. Choose the fail-safe direction carefully, as equipment damage can result from a wrong choice.

Default setting

“LOW”

Setting range

“LOW” Outputs no pulse

“HOLD” Holds the pulse to the value obtained just before the critical status condition occurred.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the fail-safe mode for the pulse output screen by following the steps to enter the engineering mode.
2			Touch the ⇨ key.
3			Use the ⬆ or ⬇ key to determine the fail-safe direction.
4			Touch the ⇨ key to move the cursor to the “#”.

Setting the contact output status

This is used to set the contact output status for normal operation.

Important

This function is displayed when contact output has been selected.





Default setting

“CLOSE”






Setting range

“CLOSE”, “OPEN”

<For 1-contact input and 1-contact output>

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the contact output status setup screen by following the steps to enter the engineering mode.
2			Touch the ⇨ key
3			Use the ⇧ key to set the contact output status.
4			Touch the ⇨ key to move the cursor to the “#”.

<For 2-contact output>

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the contact output status setup screen by following the steps to enter the engineering mode.
2			Touch the  key
3			Use the  and  keys to set the contact output status.
4			Touch the  key to move the cursor to the “#”.
5			Use the  key to move the ST.OUT2 MODE screen.
6			Touch the  key to set contact output 2 in the same way.

Damping time constant

The damping time constant removes minute fluctuations when transmitting the measured flow rate to the control equipment. Check the amplitude of fluctuation in flow output and set the damping time constant to an appropriate value. The new value becomes effective as soon as it is entered

Default setting

3.0 second.

Setting range

0.1 to 199.9 seconds.

(0.0 to 199.9 seconds for “Fast Response Option for Short Run Batch Process.”)

Step	Screen		Procedure
	(English)	(Japanese)	
7			Enter the ADVANCED mode. (See page 4-23).
8			Use the Touch  or  key to cycle through the screens until the damping screen appears.
9			Touch the  key until the cursor is at the value to be changed. (in the example, the key is touched three times.)
10			Use  or  key to change the numeric value. Touch and holding either key quickly increments or decrements the values.
11			Touch the  key until the cursor is back at the mode indicator. Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the Damping Time Value.

Manual zeroing

When piping vibration exists, process fluid slightly moves and display shows some values even though the fluid stands still. This function is used to adjust zero manually when the above phenomena occurs.

Important




Make sure to use the Manual zeroing function after using Auto zero function properly.

Manual zero is effective when the flow rate range is set as 0.2m/s or less.

When using the manual zeroing function, set damping time as 10 seconds or longer.

How to set

Verify the process fluid stands still. If the display shows some value, use the \uparrow or \downarrow key to adjust to 0%.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED mode. (See page 4-23). Use the Touch \uparrow or \downarrow key to cycle through the screens until the Manual Zero screen appears.
2			Touch the \rightarrow key to move the cursor to READY. Use the \uparrow or \downarrow key to adjust Zero. When the flow rate range is set as 0.2 m/s, value can be changed by 0.01% with every touch of \uparrow or \downarrow key. When the flow rate range is set as 0.1 m/s, value can be changed by 0.02% with every touch of \uparrow or \downarrow key.
3			Touch the \rightarrow key to move the cursor to the “&”.
4			Touch the MODE key to save data.

Setting moving average

This function is used to carry out the moving average processing of the measured flow rate values. In this mode, the MGG10C/14C performs the flow rate calculation every 200 ms. For example, if the moving average process time is set to 2 seconds, the moving average processing will be carried out $2 \text{ sec.}/200 \text{ ms}=10$ times.

If pulsation are generated, this function can be used to suppress the flow rate fluctuations. Set the averaging time as the time of the pulsation period.

Default setting



OFF

Setting range

OFF or 1.0 s to 30.0 s

The moving average processing can be given by the following formula:

$$Q_{\text{current}} = \frac{\sum_{n=1}^k Q_k}{k} .$$

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE. (See page 4-23). Use the \uparrow or \downarrow key to cycle through the screens until AVERAGING screen appears.
2			Touch the \rightarrow key to move the cursor to OFF.
3			Touch the \uparrow key to switch the OFF screen to the ON screen. Touch the \rightarrow key to move the cursor to the value to be changed. Touch the \uparrow or \downarrow key to set a desired value
4			Touch the \rightarrow key to move the cursor to back to the “&”.

Step	Screen		Procedure
	(English)	(Japanese)	
5			Touch the MODE key to return to the MEASURING MODE and save the data.

Auto spike cut function


This function eliminates steep noise spikes (spike noise) in the flow rate. Noise generated when solids hit the electrode is an example of the spike noise.

When the flow rate changes sharply, this function holds the outputs according to the damping time. Generally the spike noise occurs in a few milliseconds and settles down within the output holding time and the outputs are not affected. For ordinary flow rate changes, the output responds after the damping hold time.

It is not recommended to use this function for applications requiring high response and performance, e.g., the function should not be used when a pump frequently generates pulsation.

Default setting

OFF

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter the ADVANCED Mode. (See page 4-23). Use the  or  key to cycle through the screens until AUTO SPIKECUT screen appears.
2			Touch the  key to move the cursor to the OFF.
3			Touch the  key to switch the OFF screen to the AUTO screen.
4			Touch the  key to move the cursor to back to "&".
5			Touch the MODE key to return to the MEASURING MODE and save the data.

Manual spike cut function

This function eliminates steep noise spikes (spike noise) in the flow rate. The manual spike cut function enables to set parameters, spike cut level and spike cut time to best meet the customers application.

Default setting

Spike cut time 0

Spike cut level 1.0

Setting range

Spike cut time: 00.0 to 99.9s

Spike cut level: 1.0 to 99.9%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter the ADVANCED Mode. (See page 4-23). Use the  or  key to cycle through the screens until SPIKE CUT TIME or SPIKE CUT LEVEL screen appears.
			
2			Touch the  key to move the cursor to the value to be changed. Touch the  or  key to set a desired value.
			
3			Touch the MODE key to return to the MEASURING MODE and save the data.

Coefficient of compensation

This function changes the Coefficient, which multiplies the output flow rate in the main display.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the  or  key to cycle through the screens until the COEFFICIENT screen appears.
2			Touch the  key until the cursor is at the value to be changed. Default setting: 1.0000 Setting Range: 0.1000 to 9.9999
3			Touch the  or  key to change the value.
4			Touch the  key until the cursor is back at the mode indicator.
5			Touch the MODE key and hold for three seconds to return to MEASUREMENT MODE to save the new value. <div style="border: 1px solid black; padding: 5px;"> CAUTION  You must return to MEASURING MODE within two minutes to save this new value before the system resets it to the previously saved value.</div>

Setting the drop-out





A drop out is set to prevent incorrect integration of the flow rate. Pulse counting will pause when the flow rate is at the preset percentage of the set range.

Default setting

2%

Setting range

0 - 10%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until the DROPOUT screen appears.
2			Touch the \rightarrow key.
3			Use the \downarrow and \uparrow keys to change the numbers.
4			Touch the \rightarrow key to move the cursor to the “&”.
5			Touch the MODE key return to the MEASURING MODE and save the data.

Setting the low flow cut

This function is used to set the low flow cutoff value.


When the flow rate reaches set value, the analog output is cutoff and the display is latched to zero to avoid errors due to flow pulsation in range value closed to zero.

Default setting

OFF

Setting range

OFF or ON 0% - ON 10%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Open the low flow cut setup screen by following the steps to enter the advanced mode.
2			Touch the  key to move the cursor to OFF.
3			By touching the  key, the “OFF” message will change to “ON”. Now you can enter the low flow cut in a numerical value.
4			Touch the  key, and the cursor will moves to the numerical figures.
5			Use the  and  keys to select the desired numbers.
6			Touch the  key to move t.he cursor to the “&”.
7			Touch the MODE key return to the MEASURING MODE and save the data.

Setting decimal place

This function is used to set the decimal place. The decimal place is related to the flow rate range.

Default setting

Same as the setting flow rate range or DECIMAL PLACE:2

Setting range

DECIMAL PLACE (Single range): 0 to 4

DECIMAL PLACE (Dual or Normal/Reverse range): 0 to 4


Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until DECIMAL PLACE appears.
2			Touch the \Rightarrow key to move the cursor to the number. Use the \downarrow or \uparrow key to set the desired number.
3			Touch the \Rightarrow key to move the cursor to back to "&".
4			Touch the MODE key to return to the MEASURING MODE and save the data.

Change the excitation frequency

This function is used to change the excitation frequency.

Important

The excitation frequency is determined by the power supply frequency. Selectable frequencies are 1/8, 1/4 and 1/2 of power supply frequency. Lower frequency has better zero stability and higher frequency is suitable for slurry applications. “Default: 1/4 of power supply frequency”.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until the EX FREQUENCY screen appears.
2			Touch the \rightarrow key to move the cursor to the frequency value.
3			Use the \downarrow or \uparrow key to set a desired frequency.
4			Touch the \rightarrow key to move the cursor to back to “&”.
5			Touch the MODE key to return to the MEASURING MODE and save the data.

- ~ **Note** *The device is calibrated with the excitation frequency which is 1/4 of power supply frequency. Other excitation frequency may affect accuracy.*
- ~ **Note** *In the areas with 60Hz power supply, excitation frequency selections are 7.5Hz, 15Hz, 30Hz.*
- ~ **Note** *In some slurry applications, excess output noise may be present. Switching to a higher excitation frequency may reduce this output noise providing a more stable signal. It should be noted that changing to a higher frequency may introduce measurement error of a few percent. Please contact Azbil Corporation for assistance before utilizing this feature.*




Setting the analog output limit

This function is used to activate analog output limit. The analog output limit is determined by the values set by the HI/LO alarm function.

Default setting

OFF

When this function is set as ON, the analog output is output between values set as HI/LO alarm function.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \downarrow or \uparrow key to cycle through the screens until the I.OUT LIMITER screen appears.
2			Touch the \Rightarrow key to move the cursor to the OFF.
3			Use the \downarrow or \uparrow key to switch the OFF to ON.
4			Touch the \Rightarrow key to move the cursor to back to "&".
5			Touch the MODE key to return to the MEASURING MODE and save the data.

Change the flow direction

This function is used when the detector is installed in opposite direction to the flow direction.

Default setting

FORWARD (the direction mark on the detector matches the direction of flow.)



Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \uparrow or \downarrow key to cycle through the screens until the FLOW DIRECTION screen appears.
2			Touch the \rightarrow key to move the cursor to FORWARD
3			Touch the \uparrow or \downarrow key to switch the “FORWARD” to the “REVERSE”.
4			Touch the \rightarrow key to move the cursor to back to “&”.
5			Touch the MODE key to return to the MEASURING MODE and save the data.

Error history check/clear

The latest eight errors can be checked.

Error display

If there is no error, [1 NO ERROR] is displayed.

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter ADVANCED MODE (see page 4-23). Use the \uparrow or \downarrow key to cycle through the screens until “ERROR HISTORY” screen appears.
2			If the screen displays other than “NO ERRORS”, touch the \rightarrow key to move the cursor at the number.
3			Use the \uparrow or \downarrow key to change the number and check the error history.
4			Touch the \rightarrow key to move the cursor to back to “&”. Touch the \uparrow key once and display the “CLEAR ERR HST” screen.
5			Touch the \rightarrow key to move the cursor to “READY”. Touch the \uparrow key to clear the error history.
6			Touch the \rightarrow key to move the cursor to back to “&”.
7			Touch the MODE key to return to the MEASURING MODE and save the data.

MEMO

Chapter 5: Maintenance and Troubleshooting

This chapter contains the maintenance and inspection procedures for the flowmeter and troubleshooting.

Output signal loop check:

- Analog output
- Pulse output
- Excitation current

Simulated signal input by the calibrator

Regarding the operations through SFC communicator, refer to the users manual CM2-MGG000-2001.

Function check

Input and output signal loop check

The analog output can be checked by using the electromagnetic flowmeter as a constant-current generator.

By using this function, loop check and wiring check can be done.

Other instruments in the loop, such as recorders and controllers can be checked.

Check items

- Analog output
- Pulse output
- Contact input/output
- Excitation current

Analog output check





The analog output can be checked by using the electromagnetic flowmeter as a constant-current generator.

Default setting

Existing analog output

Setting range

000.0 to 115.0%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter MAINTENANCE MODE (see page 4-24). Use the \uparrow or \downarrow key to cycle through screen until “OUTPUT CHECK” screen appears. Touch the \rightarrow key once to move the cursor to “OFF”. Touch the \uparrow key to switch the OFF screen to ON screen.
2			Touch the \rightarrow key to move the cursor at the percent value to be checked.
3			Use the \uparrow or \downarrow key to set the desired value. In this example, the analog output is set as 100%, i.e. 20mA.
4			Touch the \rightarrow key to move the cursor to “>”.
5			Use the \uparrow or \downarrow key to move other screen. Then the analog output is back to the value according to the measured flow rate.

~ **Note** If no operation is done for ten minutes, the output check mode automatically finishes and return to the Measuring mode.

Pulse output check





The pulse output can be checked by using the electromagnetic flowmeter as a pulse generator.

Default setting

Existing measured value

Setting range

000.0 to 115.0%

Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter MAINTENANCE MODE (see page 4-24). Use the \uparrow or \downarrow key to cycle through screen until “OUTPUT CHECK I.OUT” screen appears. Touch the \rightarrow key once to move the cursor to “OFF”. Touch the \uparrow key to switch the OFF screen to ON screen. Touch the \uparrow key once to move to “OUTPUT P. OUT” screen.
2			Touch the \rightarrow key to move the cursor at the percent value to be checked.
3			Use the \uparrow or \downarrow key to set the desired value. In this example, the pulse equivalent to the 100% flow rate is output.
4			Touch the \rightarrow key to move the cursor to “>”.
5			Use the \uparrow or \downarrow key to move other screen. Then the pulse output is back to the value according to the measured flow rate.

~ Note If no operation is done for ten minutes, the output check mode finishes automatically and return to the Measuring mode.

Contact input/output loop check

By switching contact input terminal ON/OFF, contact input terminal status can be checked through the LCD.

By switching contact output terminal ON/OFF, contact output loop can be checked. Display varies according to the selection of contact input and output.

Default setting

Display the existing status

Setting range


“CLOSE”, “OPEN”

<Contact input and contact output>




Step	Screen		Procedure
	(English)	(Japanese)	
1			Enter MAINTENANCE MODE (see page 4-24). Use the \uparrow or \downarrow key to cycle through screen until “OUTPUT CHECK” screen appears. Touch the \rightarrow key once to move the cursor to “OFF”. Touch the \uparrow key to switch the OFF screen to ON screen. Touch the \uparrow key twice to move to “OUTPUT CHECK ST. IN/OUT” screen.
2			Touch the \rightarrow key to move the cursor at the status (OPEN/CLOSE).
3			Use the \uparrow key to select the desired output status (OPEN/CLOSE).
4			For the contact input, the display indicates current contact input status (OPEN/CLOSE).

Step	Screen		Procedure
	(English)	(Japanese)	
5			Touch the ⇨ key to move the cursor to “>”.
6			Use the ⬆ or ⬇ key to move other screen. Then the contact input and output are back to the current status (OPEN/CLOSE).

<2-contact inputs>



Step	Screen		Procedure
	(English)	(Japanese)	
1			<p>Enter MAINTENANCE MODE (see page 4-24). Use the ⬆ or ⬇ key to cycle through screen until “OUTPUT CHECK” screen appears.</p> <p>Touch the ⇨ key once to move the cursor to “OFF”.</p> <p>Touch the ⬆ key to switch the OFF screen to ON screen.</p> <p>Touch the ⬆ key twice to move to the “OUTPUT CHECK ST. IN” screen.</p>
2			The display indicates the current contact input status (OPEN/CLOSE).

<2-contact outputs>

Step	Screen		Procedure
	(English)	(Japanese)	
1	 <p>≥ ST. OUT1 CLOSE ST. OUT2 <u>C</u>LOSE</p>	 <p>≥ セッテンアウト1 CLOSE セッテンアウト2 <u>C</u>LOSE</p>	<p>Enter MAINTENANCE MODE (see page 4-24). Use the \uparrow or \downarrow key to cycle through screen until “OUTPUT CHECK” screen appears.</p> <p>Touch the \rightarrow key once to move the cursor to “OFF”. Touch the \uparrow key to switch the OFF screen to ON screen. Touch the \uparrow key twice to move to the “OUTPUT CHECK ST. OUT” screen.</p>
2	 <p>> ST. OUT1 OPEN ST. OUT2 <u>C</u>LOSE</p>	 <p>> セッテンアウト1 CLOSE セッテンアウト2 <u>C</u>LOSE</p>	<p>Touch the \rightarrow key to move the cursor at the status (OPEN/CLOSE).</p>
3	 <p>> ST. OUT1 OPEN ST. OUT2 <u>O</u>PEN</p>	 <p>> セッテンアウト1 OPEN セッテンアウト2 <u>O</u>PEN</p>	<p>Use the \rightarrow key to move the cursor at the status (OPEN/CLOSE).</p>
4	 <p>≥ ST. OUT1 OPEN ST. OUT2 <u>O</u>PEN</p>	 <p>≥ セッテンアウト1 OPEN セッテンアウト2 <u>O</u>PEN</p>	<p>Touch the \rightarrow key to move the cursor to “>”.</p>
5			<p>Use the \uparrow or \downarrow key to move the other screen.</p> <p>Then the contact input and output are back to the current status (OPEN/CLOSE).</p>

Excitation current check

This function is used to check the excitation current.

Step	Screen		Procedure
	(English)	(Japanese)	
1			<p>Enter MAINTENANCE MODE (see page 4-24). Use the \uparrow or \downarrow key to cycle through screen until “OUTPUT CHECK” screen appears. Touch the \leftarrow key once to move the cursor to “OFF”.</p> <p>Touch the \uparrow key to switch the ON screen.</p> <p>Touch the \uparrow key three times to move the “EX CHECK” screen. In this status, the excitation current runs from X to Y. Verify the excitation current is 160mA.</p>
2			<p>Touch the \rightarrow key once to move the cursor at the “E” of “EXX”.</p>
3			<p>Touch the \uparrow key once, then the excitation current runs from Y to X.</p>
4			<p>Touch the \uparrow key once, then the excitation current stops.</p>
5			<p>Touch the \rightarrow key once to move the cursor to “>”.</p>
6			<p>Use the \uparrow or \downarrow key to move to the other screen. Then the excitation current is added to the coil to measure the flow rate.</p>

Simulated signal by the calibrator

The model MGZ14 calibrator and the model F1X calibrator are available for this converter. The calibrator inputs the simulated signal to the converter. By using the calibrator, the converter function can be checked.

Preparation

Calibrator and cables
 Digital voltmeter
 Resistor (250 Ω)

Check the converter by following the user's manual of the calibrator.


CM2-MGZ100-2001 for the model MGZ14. CM2-F1X100-2001 for the model F1X.

! CAUTION




In case using the MGZ calibrator of the S/W version 1.6 or earlier with the converter of the model code MGG10C-M____-____-__, MGG14C-M____-____-__, make sure to connect cables of the MGZ calibrator to the connectors as indicated in the below drawings. If not, the calibrator may not work properly..

Integral style



Remote style



In case the X,Y cable from the detector is not connected together with the X,Y cable of the MGZ calibrator, upgrade the S/W version of MGZ from the current version to 1.7 or later version.

Troubleshooting

Overview

Introduction

If a problem occurs at Electromagnetic Flowmeter start-up and operation, the following four causes should be considered:

- Misapplication of the electromagnetic flowmeter
- Wrong setting or wrong operation
- Electromagnetic Flowmeter malfunction
- Improper wiring

If a problem occurs during operation, the device's self-diagnostic function will classify it as critical or non-critical. It will indicate this and respond accordingly.

Perform the proper correction measures, referring to the troubleshooting guidelines described in this section.

Critical failures

Critical problems may disrupt Electromagnetic Flowmeter operation, if not corrected, ultimately damage the Flowmeter. When critical trouble occurs during Electromagnetic Flowmeter operation, an error message will appear on the converter's display panel and the Flowmeter will continue to output the preset value in the abnormality treatment (fail-safe) direction. The error message and the self-diagnostic results will be visible on the display panel.

Example:

CPU CHECK ERROR: This message appears if the ROM or RAM is in abnormal condition.

Non-critical failures

Non-critical problems will not seriously affect Electromagnetic Flowmeter operation. When an error occurs during Electromagnetic Flowmeter operation and is regarded as a non-critical problem by the converter self-diagnostics, the output will not burn-out and the Electromagnetic Flowmeter will continue to output the measured value.

Errors at startup

When a problem occurs at start-up, perform the procedures listed in the following table. If the problem persists, the flowmeter may be damaged and you should contact technical support. (For technical support, contact an Azbil Corp. sales representative in your area.)

Table 5-1 Startup Errors

Symptom	Check Points and Treatment
No display after power on.	<ul style="list-style-type: none"> • Check the converter power supply specification and ensure that the power supply being supplied meets these requirements. • Make sure the ambient temperature is not below -25 °C (13 °F).
No output after power-on.	<ul style="list-style-type: none"> • Verify that the signal line is correctly connected.
Communication can not be done.	<ul style="list-style-type: none"> • Check the switch position. Refer to the Figure 2-15. • Check if the wiring is properly completed. • Check if the SFC is properly connected. • Check if the S/W version of the SFC is Ver.7.0 or later. • Check if the HART communicator is 375. Check if the DD file is downloaded.
No pulse output.	<ul style="list-style-type: none"> • Check the wiring of the pulse output loop. • Check the receiving device specifications. (pulse width, frequency, voltage drop). • Check if the pulse output is open collector type or Drive counter.
Output remains 0mA.	<ul style="list-style-type: none"> • Verify that power source and power supply voltage. • Verify the wiring. Refer to the Figure 2-15.

Operation errors

When a problem occurs during operation:

Check against the table on this page for symptoms of the error. If found, perform the steps indicated in the table. If the problem persists, the flowmeter may be damaged and you should contact technical support. (For technical support, contact an Azbil Corp. sales representative in your area.)

Table 5-2 Operation Errors

Symptom	Check Points and Treatment
Output fluctuates excessively beyond the estimated flow rate range.	<ul style="list-style-type: none"> • Verify that the detector is properly grounded. • Verify that the converter is properly grounded. • Verify that the damping time constant is set correctly. If not, set the an appropriate damping time constant. • Clean the electrodes.
Flow rate exceeds the flow range	<ul style="list-style-type: none"> • Check the flow range setting and make sure it is set to match the detector and process flow. If not, set an appropriate RANGE. • Check that the flowmeter has been zeroed. If not, calibrate the flowmeter.
Output exceeds 100%.	<ul style="list-style-type: none"> • Verify that the set range is set correctly. • Verify that the span is set correctly. • Verify that the zero point is correctly adjusted. • Verify that the converter is correctly calibrated.
Output remains 0%.	<ul style="list-style-type: none"> • The pipe may be empty. Use the empty detection function to check whether or not the pipe is empty. (If it is empty, the empty detection function will be functioning.) • Verify that the signal cable is correctly connected. • Verify that the valves are open on the upper and lower sides. • Verify that the span is set correctly. • Verify that the converter is set to the constant current mode. • Verify that the flow rate is not in the low flow cutoff range.
Output is in the fail-safe mode.	<ul style="list-style-type: none"> • Check the error code.
Pulse output is too large or too small.	<ul style="list-style-type: none"> • Verify if the pulse weight and width are set correctly. • Verify the converter is correctly calibrated. • Verify the pulse counter is proper. • Verify the dropout value is correctly set between 0 and 10%.

Error messages

Error messages are grouped by the severity of the problem. There are messages for non-critical problems and for critical problems.

Error codes for critical problems

Critical problems can disrupt flowmeter operation and ultimately damage the flowmeter if not corrected. When critical trouble occurs during operation, an error message appears on the converter's display panel and the flowmeter continues to output the preset value in the fail-safe direction. The error message and the self-diagnostic results are visible on the display panel.

The following table shows the possible error codes for critical problems and what to do. If the problem persists after trying these solutions, contact technical support. (For technical support, contact an Azbil Corp. sales representative in your area.)

Table 5-3 Critical Errors






Error Screen	Error	Solution
 <p>The display shows 'Err-01' in large digits, 'EX CHECK' below it, and 'ERROR' in the bottom right corner.</p>	EX check Error (Excitation circuit is open.)	<ul style="list-style-type: none"> • Check connection of terminal/wiring of X and Y. • Check if the resistance of coil is less than 50 Ω. (Coil resistance is to be checked between X and Y terminal of a detector.) • Cycle power.
 <p>The display shows 'Err-02' in large digits, 'ROM CHECK' below it, and 'ERROR' in the bottom right corner.</p>	ROM check error	<ul style="list-style-type: none"> • Cycle power. • Replace the ROM. • Replace main card.
 <p>The display shows 'Err-03' in large digits, 'RAM CHECK' below it, and 'ERROR' in the bottom right corner.</p>	RAM read after write error	<ul style="list-style-type: none"> • Cycle power. • Replace main card.
 <p>The display shows 'Err-04' in large digits, 'NUM CHECK' below it, and 'ERROR' in the bottom right corner.</p>	NVM read after write error	<ul style="list-style-type: none"> • Cycle power. • Replace main card.
 <p>The display shows 'Err-05' in large digits, 'ADC CHECK' below it, and 'ERROR' in the bottom right corner.</p>	ADC error A/D change error	<ul style="list-style-type: none"> • Cycle power. • Replace main card.

Error codes for non-critical problems

Non-critical problems do not seriously disrupt flowmeter operation. When an error occurs during operation and is regarded by the system as a non-critical problem, the flowmeter continues to output the flow rate.

The following table shows the possible error codes for non-critical problems and what to do. If the problem persists after trying these solutions, contact technical support. (For technical support, contact an Azbil Corp. sales representative in your area.)

Table 5-4 Non-critical

Error Screen	Error	Solution
	Detector type and diameter do not match.	<ul style="list-style-type: none"> Check the setting for the detector diameter and enter the correct diameter.
	High/low limit alarm error. HI < LO	<ul style="list-style-type: none"> Set HI > LO.
	The span setting is greater than 12 m/s.	<ul style="list-style-type: none"> Check the SPAN setting. Check the DIA setting. Check the TYPE setting Check the DUMMY setting.
	The pulse frequency is either too high or too low.	<ul style="list-style-type: none"> Check the pulse weight setting. Check the pulse frequency setting. Check the engineering unit match span unit.
	Pulse width too large. Duty 70% or more at pulse frequency output.	<ul style="list-style-type: none"> Check 1. Pulse width 2. Pulse weight and 3. Span setting
	Hysteresis exceeding 100% of range in normal/reverse automatic range	<ul style="list-style-type: none"> Check hysteresis setting.

Safety precautions

Introduction

Correct operation is necessary for the safe and efficient use of the SFC and MagneW FLEX+/PLUS+. Carefully read the safety precautions described in this user's manual and have a thorough understanding of it before operating the product.

Operating precautions

For safe use of the instrument, this manual uses the following symbols:

 WARNING	
	Denotes a potentially hazardous situation, which is not avoided could result in death or serious injury.

 CAUTION	
	Denotes a potentially hazardous situation which if not avoided could result in minor injury or damage to device.

Examples of symbol

	The symbol indicates a specific action that is prohibited to prevent danger. The prohibited action (prohibition of dismantling in the case of the figure at left) is indicated by a symbol or next to the symbol.
	The symbol indicates a specific action that is mandatory to prevent danger. The mandatory action (the plug should be removed from the socket in the case of the figure at left) is indicated by a symbol.

 CAUTION	
	Set the loop of the electromagnetic flow meter whose setting is to be changed to “manual” before starting communication with the SFC. Its output may change due to a communication signal, affecting the operation or control of the plant.
	Do not throw the battery for the SFC into fire. This may result in explosion. Be sure to remove the AC adapter for the SFC from the socket if it is not used. The AC adapter may be over heat.

Structure and functions of SFC

This section presents the structure and functions of the Smart Field Communicator SFC.

- Describes the key types, brief functions of keys, which are color-coded, and general rules of key operations of the SFC.
- Describes names and functions of the SFC keys.

~ Note *For the method of connection between the SFC and MagneW Flowmeter, see the user's manual of the MagneW Flowmeter.*

Terms and Conditions

We would like to express our appreciation for your purchase and use of Azbil Corporation's products.

You are required to acknowledge and agree upon the following terms and conditions for your purchase of Azbil Corporation's products (system products, field instruments, control valves, and control products), unless otherwise stated in any separate document, including, without limitation, estimation sheets, written agreements, catalogs, specifications and instruction manuals.

1. Warranty period and warranty scope

1.1 Warranty period

Azbil Corporation's products shall be warranted for one (1) year from the date of your purchase of the said products or the delivery of the said products to a place designated by you.

1.2 Warranty scope

In the event that Azbil Corporation's product has any failure attributable to azbil during the aforementioned warranty period, Azbil Corporation shall, without charge, deliver a replacement for the said product to the place where you purchased, or repair the said product and deliver it to the aforementioned place. Notwithstanding the foregoing, any failure falling under one of the following shall not be covered under this warranty:

- (1) Failure caused by your improper use of azbil product (noncompliance with conditions, environment of use, precautions, etc. set forth in catalogs, specifications, instruction manuals, etc.);
- (2) Failure caused for other reasons than Azbil Corporation's product;
- (3) Failure caused by any modification or repair made by any person other than Azbil Corporation or Azbil Corporation's subcontractors;
- (4) Failure caused by your use of Azbil Corporation's product in a manner not conforming to the intended usage of that product;
- (5) Failure that the state-of-the-art at the time of Azbil Corporation's shipment did not allow Azbil Corporation to predict; or
- (6) Failure that arose from any reason not attributable to Azbil Corporation, including, without limitation, acts of God, disasters, and actions taken by a third party.

Please note that the term "warranty" as used herein refers to equipment-only-warranty, and Azbil Corporation shall not be liable for any damages, including direct, indirect, special, incidental or consequential damages in connection with or arising out of Azbil Corporation's products.

2. Ascertainment of suitability

You are required to ascertain the suitability of Azbil Corporation's product in case of your use of the same with your machinery, equipment, etc. (hereinafter referred to as "Equipment") on your own responsibility, taking the following matters into consideration:

- (1) Regulations and standards or laws that your Equipment is to comply with.
- (2) Examples of application described in any documents provided by Azbil Corporation are for your reference purpose only, and you are required to check the functions and safety of your Equipment prior to your use.
- (3) Measures to be taken to secure the required level of the reliability and safety of your Equipment in your use

Although azbil is constantly making efforts to improve the quality and reliability of Azbil Corporation's products, there exists a possibility that parts and machinery may break down. You are required to provide your Equipment with safety design such as fool-proof design,*1 and fail-safe design*2 (anti-flame propagation design, etc.), whereby preventing any occurrence of physical injuries, fires, significant damage, and so forth. Furthermore, fault avoidance,*3 fault tolerance,*4 or the like should be incorporated so that the said Equipment can satisfy the level of reliability and safety required for your use.

*1. A design that is safe even if the user makes an error.

*2. A design that is safe even if the device fails.

*3. Avoidance of device failure by using highly reliable components, etc.

*4. The use of redundancy.

3. Precautions and restrictions on application

3.1 Restrictions on application

Please follow the table below for use in nuclear power or radiation-related equipment.

	Nuclear power quality*5 required	Nuclear power quality*5 not required
Within a radiation controlled area*6	Cannot be used (except for limit switches for nuclear power*7)	Cannot be used (except for limit switches for nuclear power*7)
Outside a radiation controlled area*6	Cannot be used (except for limit switches for nuclear power*7)	Can be used

*5. Nuclear power quality: compliance with JEAG 4121 required

*6. Radiation controlled area: an area governed by the requirements of article 3 of "Rules on the Prevention of Harm from Ionizing Radiation," article 2 2 4 of "Regulations on Installation and Operation of Nuclear Reactors for Practical Power Generation," article 4 of "Determining the Quantity, etc., of Radiation-Emitting Isotopes," etc.

*7. Limit switch for nuclear power: a limit switch designed, manufactured and sold according to IEEE 382 and JEAG 4121.

Any Azbil Corporation's products shall not be used for/with medical equipment.

The products are for industrial use. Do not allow general consumers to install or use any Azbil Corporation's product. However, azbil products can be incorporated into products used by general consumers. If you intend to use a product for that purpose, please contact one of our sales representatives.

3.2 Precautions on application

you are required to conduct a consultation with our sales representative and understand detail specifications, cautions for operation, and so forth by reference to catalogs, specifications, instruction manual, etc. in case that you intend to use azbil product for any purposes specified in (1) through (6) below. Moreover, you are required to provide your Equipment with fool-proof design, fail-safe design, anti-flame propagation design, fault avoidance, fault tolerance, and other kinds of protection/safety circuit design on your own responsibility to ensure reliability and safety, whereby preventing problems caused by failure or nonconformity.

- (1) For use under such conditions or in such environments as not stated in technical documents, including catalogs, specification, and instruction manuals
- (2) For use of specific purposes, such as:
 - * Nuclear energy/radiation related facilities
[When used outside a radiation controlled area and where nuclear power quality is not required]
[When the limit switch for nuclear power is used]
 - * Machinery or equipment for space/sea bottom
 - * Transportation equipment
[Railway, aircraft, vessels, vehicle equipment, etc.]
 - * Antidisaster/crime-prevention equipment
 - * Burning appliances
 - * Electrothermal equipment
 - * Amusement facilities
 - * Facilities/applications associated directly with billing
- (3) Supply systems such as electricity/gas/water supply systems, large-scale communication systems, and traffic/air traffic control systems requiring high reliability
- (4) Facilities that are to comply with regulations of governmental/public agencies or specific industries
- (5) Machinery or equipment that may affect human lives, human bodies or properties
- (6) Other machinery or equipment equivalent to those set forth in items (1) to (5) above which require high reliability and safety

4. Precautions against long-term use

Use of Azbil Corporation's products, including switches, which contain electronic components, over a prolonged period may degrade insulation or increase contact-resistance and may result in heat generation or any other similar problem causing such product or switch to develop safety hazards such as smoking, ignition, and electrification. Although acceleration of the above situation varies depending on the conditions or environment of use of the products, you are required not to use any Azbil Corporation's products for a period exceeding ten (10) years unless otherwise stated in specifications or instruction manuals.

5. Recommendation for renewal

Mechanical components, such as relays and switches, used for Azbil Corporation's products will reach the end of their life due to wear by repetitious open/close operations.

In addition, electronic components such as electrolytic capacitors will reach the end of their life due to aged deterioration based on the conditions or environment in which such electronic components are used. Although acceleration of the above situation varies depending on the conditions or environment of use, the number of open/close operations of relays, etc. as prescribed in specifications or instruction manuals, or depending on the design margin of your machine or equipment, you are required to renew any Azbil Corporation's products every 5 to 10 years unless otherwise specified in specifications or instruction manuals. System products, field instruments (sensors such as pressure/flow/level sensors, regulating valves, etc.) will reach the end of their life due to aged deterioration of parts. For those parts that will reach the end of their life due to aged deterioration, recommended replacement cycles are prescribed. You are required to replace parts based on such recommended replacement cycles.

6. Other precautions

Prior to your use of Azbil Corporation's products, you are required to understand and comply with specifications (e.g., conditions and environment of use), precautions, warnings/cautions/notices as set forth in the technical documents prepared for individual Azbil Corporation's products, such as catalogs, specifications, and instruction manuals to ensure the quality, reliability, and safety of those products.

7. Changes to specifications

Please note that the descriptions contained in any documents provided by azbil are subject to change without notice for improvement or for any other reason. For inquires or information on specifications as you may need to check, please contact our branch offices or sales offices, or your local sales agents.

8. Discontinuance of the supply of products/parts

Please note that the production of any Azbil Corporation's product may be discontinued without notice. After manufacturing is discontinued, we may not be able to provide replacement products even within the warranty period.

For repairable products, we will, in principle, undertake repairs for five (5) years after the discontinuance of those products. In some cases, however, we cannot undertake such repairs for reasons, such as the absence of repair parts. For system products, field instruments, we may not be able to undertake parts replacement for similar reasons.

9. Scope of services

Prices of Azbil Corporation's products do not include any charges for services such as engineer dispatch service. Accordingly, a separate fee will be charged in any of the following cases:

- (1) Installation, adjustment, guidance, and attendance at a test run
- (2) Maintenance, inspection, adjustment, and repair
- (3) Technical guidance and technical education
- (4) Special test or special inspection of a product under the conditions specified by you

Please note that we cannot provide any services as set forth above in a nuclear energy controlled area (radiation controlled area) or at a place where the level of exposure to radiation is equivalent to that in a nuclear energy controlled area.

Document Number:	CM2-MGG310-2001
Document Name:	MagneW FLEX+/PLUS+ Electromagnetic Flowmeter Converter Model MGG10C/MGG14C User's Manual
Date:	1st edition: July. 2007 12th edition: Oct. 2023
Issued/Edited by:	Azbil Corporation

Azbil Corporation